



**9300 JSDA series  
AC SERVO SYSTEM  
Instruction Manual**



**Driving &  
Connecting Globally**

■Warning and Alert:

	<b>Warning</b>
<ul style="list-style-type: none"><li>• Do not proceed to the assembly of the line while electrifying.</li><li>• Circuit &amp; change components between entering shutting down the power supply and stopping showing CHARGE LED light of the Servo driver.</li><li>• The output of Servo drive [U, V, W] must NOT touch the AC power.</li></ul>	

	<b>Alert</b>
<ul style="list-style-type: none"><li>• Install the fan if the temperature around is too high while the Servo driver is installed in the Control Board.</li><li>• Do not proceed to the Anti-Pressure-Test to the Servo driver.</li><li>• Confirm the quick stop function is available before operate servo drive.</li><li>• Matching up machine to change the user parameter setting before machine performs. If there is no according correct setting number, it could lead to out of control or breakdown.</li></ul>	

**Safety proceeding:**

Check the covering letter detail before installing, running, maintaining and examining. Furthermore, only the profession-qualified people can proceed to the line-assembly.

Safety proceeding in the covering letter discriminate between “Warning”&”Alert”.



Indicating the possibility dangerous situation. It could cause the death or serious damage if being ignored.



Indicating the possibility dangerous situation. It could cause smaller or lighter human injured and damage of equipment.

Read this covering letter detail before using Servo driver.

---

First of all, thank you for using TECO Servo Driver JADA Series (“JSDA” for short) and Servo Motors. JSDA can be controlled by digital board or PC, and provide excellent performance for a wide range of applications and different requirement from customers.

Read this covering letter before using JSDA. Contents of the letter comprises:

- Servo System checking, installing and procedure of assembly line.
- Controller procedure for digital board, status displaying, unusual alarm and strategy explanation.
- Servo System control function, running testing and procedures adjusted.
- Explanation for all parameter of Servo Driver.
- Standard specification of JSDA Series.

In order to daily examine, maintain and understand the reason of unusual situation and handle strategy, please put this covering letter in safe place to read it anytime.

P.S: The end user should own this covering letter, in order to make the Servo Driver bring the best performance .

# Contents

## Chapter 1 Checking and Installing

1-1 Checking Products .....	1-1
1-1-1 Confirming with Servo Drives .....	1-1
1-1-2 Confirming with Servomotors .....	1-2
1-2 Surface and Panel Board .....	1-3
1-3 A Brief Introduction of Operation for Drives .....	1-4
1-4 Conditions for Installation of Drives .....	1-5
1-4-1 Environmental Conditions .....	1-5
1-4-2 Direction and Distance .....	1-6
1-5 Conditions for Installation of Servomotors .....	1-7
1-5-1 Environmental Conditions .....	1-7
1-5-2 Method of Installation .....	1-7
1-5-3 Notice for in stall motor .....	1-8

## Chapter 2 Wiring

2-1 Basic Wiring for Servo System .....	2-1
2-1-1 Wiring for Main Circuit and Peripheral Devices .....	2-1
2-1-2 Wiring for Servo Drives .....	2-2
2-1-3 Specifications of Wiring .....	2-3
2-1-4 Motor Terminal Layout .....	2-4
2-1-5 Typical Wiring for Motor and Main Circuit .....	2-6
2-1-6 TB Terminal .....	2-7
2-1-7 Wiring for Mechanical Brake .....	2-8
2-2 I/O Terminal .....	2-9
2-2-1 Output Signals from the Servo pack .....	2-10
2-2-2 Encoder Connector (CN2) Terminal Layout .....	2-23
2-3 Typical Circuit Wiring Examples .....	2-25
2-3-1 Position Control Mode (Pe Mode) (Line Driver) .....	2-25
2-3-2 Position Control Mode (Pe Mode) (Open Collector) .....	2-26
2-3-3 Position Control Mode (Pi Mode) .....	2-27
2-3-4 Speed Control Mode (S Mode) .....	2-28
2-3-5 Torque Control Mode (T Mode) .....	2-29

## Chapter 3 Panel Operator / Digital Operator

3-1 Panel Operator on the Drives .....	3-1
3-2 Signal Display .....	3-6
3-2-1 Status Display .....	3-6
3-2-2 Diagnosis .....	3-7

## Chapter 4 Trial Operation

4-1 Trial Operation for Servomotor without Load .....	4-2
4-2 Trial Operation for Servomotor without Load from Host Reference .....	4-5
4-3 Trial Operation with the Servomotor Connected to the Machine .....	4-9

## Chapter 5 Control Functions

5-1 Control Mode Selection .....	5-1
5-2 Torque Mode .....	5-2
5-2-1 Analog Ratio .....	5-3
5-2-2 Adjusting the Reference Offset.....	5-4
5-2-3 Linear Acceleration and Deceleration .....	5-5
5-2-4 Output Direction .....	5-6
5-2-5 Internal Torque Limit .....	5-7
5-2-6 Limiting Servomotor Speed during Torque Control .....	5-7
5-2-7 Additional Torque Control Functions.....	5-8
5-3 Speed Mode.....	5-9
5-3-1 Setting Parameters .....	5-10
5-3-2 Analog Ratio .....	5-11
5-3-3 Adjusting the Reference Offset.....	5-11
5-3-4 Limiting Speed with Analog Reference .....	5-12
5-3-5 Encoder Signal Output.....	5-12
5-3-6 Smoothing.....	5-14
5-3-7 Definition of CW and CCW.....	5-17
5-3-8 Speed Loop Gain .....	5-18
5-3-9 Notch Filter.....	5-19
5-3-10 Limiting Servomotor Torque during Speed Control .....	5-21
5-3-11 Gain Switched.....	5-22
5-3-12 Other Functions.....	5-29
5-4 Position Mode .....	5-31
5-4-1 External Pulse Command .....	5-32
5-4-2 Internal Position Command.....	5-34
5-4-3 Electronic Gear .....	5-37
5-4-4 Smoothing Acceleration .....	5-41
5-4-5 Definition of Direction .....	5-42
5-4-6 Gain Adjustment .....	5-42
5-4-7 Deleting the Pulse Offset.....	5-43
5-4-8 Original Home .....	5-44
5-4-9 Other Position Functions .....	5-53
5-5 Gain Adjustment.....	5-54
5-5-1 Automatic Adjusting .....	5-57
5-5-2 Manual Adjusting.....	5-60
5-5-3 Improving Resonance.....	5-61
5-6 Other Functions.....	5-62
5-6-1 Programmable I/O Functions .....	5-62
5-6-2 Switching Control Mode .....	5-65
5-6-3 Auxiliary Functions .....	5-65
5-6-4 Brake Mode .....	5-66
5-6-5 Timing Diagram of Mechanical Brake .....	5-66

5-6-6 CW/CCW Inhibit Function .....	5-68
5-6-7 Selecting the External Regeneration Resistor .....	5-69
5-6-8 Fan Setting .....	5-73
5-6-9 Analog Monitor .....	5-73
5-6-10 Parameter .....	5-74
 <b>Chapter 6 Parameter Function</b>	
6-1 Explanation of Parameter Group .....	6-1
6-2 Parameter Display Table .....	6-2
 <b>Chapter 7 Communications Function</b>	
7-1 RS232 & RS485 .....	7-1
7-1-1 Communication wiring .....	7-1
7-1-2 RS232 Communication Protocol and Format .....	7-2
7-1-3 Modbus communication protocol for RS-485 .....	7-5
7-2 Communication Address table.....	7-16
 <b>Chapter 8 Troubleshooting</b>	
8-1 Alarm Display Table.....	8-1
8-2 Troubleshooting of Alarm and Warning .....	8-3
 <b>Chapter 9 Specifications</b>	
9-1 Specifications and Dimension for Servo Drives .....	9-1
9-2 Specifications and Dimension for Servomotors .....	9-7
 <b>Appendix A - Peripheral for Servo motors .....</b>	<b>App-1</b>

# Chapter 1 Checking and Installing


## 1-1 Checking Products

Our Servo Pack have already completely been functionally examined before leaving the factory. In order to protect the products from the damage during transportation, please check the items below before sealing off the pack:


- Check if the models of servo driver and motor are the same with the models of ordering.  
(About the model explanation, please check the chapters below)
- Check if there are damage or scrape out side of the servo driver and motor.  
(If there is any damage during transportation, do not power ON)
- Check if there are any bad assembly or slipped component in the Servo Drive and Motor
- Check if the Motor's rotor and shaft can be rotated smoothly by hand  
(The Servo Motor with Mechanical-Brake can not be rotated directly)
- There must be the "QC"-seal in each servo drive, if not, please do not proceed Power ON.

If there is any bug or irregular under the situation above, please contact TECO's Local sales representative or distributor instantly.

### 1-1-1 Confirming with Servo Drives




1-1-2 Confirming with Servo Motors






# 1-2 Surface and Panel Board


## JSDA-15 / JSDA-20




## JSDA-30



## JSDA-50 / JSDA-75



## Key Board



### 1-3 A Brief Introduction of Operation for Drives

There are many kinds of control-mode. The detail modes display as follow:

Name		Mode	Explanation
Single Mode	Position Mode (External Pulse Command)	Pe	Position control for the servo motor is achieved via an external pulse command. Position command is input from CN1.
	Position Mode (Internal Position Command)	Pi	Position control for the servo motor is achieved via by 16 commands stored within the servo controller. Execution of the 16 positions is via Digital Input signals.
	Speed Mode	S	Speed control for the servo motor can be achieved via parameters set within the controller or from an external analog -10 ~ +10 Vdc command. Control of the internal speed parameters is via the Digital Inputs. A maximum of three steps speed can be stored internally.
	Torque Mode	T	Torque control for the servo motor can be achieved via parameters set or from an external analog -10 ~ +10 Vdc command.
Multiple Mode		Pe-S	Pe and S can be switched by digital-input-contact-point.
		Pe-T	Pe and T can be switched by digital-input-contact-point.
		S-T	S and T can be switched by digital-input-contact-point.


## 1-4 Conditions for Installation of Drives

### 1-4-1 Environmental Conditions

The product should be kept in the shipping carton before installation. In order to retain the warranty coverage, the AC drive should be stored properly when it is not to be used for an extended period of time. Some storage suggestions are:

- Ambient Temperature: 0 ~ + 55 °C; Ambient Humidity: Under 85% RH (Under the condition of no frost).
- Stored Temperature: - 20 ~ + 85 °C; Stored Humidity: Under 85%RH (Under the condition of no frost).
- Vibrating: Under 0.5 G.
- Do not mount the servo drive or motor in a location where temperatures and humidity will exceed specification.
- To avoid the insolation.
- To avoid the erosion of grease and salt.
- To avoid the corrosive gases and liquids.
- To avoid the invading of airborne dust or metallic particles.
- When over 1 Drives are installed in control panel, enough space have to be kept to get enough air to prevent the heat; the fan also must be installed, to keep the ambient temperature under 55 °C .
- Please Install the drive in a vertical position, face to the front, in order to prevent the heat.
- To avoid the metal parts or other unnecessary things falling into the drive when installing.
- The drive must be stable by M5 screws.
- When there were the vibrating items nearby, please using vibration-absorber or installing anti-vibration- rubber, if the vibration can not be avoided.
- When there is any big-size magnetic switch, welding machines or other source of interference. Please install the filter. When the filter is installed, we must install the insulation transformer.

### 1-4-2 Direction and Distance




## 1-5 Conditions for Installation of Servo Motors

### 1-5-1 Environmental Conditions

- Ambient Temperature: 0 ~ + 40 °C; Ambient humidity: Under 90% RH (No Frost).
- Storage Temperature: - 20 ~ + 60 °C; Storage temperature: Under 90%RH (No Frost).
- Vibration: Under 2.5 G.
- In a well-ventilated and low humidity and dust location.
- Do not store in a place subjected to corrosive gases, liquids, or airborne dust or metallic particles.
- Do not mount the servo motor in a location where temperatures and humidity will exceed specification.
- Do not mount the motor in a location where it will be subjected to high levels of electromagnetic radiation.

### 1-5-2 Method of Installation


1. Horizontal Install: Please let the cable-cavity downside to prevent the water or oil or other liquid flow into the servo motor.




2. Vertical Install: If the motor shaft is side-up installed and [mounted to a gear box](#), please pay attention to and avoid the [oil leakage from the gear box](#).

### 1-5-3 Notice for install motor

1. Please using oil-seal-motor to avoid the oil from reduction gear flowing into the motor through the motor shaft.
2. The cable need to be kept dry.
3. Please fixing the wiring cable certainly, to avoid the cable ablating or breaking.
4. The extending length of the shaft shall be enough, otherwise there will be the vibration from motor operating.




5. Please do not beat the motor when installing or taking it apart. Otherwise the shaft and the encoder of backside will be damaged.



# Chapter 2 Wiring

## 2-1 Basic Wiring for Servo System

### 2-1-1 Wiring for Main Circuit and Peripheral Devices



## 2-1-2 Wiring for Servo Drives

- The wire material must go by “Wiring Specifications.”
- Wiring Length: Command Input Wire: Less than 3m.  
Encoder Input Wire: Less than 20m.  
The Wiring goes by the shortest length.
- Please wire according to the standard wiring schema. Don't connect if no using.
- Motor output terminal (U,V,W) must be connected correctly. Otherwise the servo motor will abnormally function.
- Shielded cable must be connected to FG terminal.
- Don't install the capacitor or Noise Filter at the output terminal of servo drive.
- At the control-output-signal relay, the direction of surge absorb diode must be correctly connected, otherwise it can not output signal, and cause the protect loop of emergency-stop abnormal.
- Please do these below to avoid the wrong operation from noise:
  - Please install devices such as the insulated transformer and noise filter at the input power.
  - Keep more than 30 cm between Power wire (power cable or motor cable...etc.) and signal cable, do not install them in the same conduit.
- Please set “emergency-stop switch” to prevent abnormal operation.
- After wiring, check the connection-situation of each joint (ex: loose soldering, soldering point short, terminal order incorrect...etc.). Tighten the joints to confirm if surly connected to the servo drive, if the screw is tight. There can not be the situations such as cable break, cable pulled and dragged, or be heavily pressed.
  - \* Especially pay attention to the polarity between servo motor wiring and encoder.
- There is no necessary to add extra regeneration resistance under general situation. If there is any need or problem, please connect to distributor or manufacturer.



## 2-1-3 Specifications of Wiring

Connection Terminal			Servo Drives and Wire Specifications				
Connection Terminal	Mark (Sign)	Name of Connect Terminal	JSDA-15	JSDA-20	JSDA-30	JSDA-50	JSDA-75
TB Terminal	R, S, T	Main Power Terminal	2.0mm <sup>2</sup> A.W.G.14	2.0mm <sup>2</sup> A.W.G.14	2.0mm <sup>2</sup> A.W.G.14	2.0mm <sup>2</sup> A.W.G.14	3.5mm <sup>2</sup> A.W.G.12
	U, V, W	Motor Terminal	2.0mm <sup>2</sup> A.W.G.14	2.0mm <sup>2</sup> A.W.G.14	2.0mm <sup>2</sup> A.W.G.14	2.0mm <sup>2</sup> A.W.G.14	3.5mm <sup>2</sup> A.W.G.12
	r, s	Power-Control Terminal	1.25mm <sup>2</sup> A.W.G.16	1.25mm <sup>2</sup> A.W.G.16	1.25mm <sup>2</sup> A.W.G.16	1.25mm <sup>2</sup> A.W.G.16	1.25mm <sup>2</sup> A.W.G.16
	1 FG $\perp$	Ground	2.0mm <sup>2</sup> A.W.G.14	2.0mm <sup>2</sup> A.W.G.14	2.0mm <sup>2</sup> A.W.G.14	2.0mm <sup>2</sup> A.W.G.14	3.5mm <sup>2</sup> A.W.G.12
Connect Terminal	Connect Point No.	Connect Point Name	JSDA-15	JSDA-20	JSDA-30	JSDA-50	JSDA-75
CN1 Joint Control Signal	26,27,28	Speed / Torque Command Input	0.2mm <sup>2</sup> or 0.3mm <sup>2</sup> -> Twisted-pair-cable connecting to the Analog Grounding wire (including shield cable)				
	30,31	Analog Monitor Output 1 & 2					
	33,34	Power Output +15V & -15V					
	29,32,44	Analog Ground Terminal	0.2mm <sup>2</sup> or 0.3mm <sup>2</sup> -> Twisted-pair-cable connecting to the I/O Grounding wire (including shield cable)				
	1~13	General Analog Input					
	18~25,43	General Analog Output					
	45,46, 48,49	24V Power & I/O Ground	0.2mm <sup>2</sup> or 0.3mm <sup>2</sup> -> Twisted-pair-cable (including shield cable)				
	14~17	Position Command Input					
35~40	Encoder Signal Output	0.2mm <sup>2</sup> or 0.3mm <sup>2</sup> -> Twisted-pair-cable (including shield cable)					
CN2 Joint of motor encoder	1,2						Output 5V
	3,4						Output Grounding wire of power supply
	5~18	Encoder Signal Input					
RS232 Joint of Communication	2,3	Data transfer & receive	0.2mm <sup>2</sup> or 0.3mm <sup>2</sup> -> Twisted-pair-cable (including shield cable)				
	5	Communication grounding wire					
	1,4,6,8	Floating	—				

**P.S.:** 1. Please pay attention to the NFB and the capacity of noise filter when using multi ServoDrives.

2. CN1 ->50 Pins (3M Co.)

3. CN2 -> 20 Pins (3M Co.)


4. RS232 -> 9 Pins D-type Joint.

## 2-1-4 Motor Terminal Layout

### A Table of Motor-Terminal Wiring


(1) General Joint:

Terminal Symbol	Color	Signal
1	Red	U
2	White	V
3	Black	W
4	Green	FG
Brake control wire	Fine red	DC +24V
	Fine yellow	0V




(2) Military Specifications Joint (No Brake):

Terminal	Color	Signal
A	Red	U
B	White	V
C	Black	W
D	Green	FG



(3) Military Specifications Joint (Brake):

Terminal	Color	Signal
B	Red	U
G	White	V
E	Black	W
C	Green	FG
A	Fine red	BK control wire
F	Fine yellow	
		DC +24V
		0V




**P.S.: The military joint with BK of servo motor has 9 Pins; and the encoder joint has also 9 Pins. Please confirm before wiring.**

## Table of Motor-Encoder Wiring

(1) General Joint:


Terminal Symbol	Color	Signal
1	White	+5V
2	Black	0V
3	Green	A
4	Blue	/A
5	Red	B
6	Purple	/B
7	Yellow	Z
8	Orange	/Z
9	Shield	FG



The diagram shows a 9-pin D-sub connector with terminals numbered 1 through 9. Terminal 1 is at the top left, 2 is at the top center, and 3 is at the top right. Terminal 4 is in the middle left, 5 is in the middle center, and 6 is in the middle right. Terminal 7 is at the bottom left, 8 is at the bottom center, and 9 is at the bottom right.

(2) Military Specifications Joint


Terminal Symbol	Color	Signal
B	White	+5V
I	Black	0V
A	Green	A
C	Blue	/A
H	Red	B
D	Purple	/B
G	Yellow	Z
E	Orange	/Z
F	Shield	FG




The diagram shows a circular connector with terminals labeled A through I. Terminal A is at the top right, B is at the middle right, C is at the bottom right, D is at the bottom center, E is at the bottom left, F is at the middle left, G is at the top left, H is at the top center, and I is at the top center.

## 2-1-5 Typical Wiring for Motor and Main Circuit

\* The Wiring Example of Single Phase Main Power (Less than 1KW)



\* The Wiring Example of 3 Phase Main Power (More than 1KW)





## 2-1-6 TB Terminal

Name	Terminal Sign	Detail
Control circuit power input terminal	r	Connecting to external AC Power. Single Phase 200~230VAC +10 ~ -15% 50/60Hz ±5%
	s	
Main circuit power input terminal	R	Connecting to external AC Power. Single / 3 Phase 200~230VAC +10 ~ -15% 50/60Hz ±5%
	S	
	T	
External regeneration resistance terminal	P	Please refer to <b>Cn012</b> to see resistance value, when using external regeneration resistance. After installing regeneration resistance, set the resistance power in <b>Cn012</b> . <b>*If no using external regeneration resistance, PC-P1 need be close, P doesn't be connected.</b>
Regeneration terminal common point	PC	
Internal regeneration resistance terminal	P1	<b>*When using external regeneration, equip regeneration resistance between PC-P, do not connect P1 terminal.</b>
Motor-power output terminal	U	Motor terminal wire is <b>red</b>
	V	Motor terminal wire is <b>white</b>
	W	Motor terminal wire is <b>black</b>
Motor-case grounding terminal	FG	Motor terminal wire is <b>green or yellow-green</b> .

## 2-1-7 Wiring for Mechanical Brake


Uninstall BRAKE:

- 200/300/400/750W series: Use Red wire and yellow wire connecting to DC +24V voltage(**No polarity**)
- 550/1K/1.5K/2K/3KW series: BK outputs from A & C of **Motor Power Joint**, servo motor can operate normally after uninstalling.



## 2-2 I/O Terminal

There are 3 groups of I/O terminal, which contain RS232 communication terminal, CN1 control signal terminal and CN2 encoder terminal. The diagram below displays all positions for the terminal.



## 2-2-1 Output Signals from the Servopack

(1) Diagram of CN1 Terminal:

Position Number	Name	Function									
			1	DI-1	SON ON				26	SIN	Speed/Torque Analog Command Input
2	DI-2	ALRS				27	PIC	Torque Control Speed Limit/CCW Command Limit			
			3	DI-3	PCNT PI/P Switch				28	NIC	CW Torque Command Limit
4	DI-4	CCWL				29	AG	Analog Signal Ground Terminal			
			5	DI-5	CWL				30	MON1	Analog Monitor Output 1
6	DI-6	TLMT				31	MON2	Analog Monitor Output 2			
			7	DI-7	CLR				32	AG	Analog Signal Ground Terminal
8	DI-8	LOK				33	+15V	+15V PW output			
			9	DI-9	EMC				34	-15V	-15V PW Output
10	DI-10	SPDI				35	PA	Encoder output A Phase			
			11	DI-11	SPD2				36	/PA	Encoder Output / A Phase
12	DI-12	MDC				37	PB	Encoder output B Phase			
			13	DI-13	SPDINV				38	/PB	Encoder Output / B Phase
14	Pulse	Position Pulse Command Input(+)				39	PZ	Encoder output Z Phase			
			15	/Pulse	Position Pulse Command Input(-)				40	/PZ	Encoder Output / Z Phase
16	Sign	Position Symbol Command Input(+)				41	OPC	Open Collector Position Command PW Input			
			17	/Sign	Position Symbol Command Input(-)				42	—	—
18	DO-1	RDY Servo Ready				43	ZO	Home Signal Output			
			19	DO-2	ALM				44	AG	Analog Signal Ground Terminal
20	DO-3	Zero Speed				45	IP24	+24V PW Output			
			21	DO-4	INP				46	IG24	+24V PW Ground Terminal
22	DO-5	Torque Limit(LM)/ALRS Code0(A0)				47	DICOM	DI PW Command Point			
			23	DO-6	PC / (A1)				48	IG24	+24V PW Ground Terminal
24	DO-7	Drive Limit(ST)/ALRS Code2(A2)				49	IG24	+24 PW ground terminal			
			25	DO-8	BASE BLOCK/ (A3)				50	FG	Shielded Wire Grounding

**P.S.:**

1. If there is unused terminal, please do not connect it or let it be the relay terminal.
2. The Shielded Wire of I/O cable should connect to the ground.



**(2) CN1 Signal Name and Explanation:**

**(a) General I/O Signal:**

**Explanation of General I/O Signal Function**

Signal	Function Symbol	Pin No.	Wired Mode	Signal	Function Symbol	Pin No.	Wired Mode
Position Pulse Command Input	<b>Pulse</b>	14	IO3	Encoder Output A-Phase	<b>PA</b>	35	IO4
	<b>/Pulse</b>	15		Encoder Output / A Phase	<b>/PA</b>	36	
Position Symbol Command Input	<b>Sign</b>	16		Encoder Output B-Phase	<b>PB</b>	37	
	<b>/Sign</b>	17		Encoder Output /B-Phase	<b>/PB</b>	38	
Open Collector Position Command Power Input.	<b>OPC</b>	41	IO3	Encoder Output Z-Phase	<b>PZ</b>	39	
				/Z-Phase	<b>/PZ</b>	40	
Speed / Torque Analog Command Input	<b>SIN</b>	26	IO5	Analog Signal Ground Terminal	<b>AG</b>	29,32,44	
				+15Vdc Output Terminal	<b>+15V</b>	33	
Torque Control Speed Limit Command / CCW Torque Command Limit	<b>PIC</b>	27		-15Vdc Output Terminal	<b>-15V</b>	34	
				Digital input Com Terminal	<b>DICOM</b>	47	
CW Torque Command Limit	<b>NIC</b>	28					
Analog Monitor Output 1	<b>MON1</b>	30	IO6	+24Vdc Output	<b>IP24</b>	45	
Analog Monitor Output 2	<b>MON2</b>	31		+24Vdc Com Terminal	<b>IG24</b>	46,48,49	
Home Signal Output	<b>ZO</b>	43	IO2	Shielded Wire Connect Point	<b>FG</b>	50	

## Explanation of General I/O Signal Function

Signal Name	Function Symbol	Mode	I/O Operation and Function	Chapter
Position Pulse Command Input	Pulse	Pe	The Driver can receive 3 kinds of Command below: . (Pulse)+ (Sign) . (CCW)/ (CW)Pulse . AB Phase pulse	5-4-1
	/Pulse			
Position Sign Command Input	Sign			
	/Sign			
Open Collect Position Command PW Input	OPC	Pe	When open collect input in position command, <b>OPC</b> and <b>IP24</b> can be close, and using internal <b>24V</b> power and resistor.	—
Speed Analog command Input	SIN	S	In Speed Mode, when external speed command is operated at SPD1=0, SPD2=0, input the voltage range: <b>-10V~+10V</b> , <b>Sn216</b> can be set input voltage: $\pm 10V$ 's Motor output speed.	5-3-1 5-3-2 5-3-3 5-3-4
Torque Analog Command Input		T	In Torque Mode, input the voltage range <b>-10~+10V</b> , <b>Tn103</b> can be set input voltage $\pm 10V$ 's motor output torque.	5-2-1 5-2-2
Torque Control Speed Limit Command	PIC	T	In Torque Mode, when external speed limit is operated at input connect point <b>SPD1=0 &amp; SDP2=0(P.S)</b> , input voltage range: <b>0~+10V</b> , 10V's speed limit stands for motor's ratio speed.	5-2-6
CCW Torque Limit Command		S	In Speed Mode, when external torque limit is be used at input connect point <b>TLMT=1(P.S.)</b> , input voltage range: <b>0~+10V</b> , to input 10V will limit the motor CCW torque having 300% of ratio torque.	5-3-10
CW Torque Limit Command	NIC	S	In Speed Mode, when external torque limit is be used at input connect point <b>TLMT=1(P.S.)</b> , input voltage range: <b>-10~0V</b> , to input -10V will limit the motor CW torque have 300% of ratio torque.	5-3-10
Analog Monitor Output 1	MON1	ALL	Operating the motor to control the current speed to transform the voltage output in accordance with the rate ( $\pm 10V/1.5$ times ratio speed) CCW stands for positive voltage, CW negative voltage.	5-6-9
Analog Monitor Output 2	MON2	ALL	Operating the motor to control the current torque to transform the voltage output in accordance with the rate ( $\pm 10V/3.5$ times ratio torque) CCW torque stands for positive voltage, CW negative voltage.	5-6-9
Encoder Output A Phase	PA	ALL	Outputting the Motor Encoder Signal through pulse per rotation handle. The pulse quantity of every rotating can be set in <b>Cn005</b> . When "1" is set in <b>Cn004</b> , it is CCW rotation from the motor load terminal direction, and A Phase gets 90 degree ahead B Phase. Signal Output is Line Driver.	5-3-5
Encoder Output / A Phase	/PA			
Encoder Output B Phase	PB			
Encoder Output / B Phase	/PB			
Encoder Output Z Phase	PZ			
Encoder Output / Z Phase	/PZ			
Home Signal Output	ZO	ALL	Z Phase Open Collector output connect point.	—
Analog Signal Ground Terminal	AG	ALL	Analog signal grounding: <b>CN1 - &gt; Pin 26、27、28、30、31、33、34.</b>	—
+15V PW Output Terminal	+15V	ALL	To provide $\pm 15V$ output power (Max. 10mA), which can be used in servo drive – external voltage command. <b>Suggestion: Using the variable resistance which is more than 3k<math>\Omega</math>.</b>	—
-15V PW Output Terminal	-15V	ALL		
DI PW Conmen	DICOM	ALL	Digital input power supplement common terminal.	—

Signal Name	Function Symbol	Mode	I/O Operation and Function	Chapter
Terminal				
+24V PW Output	<b>IP24</b>	ALL	+24V power output terminal(Max. 0.2A).	—
+24V PW Ground Terminal	<b>IG24</b>	ALL	+24V power grounding terminal	—
Shielded Wire Connect Point	<b>FG</b>	ALL	Connect to Shield wire of signal cable.	—

**P.S.:** “1” stands for “close loop with **IG24**”; “0” stands for “open loop with **IG24**”.  
PW is abbreviation of Power

## (b) Digital I/O Signal:

For many kinds of application, the digital input/output terminal layout of all operation mode are accordingly different. In order to provide more functions, our drives can provide multi terminal layout settings. Users can set these functions for application.

Digital input terminal layout provides 13 (**Pin1~13**) programmable terminal; digital output terminal provides 4 (**Pin18~21**) programmable terminals. The diagram below shows the default digital input/output terminal placement and functions. Please refer to 5-6-1 to check related parameters setting.

### Default Digital Input Terminal placement Functions and Wired Mode

Signal		Function Sign	Pin No.	Wired Mode	Signal		Function Sign	Pin No.	Wired Mode
Servo ON	DI-1	<b>SON</b>	1	IO1	Servo Lock	DI-8	<b>LOK</b>	8	IO1
Alarm reset	DI-2	<b>ALRS</b>	2		Emergency Stop	DI-9	<b>EMC</b>	9	
PI/P Switch	DI-3	<b>PCNT</b>	3		Internal speed command / Limit select 1	DI-10	<b>SPD1</b>	10	
CCW Operation Limit	DI-4	<b>CCWL</b>	4		Internal speed command / Limit select 2	DI-11	<b>SPD2</b>	11	
CW Operation Limit	DI-5	<b>CWL</b>	5		Control Mode Switch	DI-12	<b>MDC</b>	12	
External Torque Limit	DI-6	<b>TLMT</b>	6		Reverse Direction Speed Command	DI-13	<b>SPDINV</b>	13	
Pulse error amount delete	DI-7	<b>CLR</b>	7		—				

### Default Digital Input Terminal Layout Functions and Wired Mode

Signal		Function Sign	Pin No.	Wired Mode	Signal		Function Sign	Pin No.	Wired Mode
Servo ready	DO-1	<b>RDY</b>	18	IO2	Torque limit/ Alarm code A0	DO-5	<b>LM/A0</b>	22	IO2
Alarm	DO-2	<b>ALM</b>	19		P action / Alarm code A1	DO-6	<b>PC/A1</b>	23	
Zero speed	DO-3	<b>ZS</b>	20		Operation limit/ Alarm code A2	DO-7	<b>ST/A2</b>	24	
Fix position	DO-4	<b>INP</b>	21		Base Block/ Alarm code A3	DO-8	<b>BB/A3</b>	25	

## Digital Input Function

(Except CCWL and CWL are high electric potential, other terminal layout are low electric potential. Please refer to 5-6-1 to see related parameters)

Signal Name	Function Sign	Mode	I/O Function	Chapter																				
Servo On	<b>SON</b>	ALL	<b>SON</b> and <b>IG24</b> close loop: Servo <b>ON</b> ; <b>SON</b> and <b>IG24</b> open loop: Servo OFF. Attention: Before power on, the input connect point <b>SON</b> (servo on) can not be operated to avoid danger.	5-6-3 5-6-4																				
Abnormal Reset	<b>ALRS</b>	ALL	<b>ALRS</b> and <b>IG24</b> close loop: Relieving the stop-situation from of abnormality. <b>But the abnormality of encoder or memory will cause the same alarm again. Please reset power after the abnormality is eliminated.</b>	8-1																				
PI/P switch	<b>PCNT</b>	Pi/Pe/S	<b>PCNT</b> and <b>IG24</b> close loop will cause the speed loop control transforming to ratio control from ratio integration control.	5-3-11																				
CCW Operation limit	<b>CCWL</b>	ALL	Connect to <b>CCW</b> over travel detector: <b>CCWL</b> and <b>IG24</b> close loop; open loop with <b>IG24</b> -> <b>CCW</b> over travel operates.	5-4-8 5-6-3 5-6-4																				
CW Operation limit	<b>CWL</b>	ALL	Connect to <b>CW</b> over travel detector: <b>CWL</b> and <b>IG24</b> close loop; open loop with <b>IG24</b> -> <b>CW</b> over travel operates.	5-4-8 5-6-3 5-6-4																				
External torque limit	<b>TLMT</b>	Pi/Pe/S	<b>TLMT</b> and <b>IG24</b> close loop will cause the motor-output-torque-limit to stay in the command-voltage range of torque-limit-terminal-layout ( <b>PIC</b> 、 <b>NIC</b> ).	5-3-10																				
Pulse error amount delete	<b>CLR</b>	Pi/Pe	When <b>CLR</b> and <b>IG24</b> close loop, delete the pulse amount in the Position Error Counter.	5-4-7																				
Servo lock	<b>LOK</b>	S	When <b>LOK</b> and <b>IG24</b> close loop will transform speed control mode into position control mode in order to lock the motor at the last position.	5-3-12																				
Emergency stop	<b>EMC</b>	ALL	When <b>EMC</b> and <b>IG24</b> close loop: Emergency stop -> Servo Off and exit the rotating statue, and Cn008 will decide if the dynamic Brake operates.	5-6-4																				
Internal speed command / limit select 1 Internal speed command / limit select 2	<b>SPD1</b> <b>SPD2</b>	S/T	<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>SPD2</th> <th>SPD1</th> <th>Speed Command (Speed Mode)</th> <th>Speed Limit Command (Torque Mode)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>External command(SIN)</td> <td>External limit(PIC)</td> </tr> <tr> <td>0</td> <td>1</td> <td>Sn201</td> <td>Tn105</td> </tr> <tr> <td>1</td> <td>0</td> <td>Sn202</td> <td>Tn106</td> </tr> <tr> <td>1</td> <td>1</td> <td>Sn203</td> <td>Tn107</td> </tr> </tbody> </table> <p>Internal speed setting and limit:                      "1": Close loop with <b>IG24</b>                      "0": Open loop with <b>IG24</b></p>	SPD2	SPD1	Speed Command (Speed Mode)	Speed Limit Command (Torque Mode)	0	0	External command(SIN)	External limit(PIC)	0	1	Sn201	Tn105	1	0	Sn202	Tn106	1	1	Sn203	Tn107	5-2-6 5-3-1
SPD2	SPD1	Speed Command (Speed Mode)	Speed Limit Command (Torque Mode)																					
0	0	External command(SIN)	External limit(PIC)																					
0	1	Sn201	Tn105																					
1	0	Sn202	Tn106																					
1	1	Sn203	Tn107																					

## Digital Input Function Explanation

(Except CCWL and CWL are the high electric potential, other terminal layout are the low electric potential, please refer to 5-6-1 to check related parameters setting)

Signal Name	Function Symbol	Mode	I/O Function	Chapter															
Control Mode Switch	<b>MDC</b>	Pe/S/T	When <b>MDC</b> and <b>IG24</b> close loop, current control mode will transform into default control mode, please refer to <b>Cn001</b> .	5-1 5-6-2															
Position Command Limit	<b>INH</b>	Pe	When <b>INH</b> and <b>IG24</b> close loop, position command input does not operate (do not accept external pulse command).	5-4-1															
Speed Command Counter Wise	<b>SPDINV</b>	S	When <b>SPDINV</b> and <b>IG24</b> close loop in speed mode, setting rotating speed will become counter-wise rotating speed.	5-3-7															
Gain Select	<b>G-SEL</b>	Pi/Pe/S	When <b>G-SEL</b> and <b>IG24</b> close loop, first stage control gain switch to the second control gain.	5-3-11															
Electric Gear ratio Numerator 1~2	<b>GN1</b> <b>GN2</b>	Pi/Pe	<p>Electric gear ratio: select explanation:</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>GN2</th> <th>GN1</th> <th>Electric Gear ratio Numerator</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Pn302</td> </tr> <tr> <td>0</td> <td>1</td> <td>Pn303</td> </tr> <tr> <td>1</td> <td>0</td> <td>Pn304</td> </tr> <tr> <td>1</td> <td>1</td> <td>Pn305</td> </tr> </tbody> </table> <p>“1”: Close loop with <b>IG24</b> “0”: Open loop with <b>IG24</b></p>	GN2	GN1	Electric Gear ratio Numerator	0	0	Pn302	0	1	Pn303	1	0	Pn304	1	1	Pn305	5-4-3
GN2	GN1	Electric Gear ratio Numerator																	
0	0	Pn302																	
0	1	Pn303																	
1	0	Pn304																	
1	1	Pn305																	
Internal Position Command Trigger	<b>PTRG</b>	Pi	When <b>PTRG</b> and <b>IG24</b> close loop (positively-triggered), the motor will select related position command to operate in accordance with the terminal layout <b>POS1~POS4</b> .	5-4-8															
Internal Position Command Hold	<b>PHOLD</b>	Pi	When <b>PHOLD</b> and <b>IG24</b> close loop(positively-triggered), the motor will stay holding.	5-4-8															
Home	<b>SHOME</b>	Pi/Pe	When <b>SHOME</b> and <b>IG24</b> close loop(positively-triggered), HOME function operates	5-4-8															
External Origin	<b>ORG</b>	Pi	When <b>ORG</b> and <b>IG24</b> close loop(positively-triggered), server will use this as external reference point for home position returning.	5-4-8															

## Digital Input Function Explanation

(Except CCWL and CWL are the high electric potential, other terminal layout are the low electric potential, please refer to 5-6-1 to check related parameters setting)

Signal Name	Function Symbol	Mode	I/O Function	Chapter																																																																																					
Internal Position Command select 1~4	POS1 POS2 POS3 POS4	Pi	<b>Internal position command select :</b> <table border="1"> <thead> <tr> <th>POS1</th> <th>POS2</th> <th>POS3</th> <th>POS4</th> <th>Internal Position Command select</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>0</td><td>0</td><td>Pn317, Pn318</td></tr> <tr><td>0</td><td>0</td><td>0</td><td>1</td><td>Pn320, Pn321</td></tr> <tr><td>0</td><td>0</td><td>1</td><td>0</td><td>Pn323, Pn324</td></tr> <tr><td>0</td><td>0</td><td>1</td><td>1</td><td>Pn326, Pn327</td></tr> <tr><td>0</td><td>1</td><td>0</td><td>0</td><td>Pn329, Pn330</td></tr> <tr><td>0</td><td>1</td><td>0</td><td>1</td><td>Pn332, Pn333</td></tr> <tr><td>0</td><td>1</td><td>1</td><td>0</td><td>Pn335, Pn336</td></tr> <tr><td>0</td><td>1</td><td>1</td><td>1</td><td>Pn338, Pn339</td></tr> <tr><td>1</td><td>0</td><td>0</td><td>0</td><td>Pn341, Pn342</td></tr> <tr><td>1</td><td>0</td><td>0</td><td>1</td><td>Pn344, Pn345</td></tr> <tr><td>1</td><td>0</td><td>1</td><td>0</td><td>Pn347, Pn348</td></tr> <tr><td>1</td><td>0</td><td>1</td><td>1</td><td>Pn350, Pn351</td></tr> <tr><td>1</td><td>1</td><td>0</td><td>0</td><td>Pn353, Pn354</td></tr> <tr><td>1</td><td>1</td><td>0</td><td>1</td><td>Pn356, Pn357</td></tr> <tr><td>1</td><td>1</td><td>1</td><td>0</td><td>Pn359, Pn360</td></tr> <tr><td>1</td><td>1</td><td>1</td><td>1</td><td>Pn362, Pn363</td></tr> </tbody> </table>	POS1	POS2	POS3	POS4	Internal Position Command select	0	0	0	0	Pn317, Pn318	0	0	0	1	Pn320, Pn321	0	0	1	0	Pn323, Pn324	0	0	1	1	Pn326, Pn327	0	1	0	0	Pn329, Pn330	0	1	0	1	Pn332, Pn333	0	1	1	0	Pn335, Pn336	0	1	1	1	Pn338, Pn339	1	0	0	0	Pn341, Pn342	1	0	0	1	Pn344, Pn345	1	0	1	0	Pn347, Pn348	1	0	1	1	Pn350, Pn351	1	1	0	0	Pn353, Pn354	1	1	0	1	Pn356, Pn357	1	1	1	0	Pn359, Pn360	1	1	1	1	Pn362, Pn363	5-4-2
			POS1	POS2	POS3	POS4	Internal Position Command select																																																																																		
			0	0	0	0	Pn317, Pn318																																																																																		
			0	0	0	1	Pn320, Pn321																																																																																		
			0	0	1	0	Pn323, Pn324																																																																																		
			0	0	1	1	Pn326, Pn327																																																																																		
			0	1	0	0	Pn329, Pn330																																																																																		
			0	1	0	1	Pn332, Pn333																																																																																		
			0	1	1	0	Pn335, Pn336																																																																																		
			0	1	1	1	Pn338, Pn339																																																																																		
			1	0	0	0	Pn341, Pn342																																																																																		
			1	0	0	1	Pn344, Pn345																																																																																		
			1	0	1	0	Pn347, Pn348																																																																																		
			1	0	1	1	Pn350, Pn351																																																																																		
			1	1	0	0	Pn353, Pn354																																																																																		
			1	1	0	1	Pn356, Pn357																																																																																		
			1	1	1	0	Pn359, Pn360																																																																																		
1	1	1	1	Pn362, Pn363																																																																																					
Internal position command select explanation: "1": close loop with <b>IG24</b> "0": open loop with <b>IG24</b>																																																																																									
Torque Command Counter Clock Wise	<b>TRQINV</b>	T	When <b>TRQINV</b> and <b>IG24</b> close loop in torque mode, setting torque command output wise becomes counter wise output.	5-2-4																																																																																					

## Digital Output Function Explanation

(The terminal layout here from this explanation are all the low electric potential, please refer to 5-6-1 to check parameter settings)

Signal Name	Function Symbol	Mode	I/O Function	Chapter
Servo Ready	<b>RDY</b>	ALL	Main power and control power input are normal. Under the situation of no alarm, terminal layouts <b>RDY</b> and <b>IG24</b> close loop.	—
Alarm	<b>ALM</b>	ALL	If normally operates, the terminal layouts <b>ALM</b> and <b>IG24</b> open loop. When alarm occurs, protection-function operates, the terminal and <b>IG24</b> close loop.	—
Zero Speed	<b>ZS</b>	S	When the motor speed is less than the speed from <b>Sn215</b> , the terminal layout <b>ZS</b> and <b>IG24</b> close loop.	5-3-12
BK Signal	<b>BI</b>	ALL	When <b>Cn008</b> is set "1" or "3" and the servo on, the terminal layout <b>BI</b> and <b>IG24</b> close loop; when servo off, terminal layout and <b>IG24</b> open loop. (When this terminal layout is generally applied, it is the Brake relay, which is connected to control motor).	5-6-4 5-6-5
In Speed	<b>INS</b>	S	When the motor speed has achieved the setting speed from <b>Cn007</b> , <b>INS</b> and <b>IG24</b> close loop.	5-3-12
In Position	<b>INP</b>	Pi/Pe	When the amount of position error counter is less than the amount range which is set in <b>Pn307</b> , <b>INP</b> and <b>IG24</b> close loop.	5-4-9
Home	<b>HOME</b>	Pi/Pe	When HOME is accomplished, <b>HOME</b> and <b>IG24</b> close.	5-4-8
Limiting Torque/ Alarm No. 0	<b>LM/A0</b>	ALL	When motor output torque is limited by internal torque limit amount ( <b>Cn010&amp;Cn011</b> ) or external torque limit command ( <b>PIC&amp;NIC</b> ). <b>LM/A0</b> and <b>IG24</b> close loop. When alarm occurs, this terminal layout is alarm code output <b>A0</b> .	8-1
P in Action / Alarm No.1	<b>PC/A1</b>	Pe/Pi/S	When speed loop is ratio(P)-control, <b>PC/A1</b> and <b>IG24</b> close loop. When alarm occurs, this terminal layout is alarm code output <b>A1</b> .	8-1
Server in Limiting/ Alarm No.2	<b>ST/A2</b>	ALL	When CCW or CW operation-limit occurs, <b>ST/A2</b> and <b>IG24</b> close loop. When alarm occurs, this terminal layout is alarm code output <b>A2</b>	8-1
Base Block/ Alarm No.3	<b>BB/A3</b>	ALL	When servo motor has not be operated, <b>BB/A3</b> and <b>IG24</b> close loop. When alarm occurs, this terminal layout is alarm code output <b>A3</b>	8-1




(3) CN1 Interface Circuit and Wire Mode:

The diagram below introduces all interface circuit of CN1 and wire-method of host controller.


(a) Digital input interface circuit (IO1):

Digital input interface circuit can be operated by relay or collector transistor circuit. The relay should be the low electric current, in order to avoid the faulty contacting. External voltage: 24V.






(b) Digital Output Interface Circuit (IO2):

When using external power, please attention to the power polarity. Adverse polarity will case circuit damage. Digital output is "Open Collector". The maximum of external voltage is 24V; and the maximum electric current is 10mA.




(c) Pulse Command Input Interface Circuit(103):

Suggesting to use the input method of Line Driver to send the pulse command. The maximum input command frequency is 500kpps. Using the input method of Open Collector will cause the decrease of input command frequency, the maximum input command frequency is 200kpps. The servo provides only 24V power, and other power should be prepared. Adverse polarity of power will cause the servo damage. The maximum of External power (Vcc) is 24V limited. Input current is about 8~15mA. Please refer to the examples below to select resistance. Please refer to 5-4-1 to check pulse input command timing.

Line Driver pulse command input	Open Collector pulse command input		
 <p>The max. frequency of line driver type pulse command is 500kpps</p>	 <p>Maximum input command frequency of open collector is 200kpps</p>		
Open Collector (Internal 24V)	Open Collector – Selection of input Resistance		
 <p>The maximum input command frequency of open collector is 200kpps</p>	<p>External Power Vcc=24V R=2KΩ</p>	<p>External Power Vcc=12V R=750Ω</p>	<p>External Power Vcc=5V R=100Ω</p>

(d) Encoder Output Interface Circuit (IO4):

Encoder output interface circuit is the output method of Line Driver, please let end terminal resistance( $R=200\sim 330\Omega$ ) connect to Line Receiver input terminal.




(e) Analog Input Interface Circuit(IO5):

There is sometimes ripple inside the servo internal power. Adverse external power polarity will cause severe damage. Maximum external power voltage ( $V_c$ ) should be less than 12V; terminal input voltage should not more than 10V. Over voltage will cause damage. When using internal power of server, user need to choose the resistance(suggestion: more than  $3K\Omega$ ), which maximum current is less than 10mA.

SIN Input impedance:  $15K\Omega$


PIC Input impedance:  $40K\Omega$

NIC Input impedance:  $20K\Omega$



(f) Analog Output Interface Circuit(106):

The maximum current of analog output is 5mA, so user need to choose the device, which Impedance is larger.



## 2-2-2 Encoder Connector (CN2) Terminal Layout

(1) Diagram of CN2 Terminal:

(a) Diagram of Fewer Wiring Type Encoder:

Pin No.	Terminal Layout	Function
1	+5V	PW Output Terminal
2	+5V	PW Output Terminal
3	0V	PW Grounding Terminal
4	0V	PW Grounding Terminal
5	A	Encoder / A Phase Input
6	/A	Encoder / A Phase Input
7	B	Encoder / B Phase Input
8	/B	Encoder / B Phase Input
9	Z	Encoder / Z Phase Input
10	/Z	Encoder / Z Phase Input
11	—	—
12	—	—
13	—	—
14	—	—
15	—	—
16	—	—
17	—	—
18	—	—
19	—	—
20	FG	Shielded Wire Grounding

(b) Diagram of non-Fewer Wiring Type Encoder:

Pin No.	Terminal Layout	Function
1	+5V	PW Output Terminal
2	+5V	PW Output Terminal
3	0V	PW Grounding Terminal
4	0V	PW Grounding Terminal
5	A	Encoder / A Phase
6	/A	Encoder / A Phase
7	B	Encoder / B Phase
8	/B	Encoder / B Phase
9	Z	Encoder / Z Phase
10	/Z	Encoder / Z Phase
11	U	Encoder / U Phase
12	/U	Encoder / U Phase
13	V	Encoder / V Phase
14	/V	Encoder / V Phase
15	W	Encoder / W Phase
16	/W	Encoder / W Phase
17	—	—
18	—	—
19	—	—
20	FG	Shielded Wire Grounding


**P.S.: Do not wire to the terminal, which is un-operated.**

(2) Name and Explanation of I/O Signal:

Pin No.	Signal Name	Code	Encoder Output No. and Color			Terminal Layout Function
			General Joint		Plug-in Joint	
			9 wires (fewer wiring)	15 wires (non-fewer wiring)	Output No.	
1 2	Power output + Terminal	+5V	white	Red	B	5V Power for encoder (provided from driver). When the cable is more than 20m, user should separately use 2 cables to avoid decreasing voltage of encoder. When the cable is more than 30m, please contact to the distributorship.
3 4	Power output - Terminal	0V	Black	Black	I	
5 6	A Phase encoder input A	A	Green	Green	A	Encoder A Phase: From motor terminal to the driver.
		/A	Blue	Green White	C	
7 8	B Phase encoder input	B	Red	Gray	H	Encoder B Phase: From motor terminal to the driver.
		/B	Pink	Gray white	D	
9 10	Z Phase encoder input	Z	Yellow	Yellow	G	Encoder Z Phase: From motor terminal to the driver.
		/Z	Orange	Yellow white	E	
11 12	U Phase encoder input	U		Brown		<b>When using fewer-wiring-type motor, do not wire.</b>
		/U		Brown white		
13 14	V Phase encoder input	V		Blue		<b>When using fewer-wiring-type motor, do not wire.</b>
		/V		Blue white		
15 16	W Phase encoder input	W		Orange		<b>When using fewer-wiring-type motor, do not wire.</b>
		/W		Orange white		
17 18 19	No operated					<b>Do not wire.</b>
20	Shielded wire terminal layout	FG	Shielded net wire		F	Shielded wire, which is connected to the signal wire.


## 2-3 Typical Circuit Wiring Examples

### 2-3-1 Position Control Mode (Pe Mode) (Line Driver)



Pe mode =External pulse positioning command


## 2-3-2 Position Control Mode (Pe Mode) (Open Collector)



Pe mode = External pulse positioning command




## 2-3-3 Position Control Mode (Pe Mode) (Pi Mode)




Pi mode = Internal position command

## 2-3-4 Speed Control Mode (S Mode)



## 2-3-5 Torque Control Mode (T Mode)



# Chapter 3 Panel Operator / Digital Operator


## 3-1 Panel Operator on the Drives







The operator keypad & display contains a 5 digit 7 segment display, 4 control keys and two status LED displays.

**Power status LED** (Green) is lit when the power is applied to the unit.

**Charge LED** (Red) Indicate the capacitor 's charge status of main circuit. power on to light up Charge LED and gradual dark when internal power capacitors are discharged complete.

Do NOT wire or assemble to the servo drive before Charge LED is off.



Key	Name	Function Keys Description
	MODE/SET	1. To select a basic mode, such as the status display mode, utility function mode, parameter setting mode, or monitor mode. 2. Returning back to parameter selection from data-setting screen.
	INCREMENT	1. Parameter Selection. 2. To increase the set value.
	DECREMENT	3. Press  and  at the same time to clear ALARM.
	DATA SETTING & DATA ENTER	1. To confirm data and parameter item. 2. To shift to the next digit on the left. 3. To enter the data setting (press 2 sec.)

After power on, MODE button can be used to select 9 groups of parameter.

By pressing the Mode key repeatedly once at a time you can scroll trough the displays below.

Step	Key	LED Display after Operation	Description
1	Power on	U <sub>n</sub> -001	Drive status parameters.
2	MODE	d <sub>n</sub> -001	Diagnostic parameters.
3	MODE	AL-000	Alarm parameters.
4	MODE	C <sub>n</sub> 001	System Control parameters.
5	MODE	T <sub>n</sub> 101	Torque Control parameters.
6	MODE	S <sub>n</sub> 201	Speed Control parameters.
7	MODE	P <sub>n</sub> 301	Position Control parameters.
8	MODE	Q <sub>n</sub> 401	Quick set up parameters.
9	MODE	H <sub>n</sub> 501	Multi function I/O (programmable Inputs/Outputs) Parameters.
10	MODE	U <sub>n</sub> -001	Return to Drive status parameters.

Once the first parameter in a parameter group is displayed use **Increment** or **Decrement** keys to select the required parameter then use **Enter** key in order to view and alter the parameter setting, once this is done then press **Enter** key again to save the change.

Notes: On each parameter display the first digit will be flashing, the enter key can be used to move between digits.

Example procedures are shown below: -

**Ex: Setting Speed Parameter Sn203 to 100rpm.**

Step	Key	LED Display after Operation	Description
1	Power On		Display status of servo drive
2			Press <b>MODE-Key</b> 6 times to select Sn 201
3			Press <b>INCRMENT- Key</b> twice Sn203 is displayed.
4			To view the Sn203 preset value by press <b>ENTER-Key</b> for 2 seconds
5			Shift to the second digit by press <b>ENTER- Key</b> once
6			Shift to next Digit by press <b>ENTER-Key</b> once again
7			Change the digit preset value by press the <b>DECREMET-Key</b> twice
8			To save the altered preset value, Press the <b>ENTER- Key</b> for 2 seconds until <b>"SET"</b> is displayed briefly and then display is returned to parameter Sn203

Following example shows the sequence where a parameter preset value is displayed

When no change is made and it is skip back to the original parameter by pressing the Mode-Key.


Step	Key	LED Display after Operation	Description
1	Power ON		When power on drive status parameter will display
2			Pressing <b>MODE-Key</b> 6 times, Sn 201 will be displayed.
3			Pressing <b>INCRMENT- Key</b> twice Sn203 is displayed.
4			To view the Sn203 preset press <b>ENTER-Key</b> for 2 seconds.
5			No change is made and LED display return to last select parameter Sn203, press <b>MODE-Key</b> once skip

Some of the data entry in this drive are in the format shown below, for these data the Most significant digit will be shown by the Capital letter "H" as shown below.

Ex: Home search function in position mode **Pn365 = 0212**. Each digit of this preset for Pn365 parameter defines a selection for a specific function.

Bit0 corresponds to a selection for parameter Pn 365.0 and bit1 setting for Pn 365.1 ... etc.

Parameter Pn 365 Format for the 5 digits data value is shown below:



### Display of Positive and Negative values:

Description of Positive/Negative Display	Display of Positive	Display of Negative
For negative numbers with 4 digits or less, the negative sign is displayed In the most significant digit as shown. Ex: <b>Sn201</b> (Internal Speed Command 1).	3000 	-3000 
For negative numbers with 5 digits the negative sign is indicated by displaying <b>all the 5 decimal points</b> on the display. Ex: <b>Pn317</b> (Internal Position Command 1- Rotation number)	30000 	-30000 

### Setting a negative value.

(1) If the negative value has 4 digits or less follow the steps in the example below:

Ex: Sn201(Internal speed command 1)= preset speed of 100 to -100 rpm.

Step	Key	LED Display after Operation	Description
1	Power ON		On" power on " <b>Drive Status</b> parameter is displayed.
2			Pressing <b>MODE-Key</b> 5 times, Sn 201 will be displayed.
3			To view the Sn201 preset press <b>ENTER-Key</b> for 2 seconds.
4			To move to the most significant digit press the <b>ENTER-Key</b> 4 times.
5	or		Use <b>INCREMENT Or DECREMENT</b> key until the minus sign ( - ) is displayed. You can toggle between - and + by this key.
6		 	To save the altered preset value, Press the <b>ENTER- Key</b> for 2 seconds until "SET" is displayed briefly and then display is returned to parameter Sn201.

If the negative value has 5 digits follow the steps in the example below:

Ex: **Pn317** (internal position preset command 1) set to a negative value -10000 revolutions.

Step	Control Keys	LED Display after Operation	Description
1	Power On		On" power on " <b>Drive Status</b> parameter is displayed.
2			Pressing <b>MODE-Key</b> 6 times, position parameter Pn 301 will be displayed.
3			Use <b>INCREMENT- Key</b> to display Pn317.
4			To view the Pn317 preset press <b>ENTER-Key</b> for 2 seconds.
5			To move to the most significant digit press the <b>ENTER-Key</b> 4 times.
6			Press <b>DECREMENT-Key</b> once to set the most significant digit To 1. And press the <b>DECREMENT-Key</b> once again. All 5 decimal points will light up to indicate a negative number.
7			To save the altered preset value, Press the <b>ENTER- Key</b> for 2 seconds until " <b>SET</b> "is displayed briefly and then display is returned to parameter Pn 317.

#### Alarm Reset from the Keypad.

All alarm displays can be cleared from the keypad without a need for an external Alarm clear (Reset) signal.

Ex. Under voltage Alarm AL-01.

Step	Control Key	LED Display after Opertion	Description
1	Alarm		Under voltage Alarm AL-01 is displayed.
2	 		To clear Alarm:- Remove input contact <b>SON</b> (Servo On). Then press <b>INCREMENT-Key</b> and <b>DECREMENT-Key</b> at the same time. The display will show <b>RESET</b> briefly and then returns back to parameter display.



## 3-2 Signal Display

### 3-2-1 Status Display

Following parameters can be used to display drive and motor Status.

Parameter Signal	Displayed	Unit	Description
Un-01	Actual motor speed	rpm	Actual Motor Speed is displayed in rpm.
Un-02	Actual motor torque	%	It displays the torque as a percentage of the rated torque. Ex: 20 are displayed. It means that the motor torque output is 20% of rated torque.
Un-03	Regenerative load ratio	%	Value for the processable regenerative power as 100% .
Un-04	Accumulated load ratio	%	Value for the rated torque as 100%.
Un-05	Max load rate	%	Max value appeared on accumulated load rate
Un-06	Speed command	rpm	Speed command is displayed in rpm.
Un-07	Position error counter value	pulse	Error between position command value and the actual position feedback.
Un-08	Position feedback pulse counter	pulse	The accumulated number of pulses from the motor encoder.
Un-09	External voltage command	V	External analog voltage command value in volts.
Un-10	Main circuit Vdc Bus Voltage	V	DC Bus voltage in Volts.
Un-11	External speed limit command value	rpm	Display external speed limit command value in rpm.
Un-12	External CCW Torque limit command value	%	Ex: Display 100. Means current external CCW torque limit command is set to 100 %.
Un-13	External CW Torque limit command value	%	Ex: Display 100. Means current external CW torque limit command is set to 100%.
Un-14	Motor feed back – Rotation value (absolute value)	rev	After power on, it displays motor rotation number as an absolute value.
Un-15	Motor feed back – Less than 1 rotation pulse value(absolute value)	pulse	After power on, it displays the pulse number for less than a revolution of the motor as an absolute value.
Un-16	Pulse command – rotation value(absolute value)	rev	After power on, it displays pulse command input rotation number in absolute value.
Un-17	Pulse command – Less than 1 rotation pulse value(absolute value)	pulse	After power on, it displays pulse command input for less than a rotation. pulse value is an absolute value.
Un-18	Torque command	%	It displays the torque command as a percentage of the rated torque. Ex: Display. 50.Means current motor torque command is 50% of rated torque.
Un-19	Load inertia	x0.1	When <b>Cn002.2=0</b> (Auto gain adjust disabled), it displays the current preset load inertia ratio from parameter <b>Cn025</b> . When <b>Cn002.2=1</b> (Auto gain adjust enabled), it displays the current estimated load inertia ratio.

### 3-2-2 Diagnostic function

Following diagnostics parameters are available:

Parameter Signal	Name and Function
dn-01	Control mode display
dn-02	Output terminal status
dn-03	Input terminal status
dn-04	Software version (CPU version)
dn-05	JOG mode operation
dn-06	Reserve function
dn-07	Auto offset adjustment of external analog command voltage
dn-08	Servo model code
dn-09	ASIC software version display

#### dn-01 (Control Mode Display)

Access **dn-01** to display the selected control mode.


Control mode display description is listed in the table below:

Control Mode	dn-01 (Control mode display)
Torque control - T	□□□□T
Speed control - S	□□□□S
Position control (External pulse command) - Pe	□□□PE
Position/Speed control switch - Pe/S	□PE-S
Speed/Torque control switch - S/T	□□S-T
Position/Torque control switch - Pe/T	□PE-T
Position control (Internal position command) - Pi	□□□PI

## dn-02 (Output terminal status)

Use dn-02 to check the status of output terminals.

Output status display is described below:



When output terminal signal has a low logic level (**close** loop with **IG24**), the corresponding LED will be on.

When output terminal signal has a high logic level (**open** loop with **IG24**), the corresponding LED will be off.

Table below shows the functions of the digital outputs.

**DO-1~DO-4** are programmable outputs. Default settings are shown below.

**DO-5~DO-8** are fix function outputs. ( non-programmable)

For programmable output list see section 5-6-1.

LED No.	Output terminal number	Default function
1	DO-1	RDY
2	DO-2	ALM
3	DO-3	ZS
4	DO-4	INP
5	DO-5	LM/A0
6	DO-6	PC/A1
7	DO-7	ST/A2
8	DO-8	BB/A3


**Note:** To set the logic state (High or Low) of for programmable digital outputs refer to section 5-6-1.

For the DO-5~DO-8 ( non-programmable) terminals are active when logic is low.

**dn-03 (Input terminals status)**

Use dn-03 to check the status of Input terminals.

Digital Input status display is described below:



When Input terminal signal has a low logic level (close loop with **IG24**), the corresponding LED will be on.

When Input terminal signal has a high logic level (open loop with **IG24**), the corresponding LED will be off.

Table below shows the functions of the digital input.

**DI-1 ~ DI -10** are programmable Inputs. Default settings are shown below.










For programmable function list see section 5-6-1.

LED Number	Input terminal number	Default function
1	DI-1	SON
2	DI -2	ALRS
3	DI -3	PCNT
4	DI -4	CCWL
5	DI -5	CWL
6	DI -6	TLMT
7	DI -7	CLR
8	DI -8	LOK
9	DI -9	EMC
10	DI -10	SPD1

### dn-04 (Version of Software)

Use **dn-04** to view the current software version of the Servo drive.

Software version can be checked as below:

Step	Keys	LED Display	Description
1	Power On		On" power on <b>Drive Status</b> is displayed.
2			Press <b>MODE-Key</b> twice to view diagnostics parameter dn-01.
3			Press <b>INCREMENT-Key</b> 3 times to display dn-04.
4			Press <b>ENTER-Key</b> for 2 seconds to view the software version. (Software version: 2.00)
5			Press <b>MODE-Key</b> once to return to dn-04 and parameter selection.

## dn-05 (JOG Operation)

Use dn-05 to JOG the motor. Jog is activated by following the steps below:

Note: JOG speed is in accordance with setting of Sn201(internal speed command 1).

Ensure that the required speed is set in Sn201 before executing this function.

Warning: Motor will be agitated run as soon as JOG command is activated.


without the need for SON input (Servo On signal).

Step	Key	LED display	Description
1	Power on		On" power on <b>Drive Status</b> is displayed.
2			Press <b>MODE-Key</b> once to view diagnostics parameter dn-01.
3			Press <b>INCREMENT-Key</b> 4 times to display dn-5.
4			Press <b>ENTER-Key</b> for 2 seconds to enter <b>JOG MODE</b> . Motor will power on immediately.
5			Press <b>INCREMENT-Key</b> , motor will run in the pre-defined positive direction.
6			Press <b>DECREMENT-Key</b> , motor will run in the pre-defined negative direction.
7			Press <b>MODE-Key</b> once to return to dn-05 and parameter selection. Motor stopped the excitation immediately.

### dn-07 (Auto offset adjustment of external analog command voltage)

If the external torque or speed analog command is set to 0V and the motor is rotating slowly, this is due to analog input zero offset, use **dn-07** to auto adjust this offset and stop the motor rotating. Follow the steps below:

Step	Key	LED Display	Description
1	Insert a link between analog command terminal SIN(CN1-26) and Analog Ground terminal AG(CN1-29) before proceeding.		
2	Power on		On" power on " Drive Status is displayed.
3			Press <b>MODE-Key</b> twice into diagnostics parameter dn-01.
4			Press <b>INCREMENT-Key</b> 6 times to display dn-7.
5			Press <b>ENTER-Key</b> for 2 seconds to enter <b>dn-07</b>
6			Press <b>INCREMENT-Key</b> once to set to 1 (Enable auto offset adjustment).
7			To save the altered preset value and activate auto offset adjust, Press the <b>ENTER- Key</b> for 2 seconds until "SET" is displayed briefly and then display is returned to parameter dn-07. To save this offset value, please select parameters Tn104 or Sn217 as required and press the ENTER-Key. Tn107 for analog torque command. Sn217 for analog speed command.




### dn-08 (Servo motor Model Code display)


Use **dn-08** to display servo motor code and check the servo drive and motor compatibility according to the table below.

If the dn08 preset is not according to the list below then contact your supplier.

The motor model code is stored in parameter Cn30.

dn-08 Display Cn030 Setting 	Drive Model	Motor Model	Motor Standards		Encoder Specification
			Watt (W)	Speed (rpm)	
H1111	JSDA-15	JSMA-SC01AB	100	3000	2500
H0112		JSMA-SC01AH			8192
H0121		JSMA-LC03AB	300	3000	2500
H0122		JSMA-LC03AH			8192
H0130		JSMA-SC02AF	200	3000	2000
H1133		JSMA-TC02AB			2500
H1134		JSMA-TC02AH	8192		
H0140		JSMA-SC04AF	400	3000	2000
H1141		JSMA-SC04AB			2500
H0142		JSMA-SC04AH			8192
H1143		JSMA-TC04AB			2500
H1144		JSMA-TC04AH			8192
H0211		JSDA-20	JSMA-LC08AB	750	3000
H0212	JSMA-LC08AH		8192		
H0220	JSMA-SC04AF		400	3000	2000
H1221	JSMA-SC04AB				2500
H0222	JSMA-SC04AH				8192
H1223	JSMA-TC04AB				2500
H1224	JSMA-TC04AH		8192		
H0230	JSMA-SC08AF		750	3000	2000
H1233	JSMA-TC08AB				2500
H1234	JSMA-TC08AH		8192		
H0241	JSMA-MA05AB		550	1000	2500
H0242	JSMA-MA05AH				8192
H0251	JSMA-MH05AB			1500	2500
H0252	JSMA-MH05AH				8192






dn-08 Display Cn030 Setting 	Drives Model	Motor Model	Motor Standards		Encoder Specification	
			Watt (W)	Speed (rpm)		
H0310	JSDA-30	JSMA-SC08AF	750	3000	2000	
H1313		JSMA-TC08AB			2500	
H1314		JSMA-TC08AH			8192	
H0321		JSMA-MA10AB	1000	1000	2500	
H0322		JSMA-MA10AH			8192	
H0331		JSMA-MB10AB		2000	2500	
H0332		JSMA-MB10AH			8192	
H0341		JSMA-MH10AB		1500	2500	
H0342		JSMA-MH10AH			8192	
H0351		JSMA-MC10AB	3000	3000	2500	
H0352		JSMA-MC10AH			8192	
H0361		JSMA-MA15AB			1500	1000
H0362		JSMA-MA15AH	8192			
H0371		JSMA-MB15AB	2000	2500		
H0372		JSMA-MB15AH		8192		
H0381		JSMA-MC15AB	3000	3000		2500
H0382		JSMA-MC15AH				8192
H0511		JSDA-50	JSMA-MA15AB	1500	1000	2500
H0512	JSMA-MA15AH		8192			
H0521	JSMA-MB15AB		2000		2500	
H0522	JSMA-MB15AH				8192	
H0531	JSMA-MC15AB		3000	3000	2500	
H0532	JSMA-MC15AH				8192	
H0541	JSMA-MB20AB				2000	2000
H0542	JSMA-MB20AH		8192			
H0551	JSMA-MC20AB		3000	3000		2500
H0552	JSMA-MC20AH					8192
H0711	JSDA-75	JSMA-MB30AB	3000	2000	2500	
H0712		JSMA-MB30AH			8192	
H0721		JSMA-MC30AB		3000	3000	2500
H0722		JSMA-MC30AH				8192

# Chapter 4 Trial Operation

Before proceeding with trial run, please ensure that all the wiring is correct.

Trial run description below covers the operation from keypad and also from an external controller such as a PLC.

Trial run with external controller speed control loop (analog voltage command) and position control loop (external pulse command).

<b>(1) No-load servo motor. Trial run (Reference:4-1)</b>	
<b>A. Servo Drive wiring and motor installation</b>	<b>B. Purpose of trial run</b>
 <p>Power Wiring</p> <p>SV-Motor</p> <p>Motion Table</p>	<p>Confirm if the items below are correct:</p> <ul style="list-style-type: none"> <li>. Drives power cable wiring</li> <li>. Servo Motor wiring</li> <li>. Encoder wiring</li> <li>. Setting servo motor rotation direction and speed</li> </ul>
<b>(2) No-load servo motor with a host controller. Trial run (Reference:4-2)</b>	
<b>A. Servo drive wiring and motor installation</b>	<b>B. Purpose of trial run</b>
 <p>Power Wiring</p> <p>Connect to Host Controller</p> <p>SV-Motor</p> <p>Motion Table</p>	<p>Confirm if the items below are correct:</p> <ul style="list-style-type: none"> <li>. Control signal wiring between host controller and servo drive.</li> <li>. Servo motor rotation direction, speed and rotating number .</li> <li>. Brake function, operation limit function and protection function.</li> </ul>
<b>(3) Servo motor connected to load and controlled by a host controller. Trial run (Reference:4-3)</b>	
<b>A. Servo drive wiring and motor installation</b>	<b>B. Purpose of trial run</b>
 <p>Power Wiring</p> <p>Connect to Host Controller</p> <p>SV-Motor</p> <p>Motion Table</p>	<p>Confirm if the items below are correct:</p> <ul style="list-style-type: none"> <li>. Servo motor rotation direction, speed and mechanical operation range.</li> <li>. Set related control parameters.</li> </ul>

## 4-1 Trial Operation Servo motor without Load

To carry out a successful trial run follow the steps below and ensure that drive wiring is correct and as specified.



### Warning!

**In order to prevent potential damage, prior to trial run ensure that the driven mechanism, couplings and belts etc are disconnected from the motor.**

#### 1. Installation of servo motor.

Ensure that the motor is installed securely so that there is no movement and vibration during trial run.


#### 2. Wiring.

Check servo drive, motor power connections and motor encoder connection.

No control signal wiring is required of this stage thus remove connector (CN1) from the servo drive.

#### 3. Servo drive power.

Apply power to servo drive. If the display shows any Alarm message such as graph below then refer to Alarm contents of chapter 8 to identify the cause.



AL-14 is caused by Input terminals **CCWL (Counter clockwise Limit)** and **CWL (Clockwise Limit)** being activated at the same time.

See (the default setting of high or low input logic state according to the description in section 5-6-1 ).

Because of the alarm, the servo can not operate normally.

Set the parameter **Cn002.1=1** to disable the drive limit function temporarily during trial run period.

**Steps for setting parameter Cn002.1 ( CCWL &CWL Rotation limit selection).**

Setp	Keys	LED Display	Description
1	Power on		On" power on " <b>Drive Status</b> is displayed.
2			Press <b>MODE-Key</b> 4 times to display Cn001.
3			Press <b>INCREMENT-Key</b> once to display Cn002.
4			Press <b>ENTER-Key</b> for 2 secs to display the preset value of Cn002. Note: Cn 002 includes 4 digits corresponding to Cn002.0,Cn002.1,Cn002.2 & Cn002.3.
5			Press ENTER-Key once to move to the 2 <sup>nd</sup> digit for (Cn 002.1).
6			Press <b>INCREMENT- Key</b> once to adjust the 2 <sup>nd</sup> digit to 1. Disable the function of external limits CCWL and CWL.
7			To save the setting value by Press the <b>ENTER- Key</b> for 2 seconds until " <b>SET</b> "is displayed briefly and then display is returned to parameter Cn-002.

After accomplish these steps, reset the power. If there are any other alarms then refer to section **8-2 (Clearing Alarms)**. Once there is no alarms then operate the drive again. If any of the alarms can not be cleared, please contact your local supplier for assistance.

**4. Mechanical Brake Release.**

When a brake type servo motor is used then must release the brake before starting trial run by applying 24vdc voltage to brake terminals.

**5. Keypad Trial run (JOG function).**

Jog function can be used to check if motor speed and rotation direction is correct. Parameters Sn 201(internal speed command 1) and Cn004 (motor rotation direction selection) Can be used to set the required speed and direction.

**Warning!**

**Set the required JOG speed before the trial run otherwise the motor will run at the default speed set in parameter Sn201(internal speed command 1).**

**Warning!**

**Regardless of external SON (servo on) is active or not, Servo motor will get excitation as soon as JOG is activated.**

Steps for setting JOG function:

Step	Keys	LED Display	Description
1	Power on		On" power on " Drive Status is displayed.
2			Press <b>MODE-Key</b> twice to view diagnostics parameter dn-01.
3			Press <b>INCREMENT-Key</b> 4 times to display dn-5.
4			Press <b>ENTER-Key</b> for 2 seconds to enter <b>JOG MODE</b> . Motor will power on immediately.
5			Press <b>INCREMENT-Key</b> , motor will run in the pre-defined positive direction.
6			Press <b>DECREMENT-Key</b> , motor will run in the pre-defined negative direction.
7			Press <b>MODE-Key</b> once to return to dn-05 and parameter selection. Motor power will be turned off immediately.

## 4-2 Trial Operation for Servo motor without Load from Host Reference

Check and ensure that all power connections to the drive and motor and control signal connection between the host controller and the drive are correct. Motor must be mechanically disconnected from the load.


Following section describes the trial run when using a host controller such as a PLC.

Two trial runs have been discussed. Speed control mode ( Section B) and Position control mode ( Section C).

Section A shows the connections and SON signal (servo on) requirements for both trial runs.

### A. Launching Servo motor

Example wiring diagram:



#### a. Disable Analog Input command terminals.

**Speed control mode:** Link analog input terminal SIN to 0V terminal (AG).

**Position control mode:** Link external pulse command terminals “Pulse” to “/Pulse” and “Sign” to “/Sign”.

#### b. Enable Servo ON Signal

Connect **SON** terminal to IG 24 (0V) terminal (Digital Ground).


On drive power up servo will be turned on. Now check for any Alarms. If any alarms then refer to Chapter 8-2 for how to reset the Alarms.

## B. Trial run in Speed control mode(Cn001=1).

### 1. Wiring check:

Check and ensure that all power cable and control signal connections are correct as shown below.

To be able to adjust the speed for test connect a potentiometer between terminals SIN (analog input voltage) and AG (Analog Ground). Set the analog input voltage to 0V. (No speed reference).



### 2. Apply Servo on.

Apply power to the drive and activate (**SON**) signal by switching SON terminal to IG24 (input digital Ground).

If the motor rotates slowly, while the speed analog input voltage is 0 volts

then use **dn-07** function to auto offset adjustment for the analog input value. (refer to **section 3-2-2**).

### 3. Check the relationship between motor speed and the analog input speed command.

Increase the analog speed input voltage gradually (by potentiometer) and monitor the actual motor speed by parameter **Un0-01**.


Check if motor rotation direction is correct and if necessary set it by parameter **Cn004**.

Check for correctness of analog speed command ratio in relation to the preset in parameter (**Sn216**) and analog speed command limit as set in parameter (**Sn218**).

Finally, switch off **SON signal** (turn off the servo motor).

#### 4. Connection with a host controller.

Check and ensure that the wiring for the servo drive and host controller, speed analog signal input (**SIN**), and encoder output (**PA, /PA, PB, /PB, PZ, /PZ**) are all correct and according to the diagram below:



#### 5. Confirm the rotation number and encoder output of Servo Motor.

Use parameter Un-14 to check if the Motor feed back (number of revolutions) per minute is correct and the same as number of revolutions sent by the host controller.

If there is any difference then check and make sure that parameter Cn005 ( Encoder ppr) is set correctly.


Once this is complete remove SON signal to switch off power to the motor.



### C. Position control mode trial run (Cn001=2).

#### 1. Wiring:

Check and ensure that all power connections to the drive and motor and control signal connections are correct as diagram below.



#### 2. Setting electronic gear ratio.

Set electronic gear ratio parameters Pn302~Pn306 as required for the positioning application. (refer to section 5-4-3).

Note: Electronic gear ratio parameter can be used to scale the command output pulse.

This would be useful in transmission applications where move distance per move command pulse has to be scaled due to mechanical requirements.

#### 3. Apply Servo on.

Apply power to the drive and activate (**SON**) signal by switching SON terminal to IG24 (input digital Ground).

#### 4. Confirm motor speed, direction and number of revolutions.

Apply a low-speed pulse command from the host controller to the servo drive so that the servo motor operates at low-speed.

- Compare the number of pulses per revolution from parameters **Un-15** ( motor feed back pulse ppr) and **Un-17** (Input command ppr) these should be the same.
- Compare the number of revolutions using parameters Un-14 ( motor feed back rotation number) and Un-16 (pulse command rotation number) these should be the same.

If there are differences then adjust electronic gear ratio parameters **Pn302~Pn306** as required and test again until the result is satisfactory.

If the direction of motor rotation is incorrect then check and if necessary set parameter Pn 301.0 (position pulse command types).

Also check and if necessary set parameter **Pn314** (Position command direction selection).

Once the test result is correct then remove SON signal. (Power to the motor is switched off).

### 4-3 Trial Operation with the Servo motor Connected to the Machine




## Warning

Servo drive parameters must be set correctly otherwise damage to machinery and potential injury may result.

Do not close to the machine after temporary power loss, the machine may restart unexpectedly.

Please take the measures highlighted in the section below before trial run with load.

- Consider the Mechanical system requirements and set the parameters appropriate for control by the host controller.
- Ensure that the rotation direction and speed are suitable for the Mechanical system.



Steps required for Trial run.

1. **Ensure that the ServoDrive Power is off.**

2. **Connect the servo motor to the load shaft.**

Refer to Chapter 1-5 to check the installation guidelines for the servo motor.

3. **Gain adjustment for the servo control loop.**

Refer to Chapter 5-5 for details.

4. **Trial run with a host controller.**

Run command is to be signaled by the host controller.

Refer to Chapter 4-2 to choose the required trial run mode (Speed control or position control modes) according to the application and set and adjust the parameters if necessary for the application.

5. **Repeat adjusting and record the set parameter values.**

Repeat steps 3 and 4 until the mechanical system is operating satisfactorily then record the Gain value and the parameters changes for the future use.

## Chapter 5 Control Functions

### 5-1 Control Mode Selection

There are three control modes in the servo drive, torque, speed and position modes can be selected individually or as a combination according to the selection table below:


Parameter	Name	Setting	Description	Default Value	Control Mode
★ Cn001	Control mode selection	0	<b>Torque control</b>	2	ALL
			To use one analog voltage command signal to control torque. Please refer to <b>5-2</b> .		
		1	<b>Speed control</b>		
			Input contacts <b>SPD1</b> and <b>SPD2</b> can be used to select 4 -steps of speed. Please refer to section <b>5-3-1</b> .		
		2	<b>Position control (External pulse command)</b>		
			Four separate selectable pulse command types are possible to control position. Please refer to section <b>5-4-1</b> .		
		3	<b>Position / Speed control switch</b>		
			Input contact <b>MDC</b> can be used to switch between position & speed control. Please refer to section <b>5-6-2</b> .		
4	<b>Speed / Torque control switch</b>				
	Input contact <b>MDC</b> can be used to switch between speed & torque control. Please refer to section <b>5-6-2</b> .				
5	<b>Position / Torque control switch</b>				
	Input contact <b>MDC</b> can be used to switch between position & torque control. Please refer to <b>section 5-6-2</b> .				
6	<b>Position control (internal position command)</b>				
	Input contacts <b>POS 1~POS 4</b> can be used to select 16 programmable preset position commands to control position. Please refer to <b>5-4-2</b> .				

*New setting will become effective after re-cycling the power.*


## 5-2 Torque mode

Torque mode is used in applications such as printing machines, coil wiring machines, injection molding machines and specific application that requiring torque control.

Diagram below shows the torque control process diagram.



Analog voltage torque command is applied to the drive input terminals as shown below:



### **Caution!**

**Care should be taken in selection of required torque direction CW/CCW.  
Please refer to Chapter 5-2-4.**


### 5-2-1 Analog Torque command Ratio.

Analog torque command ratio can be used to adjust the relationship between Input voltage torque command and actual torque command.

Parameter	Name	Default	Unit	Setting range	Control Mode
Tn103	Analog torque command ratio	300	%/10V	0~300	T

Setting example: refer to the following diagram.

1. With Tn103 set to 300, a torque command input voltage of 10V, corresponds to 300% of rated torque. For input voltage of 5V, actual torque command will be 150% of rated torque.
2. With Tn03 set to 200, a torque command input voltage of 10V, corresponds to 200% of rated torque. For input voltage of 5V, actual torque command will be 100%.



## 5-2-2 Adjusting the analog torque command offset


For a torque command of 0V, motor could possibly be rotating slowly.

To rectify this effect by adjust offset value in parameter **Tn104** or use auto offset adjust feature.

(Please refer to section 3-2-2).

**Note :** To check and set the offset to zero, insert a link between analog torque command contact **SIN(CN1-26)** and analog ground contact **AG (CN1-29)**.

Parameter	Name	Default	Unit	Setting range	Control mode
Tn104	Analog torque command offset	0	mV	-10000~10000	T



### 5-2-3 Torque command linear acceleration and deceleration

An smooth torque command can be achieved by enabling [acceleration/Deceleration](#) parameter Tn101.

Parameter	Name	Setting	Description	Control mode
★ Tn101	Linear acceleration/ deceleration method	0	Disable	T
		1	Enable	


Torque command [acceleration/](#)deceleration time,

is the time taken for the torque to rise from zero to the required level by Tn102.

As per diagram below:-

Parameter	Name	Default	Unit	Setting Range	Control mode
★ Tn102	Linear acceleration /deceleration time period	1	msec	1~50000	T

***New setting will become effective after re-cycling the power.***



Setting examples:

- (1) To achieve 50% of rated torque output in 10msec:

$$Tn102 = 10(\text{msec}) \times \frac{100\%}{50\%} = 20(\text{msec})$$

- (2) To achieve 75% of rated torque output in 10msec:

$$Tn102 = 10(\text{msec}) \times \frac{100\%}{75\%} = 13(\text{msec})$$

### 5-2-4 Definition of torque direction

In torque mode, torque direction can be defined by one of the following three methods.

- (1) Input contacts **RS1**, **RS2**. (torque command CW/CCW selectable by programmable input)
- (2) Parameter **Cn004**. (motor rotation direction )
- (3) Input contact **TRQINV**. (reverse torque command)

**Caution !**


**All 3 methods can be active at the same time.**

**User must ensure that correct selections are made for these three selections.**

Input Contact		Description	Control mode
RS2	RS1		
0	0	Zero torque	T
0	1	Rotation in the current torque command direction	
1	0	Reverse the current torque command direction	
1	1	Zero torque	

Note: RS2 and RS1 contact status "1" (ON) and "0" (OFF).

Please check 5-6-1 to set the required high /Low signal levels ( PNP/NPN ) .

Parameter Signal	Name	Setting	Description		Control mode
Cn004	Motor rotation direction (load end) 	<b>No.</b>	<b>Torque Control</b>	<b>Speed Control</b>	S/T
		<b>0</b>	Counter Clockwise(CCW)	Counter Clockwise (CCW)	
		<b>1</b>	Clockwise(CW)	Counter Clockwise (CCW)	
		<b>2</b>	Counter Clockwise (CCW)	Clockwise (CW)	
		<b>3</b>	Clockwise (CW)	Clockwise (CW)	

Input contact TRQINV	Description	Control mode
0	Rotation in current torque command direction	T
1	Reverse torque command direction	

Note: Input contacts status "1" (ON) and "0" (OFF).

Please refer to 5-6-1 to set the required high /Low signal levels ( PNP/NPN) selection.



### 5-2-5 Internal Torque Limit

In torque Control mode, user can set internal torque limit values as required.

Set as below:-

Parameter	Name	Default	Unit	Setting range	Control mode
Cn010	CCW Torque command limit	300	%	0~300	ALL
Cn011	CW Torque command limit	-300	%	-300~0	ALL

### 5-2-6 Limiting Servomotor Speed during Torque Control

In torque control, input contacts SPD1 and SPD2 can be used for selecting one of the two methods below for setting speed limits.

- (1) External Analog command ( Default) Signal is applied to terminals PIC & AG ( pins 27& 29 on CN1)
- (2) Selection of Three presentable Limits (Tn105~Tn107) according to the table below.


**Caution! For achieving smooth speed response please refer to section 5-3-6.**

Input contact SPD2	Input contact SPD1	Speed limit command	Control mode
0	0	External analog command <b>PIC(CN1-27)</b>	T
0	1	Internal speed limit1 <b>Tn105</b>	
1	0	Internal speed limit2 <b>Tn106</b>	
1	1	Internal speed limit3 <b>Tn107</b>	

Note: Input contacts status "1" (ON) and "0" (OFF).

Please check 5-6-1 to set the required high /Low signal levels ( PNP/NPN) selection.

Below is the external analog speed limit command wiring diagram:



Internal presentable speed limit parameters for torque control mode are listed below:

These preset limits apply to both CW & CCW directions.

Parameter	Name	Default	Unit	Setting range	Control mode
Tn105	Internal speed limit 1	100	rpm	0~3000	T
Tn106	Internal speed limit 2	200	rpm	0~3000	T
Tn107	Internal speed limit 3	300	rpm	0~3000	T


P.S also refer to page 6-11 for detail.

## 5-2-7 Additional torque control functions

### Torque Output Monitor

When the torque level in CW or CCW directions becomes greater than the value set in **Tn108** (torque level monitor value), the output contact **INT** is active.

Parameter	Name	Default	Unit	Setting range	Control mode
Tn108	Torque output monitor level	100	%	0~300	ALL



Note: Input contacts status “1” (ON) and “0” (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

### Torque Smoothing Filter



Torque vibration can be diminished by setting an appropriate value in Cn034 (Torque command smoothing filter). In the other hand, this will cause a delay in the response time of the torque loop.

Parameter	Name	Default	Unit	Setting range	Control mode
Cn034	Torque smoothing filter	0	Hz	0~1000	ALL

### 5-3 Speed Mode

Speed Mode is necessary for applications that require precisely speed control, such as weaving, drilling and CNC type machines. Diagrams below shows the speed control system in two parts.

First stage shows **Speed processing and conditioning** and the second stage shows the **Speed controller** With P/I/P control modes, and controller1&2 selection and interface with torque control stage.



### 5-3-1 Selection for speed command

In Speed control, input contacts SPD1 and SPD2 can be used for selecting one of the two methods below for setting speed limits.


- (1) External Analog command (Default) : Analog signal is input from terminals SIN & AG (pins 26& 29 on CN1)
- (2) Internal speed command: Selection of Three presentable Limits according to the table below.

Input Contact SPD2	Input Contact SPD1	Speed Command	Control Mode
0	0	External analog command <b>SIN(CN1-26)</b>	S
0	1	Internal speed command 1 <b>Sn201</b>	
1	0	Internal speed command 2 <b>Sn202</b>	
1	1	Internal speed command 3 <b>Sn203</b>	

Note: Input contacts status “1” (ON) and “0” (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

Diagram below shows the external analog speed command wiring:



Internal presetable speed limit parameters for speed command mode are listed below:

These preset limits apply to both CW & CCW directions.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn201	Internal speed command 1	100	rpm	-3000~3000	S
Sn202	Internal speed command 2	200			
Sn203	Internal speed command 3	300			


### 5-3-2 Analog speed command Ratio

Analog speed command ratio can be used to adjust the relationship between Input voltage speed command and actual speed command.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn216	Analog speed command ratio	3000	rpm/10V	100~4500	S

Setting Example:

- (1) With **Sn216 set to 3000**, a speed command input voltage of 10V, corresponds to 3000rpm; for an input voltage of 5V speed command will be 1500rpm.
- (2) With **Sn216 set to 2000**, a speed command input voltage of 10V, corresponds to 2000rpm, for an input voltage of 5 volts speed command will be 1000rpm.



### 5-3-3 Adjusting the analog reference offset


For a speed command of 0V, motor could possibly be rotating slowly.

To rectify this effect by adjust offset value manually in parameter **Sn217** or use auto offset adjust feature. (Please refer to section 3-2-2).

**Note :** To check and set the offset to zero, insert a link between analog torque command contact **SIN(CN1-26)** and analog ground contact **AG (CN1-29)**.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn217	Analog speed command offset adjust	0	mV	-10000~10000	S

Refer to the following diagrams:




### 5-3-4 Analog reference for speed command limit

A maximum limit for analog speed can be set by Sn218.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn218	Analog speed command limit	Rate rpm x 1.02	rpm	100~4500	S

### 5-3-5 Encoder Signal Output

Servo motor encoder pulse signal can be output to a host controller to establish an external control loop.



Set the required encoder Pulse Per Revolution (PPR) in parameter Cn005.





Default output value is the actual encoder PPR.

Parameter	Name	Default	Unit	Setting range	Control mode
★Cn005	Encoder pulse output scale	Encoder Pulse Per Revolution	pulse	1~ Encoder PPR	ALL

***New setting will become effective after re-cycling the power.***

Encoder pulse output terminal description:

Pin	Name	Pin NO. of CN1	Control mode
PA	Encoder pulse output A Phase signal	CN1-35	ALL
/PA	Encoder pulse output /A Phase signal	CN1-36	
PB	Encoder pulse output B Phase signal	CN1-37	
/PB	Encoder pulse output /B Phase signal	CN1-38	
PZ	Encoder pulse output Z Phase signal	CN1-39	
/PZ	Encoder pulse output /Z Phase signal	CN1-40	



### 5-3-6 Smoothing the speed command

Sn205 can be used to eliminate speed overshoot and motor vibration by selecting one of the acceleration /deceleration methods which is suitable for the application from the table below.

Parameter	Name	Setting	Description	Control mode
Sn205	Speed command accel/decel smooth method	0	Disable accel/decel smooth function	S
		1	Smooth accel/decel according to parameter Sn206	
		2	Linear accel/decel according to parameter Sn207	
		3	S-curve accel /decel according to parameter Sn208	


Above three methods of Acceleration/deceleration are described below.

#### (1)Speed command smooth ac/deceleration:

Set **Sn205=1** to enable the use of speed command smooth acceleration/deceleration function.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn206	Speed command smooth accel/decel time Constant	1	msec	1~10000	S

Smooth acceleration/deceleration time corresponds to the time in which the speed command increases from 0 to 63.2% as shown in diagram below.





**Setting example:**

(1) To achieve 95% of speed command output in 30msec:

$$\text{Set } Sn206 = \frac{30(\text{msec})}{-\ln(1-95\%)} = 10(\text{msec})$$

(2) To achieve 75% of speed command output in 30msec:

$$\text{Set } Sn206 = \frac{30(\text{msec})}{-\ln(1-75\%)} = 22(\text{msec})$$


*In= Natural log*

**(2)Speed command linear acceleration/deceleration function:**

Set **Sn205=2** to enable the use of speed command linear acceleration/deceleration function.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn207	Speed command linear accel/decel time constant	1	msec	1~50000	S

Linear acceleration/deceleration time corresponds to the time in which the speed increases (linearly) from zero to the rated speed. As shown in the diagram below.



**Setting examples:**

(1) To achieve 50% of rated speed output in 10msec:

$$\text{Set } Sn207 = 10(\text{msec}) \times \frac{100\%}{50\%} = 20(\text{msec})$$

(2) To achieve 75% of rated speed output in 10msec:

$$\text{Set } Sn207 = 10(\text{msec}) \times \frac{100\%}{75\%} = 13(\text{msec})$$


### S-Curve Speed Command Acceleration/Deceleration:

Set Sn205=3 to enable the use of S-Curve speed command ac/deceleration function.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn208	S-Curve speed command accel/decel time setting	1	msec	1~1000	S
Sn209	S-Curve speed command acceleration time setting	200	msec	0~10000	S
Sn210	S-Curve speed command deceleration time setting	200	msec	0~10000	S

In applications where normal acceleration/deceleration on ramp up or ramp down bring in vibration of the mechanical

system. S- curve acceleration/deceleration parameters could help to reduce vibration as diagram below:



**Caution! Setting Rule:**  $\frac{t_a}{2} > t_s$  ,  $\frac{t_d}{2} > t_s$


### 5-3-7 Setting rotation direction

Motor rotation direction in speed mode can be set by parameter **Cn004 (Motor rotation direction)** and input contact **SPDINV** according to the tables below.

**Caution!**

**Both methods can be operated at the same time.**

**Ensure that these parameters are set correctly for the required direction.**

Parameter	Name	Setting	Description		Control mode
			Torque control	Speed control	
Cn004	Motor rotation direction (observation from load side).  	<b>No.</b>			S/T
		<b>0</b>	Counter Colckwise (CCW)	Counter Colckwise (CCW)	
		<b>1</b>	Colckwise (CW)	Counter Colckwise (CCW)	
		<b>2</b>	Counter Colckwise (CCW)	Colckwise (CW)	
		<b>3</b>	Colckwise (CW)	Colckwise (CW)	

Input contact SPDINV	Description	Control mode
0	Rotation by speed command direction.	S
1	Rotation by reverse speed command direction.	

Note: Input contacts status "1" (ON) and "0" (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

### 5-3-8 Speed Loop Gain

In speed mode there are two speed controller loops, with separate Gain ( P ) and Integral ( I ) functions.

Speed controllers 1 or 2 can be selected by setting one of the multi- function input terminals, to selection G-SEL or by setting one of the parameters Cn20-Cn24 as required.


Please refer to section 5-3-11 section B for more details.

Parameter	Name	Default	Unit	Setting range	Control mode
Sn211	Speed loop gain 1	40	Hz	10~450	Pe/Pi/S
Sn212	Speed loop integral time constant 1	100	x0.2 ms	1~500	Pe/Pi/S
Sn213	Speed loop gain 2	40	Hz	10~450	Pe/Pi/S
Sn214	Speed loop integral time constant 2	100	x0.2 ms	1~500	Pe/Pi/S

Diagram below shows the speed controller.

Setting a high speed loop gain or a lower speed loop integral time provides a faster speed control response time.

For more details refer to section 5-5.



### 5-3-9 Notch Filter

The function of the Notch filter is to suppress mechanical system resonance.

Resonance occurs due to low mechanical system rigidity (high springiness) of transmission systems used with servo motors such as couplings, bearings, lead screws, etc.





Enter the mechanical system vibration (resonance frequency) in parameter Cn013 (Notch Filter frequency) and adjust Cn014 to set the filter bandwidth scaling factor.

Lower the setting of Cn014 value, wider is the notch filter frequency bandwidth. The adjustment required depends on the application.

**Caution!**

**If Cn013 is set to “0” the Notch filter is disabled.**

Parameter	Name	Default	Unit	Setting range	Control mode
Cn013	Notch Filter frequency	0	Hz	0~1000	Pi/Pe/S
Cn014	Notch Filter Band Width Scaling factor	7	X	1~100	Pi/Pe/S



### 5-3-10 Torque limit of speed control mode

In speed mode, the motor torque limit input contact **TLMT** could be used to select one of the two methods below:

- (1) Internal torque limit: Using default **Cn010** (CCW Torque command limit ) and **Cn011**(CW Torque command limit ).
- (2) External analog command: Using two separate analog voltage command signals at input terminals **PIC(CN1-27)** to limit CCW torque and **NIC(CN1-28)** to limit CW torque.

As shown in the table below:

Input contact TLMT	CCW torque command limit source	CW torque command limit source	Control mode
0	<b>Cn010</b>	<b>Cn011</b>	ALL
1	External analog command <b>PIC(CN1-27)</b>	External analog command <b>NIC(CN1-28)</b>	Pi/Pe/S

Note: Input contacts status “1” (ON) and “0” (OFF).

Please check 5-6-1 to set the required high /Low signal levels ( PNP/NPN) selection.


**Caution!**

To use external analog torque command limit , If analog torque command limit is greater than internal torque command limit, the internal torque command limit has the priority over external analog torque command limit.

Internal Torque command limit is set as below.

Parameter	Name	Default	Unit	Setting range	Control mode
Cn010	CCW torque command limit	300	%	0~300	ALL
Cn011	CW torque command limit	-300	%	-300~0	ALL

The diagram below shows the external analog torque limit command wiring:



## 5-3-11 Gain Switched

### PI/P control mode selection (Section A)


### Automatic gain 1& 2 switch (Section B)

The selection of **PI/P control mode switch** and **Automatic gain 1& 2 switch** by parameters or from input terminals can be used in following conditions.

- (1) In speed control, to restrain acceleration/deceleration overshooting.
- (2) In position control, to restrain oscillations and decrease the adjusting time.
- (3) To decrease the possible noise caused by using Servo Lock function.

#### (A) Switching between PI/P Control modes

Switch over from PI to P mode is determined by setting of parameter Cn015.0 and according to the selection options below:

Parameter Signal	Name	Setting	Description	Control mode
Cn015.0 	PI/P control mode switch	0	Switch from PI to P if the <i>torque</i> command is greater than <b>Cn016</b>	Pi/Pe/S
		1	Switch from PI to P if the <i>speed</i> command is greater than <b>Cn017</b>	
		2	Switch from PI to P if the <i>acceleration</i> command is greater than <b>Cn018</b>	
		3	Switch from PI to P if the <i>position error</i> is greater than <b>Cn019</b>	
		4	Switch from PI to P by the input contact <b>PCNT</b> . Set one of the multi function terminals to option 03.	

Parameter	Name	Default	Unit	Setting range	Control mode
Cn016	PI/P control mode switch by (torque command)	200	%	0~399	Pi/Pe/S
Cn017	PI/P control mode switch by (speed command)	0	rpm	0~4500	Pi/Pe/S
Cn018	PI/P control mode switch by (acceleration)	0	rps/s	0~18750	Pi/Pe/S
Cn019	PI/P control mode switch by (position error value)	0	pulse	0~50000	Pi/Pe/S




**(1) PI to P mode switch over by comparing *Torque command*.**

When the ***Torque command*** is less than **Cn016** PI control is selected.

When the ***Torque command*** is greater than **Cn016** P control is selected..

As shown in diagram below:




**(2) PI to P mode switch over by comparing *Speed command*.**

When the ***Speed command*** is less than **Cn017** PI control is selected.

When the ***Speed command*** is greater than **Cn017** P control is selected.

As shown in diagram below:




(3) **PI to P mode switch over by comparing *Acceleration command*.**

When the ***Acceleration command*** is less than **Cn018** PI control is selected.

When the ***Acceleration command*** is greater than **Cn018** P control is selected.

As shown in diagram below:




(4) **PI to P mode switch over by comparing *Position Error value*.**

When the ***Position Error value*** is less than **Cn019** PI control is selected.

When the ***Position Error value*** is greater than **Cn019** P control is selected.

As shown in diagram below:




(5) **PI to P mode switch over by PCNT input contact.**

When the **PCNT input contact is open** PI control is selected.

When the **PCNT input contact is closed** P control is selected.

Note: Input contacts status "1" (ON) and "0" (OFF).


Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.



## (B) Automatic gain 1 & 2 switching

Selection of **Automatic gain 1 & 2 switch** with different **P&I Gains** is possible by setting Parameter Cn 015.1 to one of the selections listed in the table below.

Parameter Cn 020 can be use for setting a switch delay time between different gains. (Gain 1 and 2)

Parameter	Name	Setting	Description	Control Mode
Cn015.1 	<b>Automatic gain 1 &amp; 2 switch</b>	0	Switch from gain 1 to 2 if <b>torque</b> command is greater than <b>Cn021</b> .	Pi/Pe/S
		1	Switch from gain 1 to 2 if <b>speed</b> command is greater than <b>Cn022</b> .	
		2	Switch from gain 1 to 2 if <b>acceleration</b> command is greater than <b>Cn023</b> .	
		3	Switch from gain 1 to 2 if <b>position error</b> value is greater than <b>Cn024</b> .	
		4	Switch from gain 1 to 2 by input contact <b>G-SEL</b> . Set one of the multi function terminals to option 15 of Hn501.	

Parameter	Name	Default	Unit	Setting Range	Control Mode
Cn020	Automatic gain 1 & 2 switch delay time.	0	x0.2 msec	0~10000	Pi/Pe/S
Cn021	Automatic gain 1 & 2 switch condition ( <b>torque command</b> )	200	%	0~399	Pi/Pe/S
Cn022	Automatic gain 1 & 2 switch condition ( <b>speed command</b> )	0	rpm	0~4500	Pi/Pe/S
Cn023	Automatic gain 1 & 2 switch condition ( <b>acceleration command</b> )	0	rps/s	0~18750	Pi/Pe/S
Cn024	Automatic gain 1 & 2 switch condition ( <b>position error value</b> )	0	pulse	0~50000	Pi/Pe/S

**Note: Gain 1** : is consisted of **Pn310**(position loop gain 1), **Sn211**(speed loop gain 1 ) and

**Sn212**(Speed loop integral time 1).

**Gain 2** : is consisted of **Pn311**(position loop gain 2), **Sn213**(speed loop gain 2) and

**Sn214**(Speed loop integral time 2 ).


**(1) Automatic gain 1&2 switch condition ( by *torque command* ).**

When torque command is less than **Cn021** , Gain 1 is selected.

When torque command is greater than **Cn021**, Gain 2 is selected

When **Gain 2** is active and torque command becomes less than **Cn021** system will automatically switch back to **Gain 1** the switch time delay can be set by Cn020.

As show in the diagram below:




**(2) Automatic gain 1&2 switch condition (by *Speed command* ).**

When speed command is less than Cn022 Gain 1 is selected.

When speed command is greater than Cn022 Gain 2 is selected.

When **Gain 2** is active and speed command becomes less than **Cn022** system will automatically switch back to **Gain 1** the switch time delay can be set by Cn020.

As show in the diagram below :




### (3) Automatic gain 1&2 switch condition (by Acceleration command).

When acceleration command is less than Cn023 Gain 1 is selected.

When acceleration command is greater than Cn023 Gain 2 is selected.

When **Gain 2** is active and acceleration command becomes less than **Cn023** system will automatically switch back to **Gain 1** the switch time delay can be set by Cn020.

| As show in the diagram below :




### (4) Automatic gain 1&2 switch condition (by Position error value ).

When position error value is less than Cn024 Gain 1 is selected.

When position error value is greater than Cn024 Gain 2 is selected.

When **Gain 2** is active and position error value becomes less than **Cn024** system will automatically switch back to **Gain 1** and the switch time delay can be set by Cn020.

| As show in the diagram below :




**(5) Automatic gain 1&2 switch condition by G-SEL input contact.**

When the G-SEL input contact is open Gain 1 is selected.

When G-SEL input contact is closed Gain 2 is selected.

When G-SEL input contact opens again then Gain 1 is selected and switch delay time can be set by Cn20.

As [show](#) in the diagram below :



Note: Input contacts status “1” (ON) and “0” (OFF).


Please refer to 5-6-1 for setting required high /Low signal levels (PNP/NPN) selection.

### 5-3-12 Other Functions

When the speed level in CW or CCW directions becomes greater than the value set in **Cn007** (Speed reached preset), the output contact **INS** operates.

#### Speed reached preset

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Cn007	Speed reached preset	Rated rpm × 1/3	rpm	0~4500	S/T




Note: Input contacts status "1" (ON) and "0" (OFF).

Please check section 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

## Zero Speed preset

When the speed is less than the speed set in Sn215 (Value of ZS), the output contact **ZS** operates.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Sn215	Value of zero speed	50	rpm	0~4500	S




Note: Input contacts status “1” (ON) and “0” (OFF)

Please check section 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

To Zero the speed command according to preset level in Sn215 set Sn204 to selection 1.

Parameter Signal	Name	Setting	Description	Control Mode
Sn204	Zero Speed selection	0	No action	S
		1	Regard Speed command as Zero. (According to Sn215 setting).	



## Servo Lock

In speed mode: the Servo Lock is used to lock servo motor when input voltage command is not at 0V.

When input contact **LOK** operates: The control mode changes to internal position control mode, it temporarily stop motor rotation. Please refer to section 5-6-1 for setting input contact **LOK** function.



## Speed Feed Back Smooth Filter

When there is system abnormal vibration or noise, Set **Cn032** (speed feed back smoothing filter) to restrain vibration or noise. Addition of this filter will delay the speed response of servo system.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Cn032	Speed feed back smoothing filter	500	Hz	1~1000	Pe/Pi/S

## 5-4 Position mode

Position control mode is used for high-precision applications on machinery such as machine tools.

The Position control mode offers *two methods* of control.

- External pulse input position command
- Internal position command.

In external pulse command input mode, the positioning command is signaled to the drive by a host Controller to achieve a fixed position.

In internal position command mode, 16 preset position commands can be set by parameters (**Pn317~Pn364**),


and can be activated by use of input contacts **POS1 ~ POS4**.

Set parameter **Cn001** (control mode selection) as required according to the table below.

Parameter Signal	Name	Setting	Description	Control Mode
★Cn001	Control mode selection	2	<b>Position control (External pulse command)</b>	ALL
			Using one pulse command signal to control position. Please refer to 5-4-3.	
		6	<b>Position control (Internal pulse command)</b>	
			Use input contacts to select 16 programmable preset position commands. Please refer to 5-4-2.	

**New setting will become effective after re-cycling the power.**

The diagram below shows the position loop control. Detailed functions are described in the following chapters.





### 5-4-1 External Pulse Command


Four types of external position pulse command signals can be interfaced,

These can be selected from the list below.

Position pulse signal logic can be selected Positive or negative as required.

Parameter Signal	Name	Setting	Description	Control Mode
★Pn301.0 	Position pulse command selection	0	(Pulse)+(Sign)	Pe
		1	(CCW)and (CW) pulse	
		2	AB-Phase Pulsex2	
		3	AB-Phase Pulsex4	
★Pn301.1 	Position pulse command logic selection	0	Positive Logic	Pe
		1	Negative Logic	

***New setting will become effective after re-cycling the power.***



Two types of pulse command can be connected, (Open collector) and (Line driver).

Please refer to **section 2-2-1** for the pulse wiring method.

Pulse command timing should be in accordance with the time sequence standard below.

Pulse Command Types	Time Sequence Diagram of Pulse Command	Time Standard
(Pulse)+ (Sign)	<p>The diagram shows two waveforms: Pulse and Sign. The Pulse waveform consists of a series of pulses with a period T. The Sign waveform is a single pulse that occurs during the first pulse of the Pulse train. Parameters are labeled: t1 (rise time), t2 (fall time), T (period), and t3 (pulse width).</p>	<p>Line Driver:  <math>t1, t2 \leq 0.1\mu s</math>  <math>t3 &gt; 3\mu s</math>  <math>\tau \geq 1.0\mu s</math>  <math>(\tau/T) \leq 50\%</math></p> <p>OpenCollector:  <math>t1, t2 \leq 0.2\mu s</math>  <math>t3 &gt; 3\mu s</math>  <math>\tau \geq 2.0\mu s</math>  <math>(\tau/T) \leq 50\%</math></p>
(CCW)/ (CW) Pulse	<p>The diagram shows two waveforms: Pulse and Sign. The Pulse waveform consists of a series of pulses with a period T. The Sign waveform is a single pulse that occurs during the first pulse of the Pulse train. Parameters are labeled: t1 (rise time), t2 (fall time), T (period), and t3 (pulse width).</p>	<p>LineDrive:  <math>t1, t2 \leq 0.1\mu s</math>  <math>t3 &gt; 3\mu s</math>  <math>\tau \geq 1.0\mu s</math>  <math>(\tau/T) \leq 50\%</math></p> <p>OpenCollector:  <math>t1, t2 \leq 0.2\mu s</math>  <math>t3 &gt; 3\mu s</math>  <math>\tau \geq 2.0\mu s</math>  <math>(\tau/T) \leq 50\%</math></p>
AB-Phase Pulse	<p>The diagram shows two waveforms: Pulse and Sign. The Pulse waveform consists of a series of pulses with a period T. The Sign waveform is a single pulse that occurs during the first pulse of the Pulse train. Parameters are labeled: t1 (rise time), t2 (fall time), T (period), and t (pulse width).</p>	<p>LineDrive:  <math>t1, t2 \leq 0.1\mu s</math>  <math>\tau \geq 1.0\mu s</math>  <math>(\tau/T) \leq 50\%</math></p> <p>OpenCollector:  <math>t1, t2 \leq 0.2\mu s</math>  <math>\tau \geq 2.0\mu s</math>  <math>(\tau/T) \leq 50\%</math></p>

Position command can be disabled ( Inhibited) by external input contact **INH**.

Input Contact INH	Description	Control Mode
0	Position Pulse command <b>enabled</b>	Pe
1	Position Pulse command <b>disabled</b>	

Note: Input contacts status "1" (ON) and "0" (OFF)

Please check section 5-6-1 to set the required high /Low signal levels ( PNP/NPN) selection.

## 5-4-2 Internal Position Command

In internal position command mode, 16 preset position commands can be set by parameters (Pn317~Pn364), and can be activated by use of input contacts POS1 ~ POS4.

Preset positions are programmable and can be selected according to the table below:

Position Command	POS4	POS3	POS2	POS1	Position Command Parameter		Position Speed Parameter
					Rotation Number	Pulse Number	
P1	0	0	0	0	Rotation Number	Pn317	Pn319
					Pulse Number	Pn318	
P2	0	0	0	1	Rotation Number	Pn320	Pn322
					Pulse Number	Pn321	
P3	0	0	1	0	Rotation Number	Pn323	Pn325
					Pulse Number	Pn324	
P4	0	0	1	1	Rotation Number	Pn326	Pn328
					Pulse Number	Pn327	
P5	0	1	0	0	Rotation Number	Pn329	Pn331
					Pulse Number	Pn330	
P6	0	1	0	1	Rotation Number	Pn332	Pn334
					Pulse Number	Pn333	
P7	0	1	1	0	Rotation Number	Pn335	Pn337
					Pulse Number	Pn336	
P8	0	1	1	1	Rotation Number	Pn338	Pn340
					Pulse Number	Pn339	
P9	1	0	0	0	Rotation Number	Pn341	Pn343
					Pulse Number	Pn342	
P10	1	0	0	1	Rotation Number	Pn344	Pn346
					Pulse Number	Pn345	
P11	1	0	1	0	Rotation Number	Pn347	Pn349
					Pulse Number	Pn348	
P12	1	0	1	1	Rotation Number	Pn350	Pn352
					Pulse Number	Pn351	
P13	1	1	0	0	Rotation Number	Pn353	Pn355
					Pulse Number	Pn354	
P14	1	1	0	1	Rotation Number	Pn356	Pn358
					Pulse Number	Pn357	
P15	1	1	1	0	Rotation Number	Pn359	Pn361
					Pulse Number	Pn360	
P16	1	1	1	1	Rotation Number	Pn362	Pn364
					Pulse Number	Pn363	


For **internal positioning** mode there are two types of moves **incremental** move or **absolute** move, selectable by parameter **Pn316** as below.

Parameter Signal	Name	Setting	Description	Control Mode
★Pn316	Internal position command mode selection	0	Absolute mode	Pi
		1	Incremental mode	

**New setting will become effective after re-cycling the power.**

Example below shows the difference between absolute and incremental moves.


For two pulse commands of 10 pulse position pulse command and followed with another 20 pulse, the traveled positions will be different.



### PTRG. (Position Trigger).

Once any preset position is selected by input contacts **POS1~POS4** then require a trigger signal (**PTRG**) from the input contact, enable **PTRG** to start operation.

Diagram below shows an example for 4 different absolute encoders.



Note: Input contacts status "1" (ON) and "0" (OFF)

Please check section 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.


## PHOLD. (Position Hold)

The Position command can be inhibited (Held) at any time by input contact signal **PHOLD**.

Once PHOLD is initiated the motor will decelerate and stop.

As soon as the input contact **PTRG** is triggered again the original position command will be Completed.


Diagram below shows PHOLD function with incremental encoder.



## CLR ( Clear position command).

If the CLR input is activated when a position command is in process then the motor will stop immediately and the remaining positioning pulses will be cleared. Parameter Pn315 must be set to 1 or 2 as required ( refer to section 5-4-7).

Once the PTRG input contact is activated again then a new position command will be started according to the selection of input contacts POS1~POS4.



Note: Input contacts status "1" (ON) and "0" (OFF)

Please check section 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.


### 5-4-3 Electronic Gear

Electronic gear ratio parameter can be used to scale the command output pulse.

This would be useful in transmission applications where move distance per move command pulse has to be scaled due to mechanical requirements.

Diagram and notes below describe the electronic gear ratio effect.

Example of a transmission device and calculations that show the required number of pulses from a host controller to move the table by 10mm.



Calculations without Electronic Gear Ratio	Calculations with Electronic Gear Ratio
<p>1. One rotation of ball screw = Table move distance of 5mm.</p> <p>2. If the table is required to move 10mm, then Ball screw needs to rotate by <math>(10\text{mm} \div 5 \text{ mm/rev})= 2</math> Revs</p> <p>3. Command pulses required to cause <b>one</b> revolution:-            = Encoder ppr <math>\times</math> ( Internal multiplication factor).            = 2000 ppr <math>\times</math> 4 = 8000 pulses.</p> <p>4. So the Command pulses required to move 10mm (2 revs):-            = 8000 pulses <math>\times</math> 2 ( revs) = 16000 Pulses.</p> <p><b>Number of command pulses for an specific move distance can be calculated according to the formula below:</b>  <b>= Number of Ball Screw Revs <math>\times</math> (Encoder ppr <math>\times</math> 4).</b></p>	<p>For Calculating the number of pulses command required, Setting of Electronic gear ratio see next chapter.</p> <p>Electronic gear ratio can be set according to the required <b>move distance per move command pulse.</b></p> <p>For example:</p> <p>1. One Pulse command = Move distance of <math>1\mu\text{m}</math>.</p> <p>2. If the Motion Table needs to move 10mm, Then the required command pulses from a Host Controller is</p> <p>= <math>10\text{mm} \div 1\mu\text{m} / \text{Pulse} = 10000</math> Pulses.</p> <p><b>Once the move distance per pulse and the Electronic gear ratio is known then the required number of pulse command can be calculated.</b></p>

## Electronic Gear Ratio Calculation

Follow the Steps below:

### 1. Define the requirements of the positioning system

Establish the following:

- Move distance per one revolution of load shaft.
- Servo motor Encoder ppr (Pulse Per Revolution). (please refer to section 1-1-2 Servo Motor Standards).
- Motor / load Shaft deceleration ratio.

### 2. Move distance per one move command pulse.

Define the move distance caused by the transmission system as a result of, one move command pulse from the host controller.

Ex: When 1 Pulse Command move = 1μm

If the Host Controller gives a move command of 2000 pulses, the transmission device will move by: -  
 $2000\text{pulse} \times 1\mu\text{m/pulse} = 2\text{mm}$  (The Electronic Gear Ratio must be set correctly).

### 3. Calculate the Electronic Gear Ratio

Calculate the Electronic Gear Ratio according to the formula below:-

$\text{Electronic Gear Ratio} = \frac{\text{Encoder ppr ( Pulse Per Revolution) x 4}}{\text{Move distance per load shaft revolution} \div \text{Move distance per command Pulse}}$
--

If the deceleration ratio between motor and load shaft is  $\frac{n}{m}$

(m = Motor Rotating number , n= Load Shaft Rotating Value), Then the formula for Electronic Gear Ratio is:

$\text{Electronic Gear Ratio} = \frac{\text{Encoder ppr ( Pulse Per Revolution) x 4}}{\text{Move distance per load shaft revolution} \div \text{Move distance per command Pulse}} \times \frac{m}{n}$
---

#### Warning!

The calculated Electronic Gear Ratio must be according to the conditions below, otherwise the servo drive and motor will not function correctly.

$$\frac{1}{200} \leq \text{ElectroniceGearRatio} \leq 200$$



#### 4.Parameter Setting for Electronic Gear Ratio

Setting gear ratio Numerator and denominator parameters:

Numerator and denominator values of the calculated electronic gear ratio must be entered in the required parameters.

These two values have to be integer and with a value within the specified range in the table below.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn302	Numerator of Electronic Gear Ratio 1	1	X	1~50000	Pi/Pe
Pn303	Numerator of Electronic Gear Ratio 2	1	X	1~50000	Pi/Pe
Pn304	Numerator of Electronic Gear Ratio 3	1	X	1~50000	Pi/Pe
Pn305	Numerator of Electronic Gear Ratio 4	1	X	1~50000	Pi/Pe
★Pn306	Denominator of Electronic Gear Ratio	1	X	1~50000	Pi/Pe

***New setting will become effective after re-cycling the power.***

This device provides 4 selections of Numerator for Electronic Gear Ratio.

Input contacts **GN1** and **GN2** can be used to select the required Numerator for the Electronic Gear Ratio




According to the table below.

Input Contact GN2	Input Contact GN1	Numerator of Electronic Gear Ratio	Control Mode
0	0	Numerator of Electronic Gear Ratio 1 <b>Pn302</b>	Pi/Pe
0	1	Numerator of Electronic Gear Ratio 2 <b>Pn303</b>	
1	0	Numerator of Electronic Gear Ratio 3 <b>Pn304</b>	
1	1	Numerator of Electronic Gear Ratio 4 <b>Pn305</b>	

Note: Input contacts status "1" (ON) and "0" (OFF)

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

## Electronic Gear Ratio setting examples

Transmission System	Setting Process
<p style="text-align: center;"><b>Ball Screw</b></p>  <p>Pulse Value of 1 Rotating for Encoder=2000pulse/rev</p> <p>Distance of 1 Rotating for Ball Screw = 5mm</p>	<ol style="list-style-type: none"> <li><b>1. Main positioning specifications:</b> <ol style="list-style-type: none"> <li>a) Load Shaft(Ball Screw) pitch move distance per revolution= 5mm</li> <li>b) Motor Encoder ppr ( Pulse per revolution) = 2000pulses</li> </ol> </li> <li><b>2. Move distance per one pulse of move Command.</b> Moving Distance of 1 Pulse Command =1μm</li> <li><b>3. Calculation of the Electronic Gear Ratio:</b>  <math display="block">\text{ElectronicGear Ratio} = \frac{2000\text{pulse/ rev} \times 4}{5\text{mm/ rev} \div 1\mu\text{m/ pulse}} = \frac{8000}{5000}</math> </li> <li><b>4. Set the parameter of Electronic Gear Ratio:</b>                      Numerator of Electronic Gear Ratio = 8000                      Denominator of Electronic Gear Ratio = 5000                 </li> </ol>
<p style="text-align: center;"><b>Mechanical Disc</b></p>  <p>Pulse Value of Rotating for Encoder = 2500pulse/rev</p> <p>Deceleration Ratio-1/5</p>	<ol style="list-style-type: none"> <li><b>1. Main positioning specifications:</b> <ol style="list-style-type: none"> <li>a) Deceleration Ratio=1/5</li> <li>b) Load Shaft(Mechanical Disc)Move Value per one revolution=360°</li> </ol>                     Motor Encoder ppr ( Pulse per revolution)= 2500 pulses                 </li> <li><b>2. Move distance per one pulse of move Command.</b> Distance for 1Pulse Command =0.1°</li> <li><b>3. Calculation of the Electronic Gear Ratio:</b>  <math display="block">\text{Electronic Gear Ratio} = \frac{2500\text{pulse/ rev} \times 4}{360^\circ \div 0.1^\circ / \text{pulse}} \times \frac{5}{1} = \frac{50000}{3600}</math> </li> <li><b>4. Set the parameter of Electronic Gear Ratio:</b>                      Numerator of Electronic Gear Ratio = 50000                      Denominator of Electronic Gear Ratio = 3600                 </li> </ol>
<p style="text-align: center;"><b>Transmission Belt</b></p>  <p>Pulse Value of 1 Rotating for Encoder = 8192pulse/rev</p> <p>Deceleration Ratio=1/8</p> <p>Diameter of Idler=100mm</p>	<ol style="list-style-type: none"> <li><b>1. Main positioning specifications:</b> <ol style="list-style-type: none"> <li>a) Deceleration Ratio=1/8</li> <li>b) Load Shaft ( Idler) Move Value per revolution. = 3.14 × 100mm = 314mm</li> <li>c) Motor encoder ppr ( Pulse Per Revolution) = 8192pulse</li> </ol> </li> <li><b>2. Move distance per pulse of move Command.</b> Distance for 1Pulse Command =10μm</li> <li><b>3. Calculation the Electronic Gear Ratio:</b>  <math display="block">\text{Electronic Gear Ratio} = \frac{8192\text{pulse/ rev} \times 4}{314\text{mm} \div 10\mu\text{m/ pulse}} \times \frac{8}{1} = \frac{262144}{31400}</math> </li> <li><b>4. Set the parameter of Electronic Gear Ratio:</b>                      Reduction of the fraction to make the Numerator and Denominator less than 50000.                      Numerator of Electronic Gear Ratio = 32768                      Denominator of Electronic Gear Ratio = 3925                 </li> </ol>

### 5-4-4 Smooth Acceleration

Using the **One Time Smooth Acceleration/Deceleration of Position Command**


It smoothes the position pulse command frequency.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
★Pn313	Position command Accel/Decel Time Constant	0	msec	0~10000	Pi/Pe

***New setting will become effective after re-cycling the power.***

#### **Time Constant of One Time Smooth Acceleration/Deceleration of Position Command:**

The Time in which The Position Pulse Frequency increases (one time) from zero to 63.2% of Position Pulse Command Frequency.



Setting Examples:

(1) To achieve 95% of Position Pulse Command Frequency Output in 30msec:

$$Pn313 = \frac{30(\text{msec})}{-\ln(1 - 95\%)} = 10(\text{msec})$$

(2) To achieve 75% of Position Pulse Command Frequency Output in 30msec:


$$Pn313 = \frac{30(\text{msec})}{-\ln(1 - 75\%)} = 22(\text{msec})$$

Note: Above curve is a logarithmic

ln = Natural log.

### 5-4-5 Definition of Direction

In position mode, user can use Pn314 (Position Command Direction Definition) to define motor rotation direction. The setting is showed as follow:

Parameter Signal	Name	Setting	Description	Control Mode
★Pn314	Definition of position command direction (from motor load end) 	0	Clockwise (CW)	Pi Pe
		1	Counter Clockwise (CCW)	

*New setting will become effective after re-cycling the power.*

### 5-4-6 Gain Adjustment

The table below shows the parameters for adjusting the position loop.

Two position loop gains can be selected from input contact terminals according to table below.


For selection methods refer to section. 5-3-11.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn310	Position Loop Gain1	40	1/s	1~450	Pe/Pi
Pn311	Position Loop Gain 2	40	1/s	1~450	Pe/Pi
Pn312	Position Feed-Forward Gain	0	%	0~100	Pe/Pi
Cn033	Speed Feed-Forward Smooth Filter	40	Hz	0~1000	Pe/Pi

Diagram below shows the position controller. Adjust a higher gain value can reduce response time.

Position Feed-Forward Gain can also be used to shorten the positioning time.

refer to section 5-5 for Position Loop Gain Adjustment methods.



### 5-4-7 Clear the Pulse Offset

In position control mode, **parameter Pn315** (Pulse Error clear mode) has three modes can be select.

**CLR** input contact is used to clear the pulse error as required according to the list below.

Parameter	Name	Setting	Description	Control Mode
Pn315	Pulse Error Clear Mode	0	When Input <b>CLR</b> contact, clears the pulse error value.	Pe
		1	When Input <b>CLR</b> contact to cancels the position command, Stops the motor rotating, the pulse error value is cleared and mechanical Home signal is reset.	Pi Pe
		2	When Input <b>CLR</b> contact to cancels the position command, stops the motor rotating and the pulse error value is cleared.	Pi

Note: Input contacts status "1" (ON) and "0" (OFF)


Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.




### 5-4-8 Original Home

Home routine is used to find and set a reference point for correct positioning.

To set a HOME reference position, one of input contacts ORG (external sensor input), CCWL, or CWL can be used.

An encoder Z phase (marker pulse) can also be used as home reference and can be search by CW or CCW direction. Following Home routine selections are available for setting parameter Pn 365.0.

Parameter	Name	Setting	Description	Control Mode
Pn365.0 	On activation of Home input contact, It sets the search direction and Home reference. (Setting for home routine)	0	Once the home routine is activated, motor will search for Home Position switch in 1 <sup>st</sup> preset speed in <b>CCW</b> direction. Input contacts CCWL or CWL can be used as the Home Reference Switch. Once Home reference switch is detected and complete, input contacts <b>CCWL</b> and <b>CWL</b> will act as limits input contact again. <b>Note:</b> When using this function, 1 or 2 setting of <b>Pn365.1</b> is not allowable. <b>Cn002.1 (CCWL &amp; CWL Input terminal function) must to set as 0.</b>	Pi/Pe
		1	Once the home routine is activated, motor will search for Home Position switch in 1 <sup>st</sup> preset speed in <b>CW</b> direction. Input contacts CCWL or CWL can be used as the Home Reference Switch. Once Home reference switch is detected and complete, input contacts <b>CCWL</b> and <b>CWL</b> will act as limits input contact again. <b>Note:</b> When using this function, 1 or 2 setting of <b>Pn365.1</b> is not allowable. <b>Cn002.1 (CCWL &amp; CWL Input terminal function) must to set as 0.</b>	
		2	Once the home routine is activated , motor will search for Home Position switch in 1 <sup>st</sup> preset speed in <b>CCW direction</b> and sets the input contact ORG (external sensor input) as a Home reference when ORG contact is activated.  If <b>Pn365.1=2</b> , it will directly find the closest Rising-Edge of <b>ORG</b> to be the Home position (without a need for Home reference),then it stops in accordance with <b>Pn365.3</b> setting.	
		3	Once the home routine is activated , motor will search for Home Position switch in 1 <sup>st</sup> preset speed in <b>CW direction</b> and sets the input contact ORG (external sensor input) as a Home reference when ORG contact is activated.  If <b>Pn365.1=2</b> , it will directly find the closest Rising-Edge of <b>ORG</b> to be the Home position (without a need for Home reference),then it stops in accordance with <b>Pn365.3</b> setting.	
		4	Once the home routine is activated , motor will search for Home position in 1st preset speed in <b>CCW</b> direction and sets the Home reference Servo drive start to find the Home position of the nearest Z phase. (No need for Home reference) When using this function, set <b>Pn365.1=2</b> . After finished setting of <b>Z</b> Phase to the Home position, for the stop method refer to the setting of <b>Pn365.3</b> .	
		5	Once the home routine is activated , motor will search for Home position in 1st preset speed in <b>CW</b> direction and sets the Home reference Servo drive start to find the Home position of the nearest Z phase. (No need for Home reference) When using this function, set <b>Pn365.1=2</b> . After finished setting of <b>Z</b> Phase to the Home position, for the stop method refer to the setting of <b>Pn365.3</b> .	

Parameter	Name	Setting	Description	Control Mode
Pn365.1 	Once Reference Home switch or Signal, is found set search method for the Home position.	0	Once the Home Reference switch or signal is detected, motor <b>reverses direction</b> in 2 <sup>nd</sup> speed to find the nearest <b>Z</b> Phase pulse and sets this as the Home position, then stops in accordance with <b>Pn365.3</b> setting method.	Pi/Pe
		1	Once the Home Reference switch or signal is detected, motor <b>Continues in its direction</b> in 2 <sup>nd</sup> speed to find the nearest <b>Z</b> Phase pulse and sets this as the Home position, then stops in accordance with <b>Pn365.3</b> setting method.	
		2	When <b>Pn365.0=2</b> or <b>3</b> , it finds the rising edge of ORG to be the Home position, then stops in accordance with <b>Pn365.3</b> ; When <b>Pn365.0=4</b> or <b>5</b> , it finds <b>Z</b> Phase pulse to be the Home, then stops in accordance with <b>Pn365.3</b> .	
Pn365.2 	Setting of Home Routine Start method	0	Homing routine is <b>Disabled</b> .	Pi/Pe
		1	On power up and activation of <b>Servo on</b> the home routine is started automatically. This method is useful for applications that do not require repeated home routines. No external home reference switch is required.	
		2	Use <b>SHOME</b> input contact to start a home routine. In position mode, <b>SHOME</b> can be used to start a home routine at any moment.	
Pn365.3 	Stopping mode after finding Home signal.	0	After detecting the Home signal, it <b>sets</b> this position to be the Home reference ( <b>Un-14</b> encoder feed back rotating number and <b>Un-15</b> encoder feed back pulse number are all 0), motor decelerates and stops. Then it reverses direction in 2 <sup>nd</sup> speed to detect the Home Position again then it decelerates and stops..	Pi/Pe
		1	After detecting the Home signal, it <b>sets</b> this position to be the Home reference ( <b>Un-14</b> encoder feed back rotating number and <b>Un-15</b> encoder feed back pulse number are all 0), motor decelerates and stops.	

### Home Mode selection table

Pn365.0 pn 365.1 selections can be made for each application as required according to the table below:-

Pn365.0 \ Pn365.1	0	1	2	3	4	5
0	●	●	●	●	×	×
1	×	×	●	●	×	×
2	×	×	●	●	●	●

● HOME routine available    × HOME routine not available.

## Additional Home routine parameters

Home search speed parameters 1<sup>st</sup> (Fast) and 2<sup>nd</sup> (Slow) speeds are set according to table below:

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn366	1 <sup>st</sup> preset high speed of HOME	100	rpm	0~2000	Pi/Pe
Pn367	2 <sup>nd</sup> preset low speed of HOME	50	rpm	0~500	Pi/Pe

Parameters Pn368 and Pn 369 provide Home position offset feature for applications where the machine mechanical home position is a different position to the detected home position.

This offset can be achieved by setting the two parameters below.


Once the detected home position is found in accordance with **Pn365** (Home routine mode), then it will search by number of revolutions and pulses set in Pn368 and Pn 369 to find the new off set Home position.

Parameter Signal	Name	Default	Unit	Setting Range	Control Mode
Pn368	HOME Position Offset. (No of Revolutions)	0	rev	-30000~30000	Pi/Pe
Pn369	HOME position Bias Pulse value (No of pulses)	0	pulse	-32767~32767	Pi/Pe



## Home routine Timing Chart

During the Home routine if the SON (Servo On) is not activated or any alarm happens, Home routine is stopped and Home Complete output contact is reset (Cleared).



Note: Input contacts status "1" (ON) and "0" (OFF)

Please check 5-6-1 to set the required high /Low signal levels ( PNP/NPN) selection.

## Home Routine Speed /Position Timing Charts

Following Sections Show the Speed/Position Timing charts according to Pn 365.0 and Pn365.1 selections.

Pn365.1	Pn365.0	0	1	2	3	4	5
0		(1)	(2)	(1)	(2)	✗	✗
1		✗	✗	(3)	(4)	✗	✗
2		✗	✗	(5)	(6)	(7)	(8)

✗ No Home routine


(1)

**Pn365.0=0 or 2** (After starting HOME routine, run **CCW** in 1<sup>st</sup> preset high speed for HOME Reference (CCWL, CWL or ORG)).

**Pn365.1=0**(After finding HOME Reference, **reverse direction** in 2<sup>nd</sup> preset low speed to search for the nearest **Z** Phase pulse to be set as the HOME position).

**Pn365.2=2**(Input Contact SHOME to Start Home routine).

**Pn365.3=0**(Reverse search for HOME position).




(2)

**Pn365.0=1 or 3.** After starting the HOME routine, run **CW** in 1<sup>st</sup> preset high speed to search for HOME Reference (**CWL, CCWL or ORG**).

**Pn365.1=0.** After finding HOME Reference, **reverse direction** in 2<sup>nd</sup> preset low speed to search for the nearest **Z** Phase pulse to be set as the HOME position.

**Pn365.2=2.** Input Contact SHOME Starts the Home routine.

**Pn365.3=0.** Reverse search for HOME position.




(3)

**Pn365.0=2.** After starting HOME routine, run **CCW** in 1<sup>st</sup> preset high speed to search for HOME Reference (**ORG**).

**Pn365.1=1.** After finding HOME Reference, **continues in the same direction** in 2<sup>nd</sup> preset low speed to find the nearest **Z** Phase to be set as the HOME position.

**Pn365.2=2** Input Contact **SHOME** Starts the HOME routine.

**Pn365.3=0** Reverse search for HOME position




(4)

**Pn365.0=3**(After Starting HOME routine, run **CW** in 1<sup>st</sup> preset high speed to search for HOME Reference.( **ORG**)

**Pn365.1=1**. After finding HOME Reference, **continues in the same direction** in 2<sup>nd</sup> preset low speed to find the nearest **Z** Phase to be set as the HOME position.

**Pn365.2=2** Input Contact **SHOME** Starts the HOME routine.

**Pn365.3=0** Reverse search for HOME position




(5)

**Pn365.0=2.** After Starting HOME routine, run **CCW** in 1<sup>st</sup> preset high speed to search for HOME Reference.( **ORG**).

**Pn365.1=2.** After Finding the HOME Reference, the Rising Edge of **ORG** sets the HOME Position.

**Pn365.2=2** Input Contact **SHOME** Starts the HOME routine.

**Pn365.3=0** Reverse search for HOME position




(6)

**Pn365.0=3.** After Starting HOME routine, run **CW** in 1<sup>st</sup> preset high speed to search for HOME Reference.( **ORG**).

**Pn365.1=2.** After Finding the HOME Reference, the Rising Edge of **ORG** sets the HOME Position.

**Pn365.2=2** Input Contact **SHOME** Starts the HOME routine.

**Pn365.3=0** Reverse search for HOME position




(7)

**Pn365.0=4.** After Starting HOME routine, run **CCW** in 1<sup>st</sup> preset high speed to search for the nearest Z phase pulse.

**Pn365.1=2.** After Finding the Z phase pulse, set this position as the HOME position.

**Pn365.2=2** Input Contact **SHOME** Starts the HOME routine.

**Pn365.3=0** Reverse search for HOME position




(8)

**Pn365.0=5.** After Starting HOME routine, run **CW** in 1<sup>st</sup> preset high speed to search for the nearest Z phase pulse.

**Pn365.1=2.** After Finding the Z phase pulse, set this position as the HOME position.

**Pn365.2=2** Input Contact **SHOME** Starts the HOME routine.

**Pn365.3=0** Reverse search for HOME position




### 5-4-9 Other Position Function

#### In position (Position Complete)

As long as the position **error value** (counts) is less than the pulse counts set in **Pn307** (Position Complete value) then **INP output contact** will be activated.

Parameter	Name	Default	Unit	Setting Range	Control Mode
Pn307	Position Complete value	10	pulse	0~50000	Pi/Pe



Note: Input contacts status “1” (ON) and “0” (OFF)

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

#### Position error alarm

When the Position error value is greater than the preset pulse value of **Pn308** (Positive position error level) or **Pn309** (Negative position error level) this will generate **AL-11 (Position error)** signal.

Parameter	Name	Default	Unit	Setting Range	Control Mode
Pn308	Positive position error level	50000	pulse	0~50000	Pi/Pe
Pn309	Negative position error level	50000	pulse	0~50000	Pi/Pe

## 5-5 Gain Adjustment

The Servo controller provides 3 control loops as diagram shown below:

Control methods are: **Current** Control, **Speed** Control and **Position** Control.




Diagram above shows the three control loops.

Current ( Inner loop), Speed ( middle loop) and position (outer loop).

Theoretically, the bandwidth of inner control loop must be higher than the bandwidth of the outer control loop, otherwise, the whole control system will become unstable, and cause vibration or abnormal response.

The relationship between the **band width** for these three control loops is as follows:

**Current Loop (Inner) >Speed Loop (Middle )>Position Loop(outer).**

The **default current control bandwidth** has already been set for optimum response, So **Only speed and position control loop gains** may be adjusted.

Table below shows the Gain adjustment parameters for the three control loops.

Parameter	Name	Default	Unit	Setting Range	Control Mode
Sn211	Speed Loop Gain 1	40	Hz	10~450	Pe/Pi/S
Sn212	Speed Loop Integration Time Constant 1	100	x0.2 msec	1~500	Pe/Pi/S
Sn213	Speed Loop Gain 2	40	Hz	10~450	Pe/Pi/S
Sn214	Speed Loop Integration Time Constant 2	100	x0.2 msec	1~500	Pe/Pi/S
Pn310	Position Loop Gain 1	40	1/s	1~450	Pe/Pi
Pn311	Position Loop Gain 2	40	1/s	1~450	Pe/Pi
Pn312	Position Loop Feed-Forward Gain	0	%	0~100	Pe/Pi
Cn025	Load Inertia Ratio	40	x0.1	0~1000	Pe/Pi/S



## Speed Loop Gain

Speed Loop Gain has a direct effect on the response Bandwidth of Speed Control Loop.

Under the condition of no vibration or noise, when higher is the Speed Loop Gain Value is setting speed response is becoming faster.

If **Cn025** (Load Inertia Ratio) is correctly set then,

**Speed Loop Bandwidth = Sn211** (Speed Loop Gain1) or **Sn213** (Speed Loop Gain2).

Load Inertia Ratio Formula is as below:

$$\text{Load inertia rating} = \frac{\text{Load inertia transforming to motor axis } (J_L)}{\text{Inertia of servo motor rotor } (J_M)} \times 100\%$$

## Speed Loop Integration Time Constant

Integral element in Speed Control Loop eliminates the steady state error.

Under the condition of no vibration or noise, reducing the speed loop Integral Time Constant can enhance system rigidity. If the Load Inertia Ratio is very high or the system has vibration factors, ensure that the Speed Loop Integral Time Constant is also high enough, otherwise the mechanical system would produce resonance easily.

Integral Time Constant for Speed Loop can be set using the formula below:

$$\text{Sn212(Integral Time constant 1 of Speed Loop)} \geq 5 \times \frac{1}{2\pi \times \text{Sn211(Speed Loop Gain 1)}}$$

Setting Example:

Assume: **Cn025** (Load Inertia Ratio) is correctly set, If target Speed Loop Bandwidth 100Hz, set **Sn211**(Speed Loop Gain 1)=100(Hz) then

$$\text{Sn212(Integral Time Constant 1 of Speed Loop)} \geq 5 \times \frac{1}{2\pi \times 100} = 40 (\times 0.2\text{msec})$$

## Position Loop Gain

Position Loop Gain has a direct effect on the response speed of Position Loop.

Under the condition that there is no vibration or noise from servo motor, increasing the Position Loop Gain Value can enhance the response speed and hence reduce the positioning time.

## Position Loop Feed-Forward Gain

Using Position Loop Feed-Forward Gain can enhance the response speed.

If the Feed-Forward Gain value is setting too high, overshooting could occur and cause the **INP** (In Position) output contact to switch ON and OFF repeatedly.

SO monitor Speed Curve and **INP** (In Position Signal) at the same time then increase Feed-Forward Value slowly.

If Position Loop Gain is too high, Feed-Forward function will be insignificant.

## Quick Parameters for Gain adjustment

Quick Gain adjust parameters are available for setting manually.

The related Gain Adjust parameters are listed in the Quick-Parameter leaflet for convenient reference.

Quick adjust parameters once altered are saved and become effective **immediately**,


without pressing the Enter-Key. The table below shows the Gain Adjust Quick-Parameters.

Parameter	Name	Default	Unit	Setting Range	Control Mode
◆qn401	Speed Loop Gain 1	40	Hz	10~450	Pe/Pi/S
◆qn402	Integral Time Constant 1 of Speed Loop	100	x0.2 msec	1~500	Pe/Pi/S
◆qn403	Speed Loop Gain 2	40	Hz	10~450	Pe/Pi/S
◆qn404	Integral Time Constant 2 of Speed Loop	100	x0.2 msec	1~500	Pe/Pi/S
◆qn405	Position Loop Gain 1	40	1/s	1~450	Pe/Pi
◆qn406	Position Loop Gain 2	40	1/s	1~450	Pe/Pi
◆qn407	Position Loop Feed-Forward Gain	0	%	0~100	Pe/Pi

Become effective immediately without pressing Enter-Key

### 5-5-1 Automatic Adjusting

This device provides ON-LINE Auto tuning, which can quickly and precisely measure Load Inertia and adjust the Gain automatically. Setting is according to the table below:

Parameter	Name	Setting	Description	Control Mode
Cn002.2 	Auto tuning	0	Auto tuning Disabled	Pe/Pi/S
		1	Enable Auto tuning	

When **Cn002.2** is set to **0** (Auto tuning Disabled), following Gain adjust parameters must be set.

Parameter Signal	Name
Cn002.2	Auto tuning
Sn211	Speed Loop Gain 1
Sn212	Speed-loop Integral time constant 1
Sn213	Speed loop Gain 2
Sn214	Speed loop Integral time constant 2
Pn310	Position Loop Gain 1
Pn311	Position Loop Gain 2
Pn312	Position Loop Feed-Forward Gain

When **Cn002.2** is set to **1** auto tuning is enabled and the Servo controller will adjust the Servo Gain in accordance with **Cn026** (Rigidity Setting) and the measured Load Inertia Ratio by monitor parameter Un-19 (Load Inertia Ratio), when the Load Inertia Ratio is becomes stable,

Then set **0** in **Cn002.2** to cancel Auto tuning. At this moment, servo controller will record the measured Load Inertia Ratio into **Cn025** (Load Inertia Ratio).

If servo drive is used in a applications where there is no significant load variations, then monitor **Un-19** (Load Inertia Ratio) if this is stable then it is recommended that Auto tuning is not used.

### **Apply conditions of Auto tuning**

The Servo drive provides Auto tuning and uses an advanced control technique “ON-LINE” to measure the Load Inertia Ratio to control the system to achieve default speed or Position Response Bandwidth.

System must comply with the conditions below, so that the Auto tuning can operate normally.

- (1) The timing from stop to 2000rpm needs be less than 1 second.
- (2) Motor speed is larger than 200rpm.
- (3) Load Inertia needs be 100 times less than the inertia of the motor.
- (4) External force or the variation of inertia ratio can not be excessive.


### **Rigidity Setting**

When Auto tuning is used, set the Rigidity Level depending on the various Gain settings for applications such as those listed below:

Rigidity Setting Cn026	Position Loop Gain Pn310 [1/s]	Speed Loop Gain Sn211 [Hz]	Speed-loop Integral time constant 1 Sn212 [x0.2msec]	Mechanical Rigidity	Application
1	15	15	300	<b>Low</b>	Machines driven by timing Belt, Chain or Gear: Large Moving Table, Conveyor Belt.
2	20	20	225		
3	30	30	150		
4	40	40	100	<b>Middle</b>	The machines driven by Ballscrew through decelerator: Ordinary machines, Mechanics arms, robot arms, conveyor.
5	60	60	75		
6	85	85	50		
7	120	120	40		
8	160	160	30		
9	200	200	25	<b>High</b>	The machines driven by Ballscrew: High precision Machines, Metal engraving Machine, Insertion Machine and IC inspection Machine.
A	250	250	20		

## Process for Auto tuning

The Diagram below show the process for Auto tuning.



Note: After Auto tuning is complete Set 0 in Cn002.2, otherwise it will not record the present measured Load Inertia Ratio.

If the power is cut off during Auto tuning then when the power is established, Servo controller will use the previously recorded setting of Load Inertia Ratio which is stored in parameter Cn025.

## 5-5-2 Manual Adjusting

Manual Gain adjustment is made available for applications when auto tune is not providing a good and stable system response, Or a system where there is no significant load variations and the auto tune is not used.

### **Manual Gain Adjustment in Speed control Mode**

**Step 1: Set Rigidity level** in parameter Cn 26 (See section 5-5-1 for the selection table) and Cn25.

**Step 2:** If the Servo system includes a host controller which is used for positioning control, then it's **position loop Gain** should be set lower, relative to the servo drive Gain.

**Step 3: Adjusting Speed Loop Gain 1 (Sn211):**

- a) Increase Sn212 (Integral Time Constant 1of Speed Loop). Set a higher value than default or the set value when auto tune was unsuccessful.
- b) Increase the Speed Loop Gain (Sn211) until there is no vibration or noise.
- c) Then decrease the Speed Loop Gain (Sn211) slowly and increase Position Loop Gain of Host Controller until there is no vibration or noise.

**Step 4: Adjusting Speed Loop Integral Time Constant 1 (Sn212):**

Set the Integral Time Constant of Speed Loop for minimum time setting that without causing mechanical vibration.

**Step 5:** Finally, Slowly adjust the Speed Loop Gain, Position Loop Gain of Host Controller and Integral Time Constant of Speed Loop until the servo system provides the best response.

### **Manual Gain Adjustment in Position Control mode**

**Step 1: Set Rigidity level in parameter Cn 26** (See section 5-5-1 for the selection table) for the correct **Load Inertia Ratio**.

**Step 2: Decrease Position Loop Gain 1 (Pn 310).**

Set a lower value than default or the set value when auto tune was unsuccessful.

Set a relatively higher value in Sn212 (Integral Time Constant 1 of Speed Loop).

**Step 3: Adjust Speed Loop Gain 1(Sn211).**

Increase the Speed Loop Gain until there is no vibration or noise.

**Step 4: Adjusting Position Loop Gain 1 (Pn310).**

Slowly decrease the Speed Loop Gain again, then increase the Position Loop Gain until there is no vibration or noise.

**Step 5: Adjusting Speed Loop Integral Time Constant 1 (Sn212).**

Set the Integral Time Constant of Speed Loop for a minimum time without causing mechanical vibration.

**Step 6:** Finally, slowly adjusting the Speed Loop Gain, Position Loop Gain and the Integral Time Constant of Speed Loop until the servo system provides the best response.

### 5-5-3 Improving Resonance

The Servo drive provides the function of Gain Switching and Position Loop Feed-Forward Gain to improve system response.

Note: Both of these features must be used correctly to improve system response, otherwise the response will become worse. Refer to the description below:

#### Gain Switch

Following Gain Switching features are provided:-

- a) Speed Loop Gain PI/P Switching
- b) 2-stage Gain Switching.

Purposes list:

- (1) To restrict overshoot during acceleration/deceleration in speed control.
- (2) Reducing the in position oscillations and providing shorter settling time in position control.
- (3) Decrease the noise caused when using Servo Lock.

For further details refer to section **5-3-11**.

#### Position Loop Feed-Forward Gain

Position Loop Feed-Forward Gain can be used to reduce the error result from position control and improve the response speed.

Position loop Feed forward gain and position loop gain should be matched with. If adjusting to higher position loop gain, the feed forward gain can be ignored. Oppositly, if the loop gain value is setting for a relatively low level, adjust position loop feed forward gain will improve system response time obviously.

The adjustment steps are as follows:

**Step 1:** Refer to the procedures in sections **5-5-1~5-5-2** to adjust Speed and Position Gain.

**Step 2:** Increase **Pn312**(Position Feed-Forward Gain) slowly, and observe the **INP** ( Output Signal of In Position) at the same time and INP output should be activated faster.


**Note:** The Position Loop Feed-Forward Gain can not be set too high, otherwise it will cause speed overshooting and **INP** (In Position output signal) will be switching On/Off repeatedly.

## 5-6 Other Functions


### 5-6-1 Programmable I/O Functions

#### Digital Inputs.

There are 13 DI (Digital Inputs) contacts and 4 DO (Digital Outputs) contacts which are programmable as listed below:-

Parameter	Name	Setting	Description		Control Mode
★Hn501.0 ★Hn501.1 	<b>DI-1</b> Digital Input 1 programmable Functions		Signal	Contact Function	ALL
		01	<b>SON</b>	Servo On	
		02	<b>ALRS</b>	Alarm Reset	
		03	<b>PCNT</b>	PI/P Switching	
		04	<b>CCWL</b>	CCW Limit	
		05	<b>CWL</b>	CW Limit	
		06	<b>TLMT</b>	External Torque Limit	
		07	<b>CLR</b>	Clear Pulse Error Value	
		08	<b>LOK</b>	Servo Lock	
		09	<b>EMC</b>	Emergency Stop	
		0A	<b>SPD1</b>	Speed 1	
		0B	<b>SPD2</b>	Speed 2	
		0C	<b>MDC</b>	Control Mode Switch	
		0D	<b>INH</b>	Position Command Inhibit	
		0E	<b>SPDINV</b>	Speed Inverse	
		0F	<b>G-SEL</b>	Gain Select	
		10	<b>GN1</b>	Electronic Gear Ratio Numerator 1	
		11	<b>GN2</b>	Electronic Gear Ratio Numerator 2	
		12	<b>PTRG</b>	Position Trigger	
		13	<b>PHOLD</b>	Position Hold	
14	<b>SHOME</b>	Start Home			
15	<b>ORG</b>	Home Position Reference (Origin)			
16	<b>POS1</b>	Internal Position select 1			
17	<b>POS2</b>	Internal Position select 2			
18	<b>POS3</b>	Internal Position select 3			
19	<b>POS4</b>	Internal Position select 4			
1A	<b>TRQINV</b>	Torque Inverse			
1B	<b>RS1</b>	Torque CW Selecting			
1C	<b>RS2</b>	Torque CCW Selecting			

*New setting will become effective after re-cycling the power.*

Parameter Signal	Name	Setting	Description	Control Mode
★Hn501.2 	<b>DI-1</b> <b>Logic State</b> <b>NO/NC Selection</b>	0	Input contact state. NO (Normally Open). Connecting (IG24) to inputs, enables the selected function.	ALL
		1	Input contact state. NC (Normally Closed). Disconnecting (IG24) from inputs, enables the selected function.	

*New setting will become effective after re-cycling the power.*

Digital Inputs 2 to 13 (Hn 502 to Hn 513). Are programmable and the logic state NO/NC can also be selected same as that shown for digital input 1. See Hn501.





Parameter	Name	Description	Control Mode
★Hn502	DI-2 Programmable	Refer to <b>Hn501</b> for programmable options.	ALL
★Hn503	DI-3 Programmable		
★Hn504	DI-4 Programmable		
★Hn505	DI-5 Programmable		
★Hn506	DI-6 Programmable		
★Hn507	DI-7 Programmable		
★Hn508	DI-8 Programmable		
★Hn509	DI-9 Programmable		
★Hn510	DI-10 Programmable		
★Hn511	DI-11 Programmable		
★Hn512	DI-12 Programmable		
★Hn513	DI-13 Programmable		

**Warning!** If any of programmable Inputs of DI-1 ~ DI-13 are set for the same type of function then the logic state selection ( NO or NC selection) for these inputs must be the same type. Otherwise an Alarm will be displayed. AL-07 (**Multi-function contact setting error**).

## Digital Outputs.

There are 4 programmable Digital Outputs according to the table below:

Parameter	Name	Setting	Description		Control Mode
★Hn514.0 ★Hn514.1 	DO-1 Logic state		Code	Contactors functions	ALL
		01	<b>RDY</b>	Servo Ready	
		02	<b>ALM</b>	Alarm	
		03	<b>ZS</b>	Zero Speed	
		04	<b>BI</b>	Brake Signal	
		05	<b>INS</b>	In Speed	
		06	<b>INP</b>	In Position	
		07	<b>HOME</b>	HOME	
★Hn514.2 	DO-1	0	Close, when the output is activated.		ALL
		1	Open, when the output is activated..		

Parameter	Name	Description	Control Mode
★Hn515	DO-2 Programmable	Refer to Hn514 for programmable options.	ALL
★Hn516	DO-3 Programmable		
★Hn517	DO-4 Programmable		

***New setting will become effective after re-cycling the power.***

### Warning!

When programmable DO-1 ~ DO-4 are set for the same type of function alarm will be displayed.

AL-07 (**Multi-function contact setting error**).

### 5-6-2 Switch for the Control Mode

Set one of the programmable input terminals to MDC (Control mode) selection.

The input then will select the preset control mode, which is set by Parameter Cn001.

**Selections are listed below:**



Parameter	Name	Setting	Description		Control Mode
★Cn001	Control Mode Selection		<b>MDC Input off</b>	<b>MDC Input On</b>	ALL
		3	Position Control (External Pulse Command)	Speed Control	
		4	Speed Control	Torque Control	
		5	Position Control (External Pulse Command)	Torque Control	

***New setting will become effective after re-cycling the power.***

Please check 5-6-1 to setting the input contact required high /Low signal levels (PNP/NPN selection).

### 5-6-3 Auxiliary Functions

Function of Input Contacts SON, CCWL and CWL can be set according to the list below:-

Parameter	Name	Setting	Description	Control Mode
★Cn002.0 	<b>SON</b> (Servo ON )	0	Use input contact <b>SON</b> to switch Servo On.	ALL
		1	Servo on with Power on. <b>SON</b> input contact not required.	
Cn002.1 	<b>CCWL and CWL</b> (Counter Clockwise & Clockwise Limits)	0	<b>CCWL and CWL(external limits) are effective.</b> CCW and CW rotation is inhibited by CCWL&CWL.	ALL
		1	<b>CCWL and CWL(external limits) are ineffective.</b> CCW&CW rotation is not limited by CCWL&CWL.	

***New setting will become effective after re-cycling the power.***

### 5-6-4 Brake Mode

Brake function for servo motor and the external mechanical brake if it is used can be set according to the table below. Set the brake mode as required for Servo off, Emergency Stop and CCW/CW rotation inhibit functions.

Parameter	Name	Setting	Description		Control Mode
			Dynamic Brake	Mechanical Brake	
Cn008	Brake Modes	0	Disable	Disable	ALL
		1	Disable	Enable	
		2	Enable	Disable	
		3	Enable	Enable	

**Note!**

When the CCW/CW Drive Inhibit occur, the Cn009 has the higher priority than Cn008.

**Example:**

If Cn008 is set to 0 or 1 which means (no Dynamic Brake).

BUT Cn009= 1 (with Dynamic Brake), then the dynamic brake will be effective( enabled).


### 5-6-5 Timing Diagram of Mechanical Brake

In applications with vertical loading, if the power is turned off, to prevent the load from falling due to gravity, a servo motor with electro-mechanical brake can be used.

This servo drive provides a brake output (BI) which can be used for controlling the external brake.

Timing of brake output signal can be set by parameter Cn003 (Output Time for electro-mechanical Brake).

### Typical Circuit Diagram



### Timing for Brake output signal

Set the required time for the operation of brake output signal (BI) according to the following. BI output can be used to control the function of an external electro-mechanical brake.

Parameter	Name	Default	Default	Setting Range	Control Mode
Cn003	Output time setting for Mechanical Brake Signal	0	msec	-2000~2000	ALL

#### Note!

To use brake output signal set Cn008 (Brake mode) to selections 1 or 3 as required.

When the servo system has vertical loading, please set Cn003 to a **Positive** Number.

For definition of a time value with a positive or a negative sign refer to the following notes and timing diagrams.

#### (1) Cn003 set to a time value with a Positive sign.

AS soon as the input contact SON is switched on, Servo on is activated at the same time, then after a time delay set by parameter Cn003, Output Contact BI is switched on. (Signal to release the brake).

When SON input contact is switched off, BI output contact is also switched off (Signal to operate the brake).


Then after a time delay set by parameter Cn003, Servo ON is de-activated.

#### (2) Cn003 set to a time value with a Negative sign.

AS soon as the input contact SON is switched on, Output Contact BI is switched on at the same time. (Signal to release the brake). then after a time delay set by parameter Cn003, Servo on is activated.

When SON input contact is switched off, Servo ON is de-activated at the same time.

then after a time delay set by parameter Cn003, Output Contact BI is switched off. (Signal to operate the brake).



Note: Input contacts status of above time sequence diagram “1” (ON) and “0” (OFF).

Please check 5-6-1 to set the required high /Low signal levels (PNP/NPN) selection.

### 5-6-6 CW/CCW Drive Inhibit Function

Stopping method of the servo motor as a result of **CW/CCW Inhibit** function can be selected according to the list below:

Parameter	Name	Setting	Description	Control Mode
★Cn009	CW/CCW drive inhibit	0	When torque limit reached the setting value of ( <b>Cn010,Cn011</b> ), servo motor deceleration to stop in the zero clamp status.	ALL
		1	Deceleration by using dynamic brake to stop then hold in dynamic brake status. Cn009 setting has priority over <b>Cn008</b> setting, it require re-cycling power to take effect after setting changed.	
		2	Once max torque limit ( $\pm 300\%$ ) is detected then deceleration to stop with zero clamp.	

**New setting will become effective after re-cycling the power.**


**Note!**

When the Drive Inhibit occurs in CCW/CW, the Cn009 has the higher priority than Cn008.

**Example:**

If Cn008 is set to 0 or 1 which means (without Dynamic Brake).

**BUT Cn009= 1 (with Dynamic Brake), then the dynamic brake will be effective( enabled).**



### 5-6-7 Selecting for External Regeneration Resistor

In applications where a high inertia load is stopped rapidly, motor will generate an energy, which is regenerate power back to the servo drive ( Regeneration energy)

- (1) Short deceleration time with heavy loads.
- (2) In vertical load applications.
- (3) High inertia rotary load applied to the motor shaft.

Part of the regeneration power will be absorbed by the drive main smoothing capacitors

If there is too much regeneration power which can not be totally absorbed by the capacitor then regeneration resistors can be used to absorb the excess power.

Built-in Regeneration Resistor specification is as below table.

Drive Model	Built-in Regeneration Resistor Specifications		The Regeneration Power(W) absorbed by the built in Resistor (Average Power)	Minimum allowed Resistance Value ( $\Omega$ )
	Resistance( $\Omega$ )	Power(W)		
JSDA-15	50	60	24	50
JSDA-20	50	60	24	41
JSDA-30	25	60	24	23
JSDA-50	20	200	80	15
JSDA-75	12.5	200	80	9

#### **Built-in Regeneration Resistor**

The Regeneration Resistor which is built-in this device can absorb the Regeneration Power from acceleration and deceleration running or Vertical Loading.

But for applications that the large load inertia causes the motor shaft to rotate, an external regeneration Resistor must be installed to protect the servo drive otherwise the servo drive can not function correctly. Select the resistor according to the specified values and if installing regeneration resistors in a parallel way to have more power absorb capability.

**Ensure that the total resistance value does not smaller than the minimum resistance listed in the table above.**

## Setting for the Power of External Regeneration Resistor

When using external regeneration resistor, the power value (Watts) must be set in parameter **Cn012**.

Parameter	Name	Default	Unit	Setting Range	Control Mode
Cn012	Watts setting for External Regeneration Resistor	60 ~150	W	0~10000	ALL

## Wiring for External Regeneration Resistor


When external Regeneration Resistor is used, must remove the link between **PC** and **P1** on **TB1** Terminal.

Then the resistor should be installed between terminals **P** and **PC**.

For safety, use of resistors with thermal protection is recommended.

The thermal switch contact can then be interlocked to disable drive or remove power if necessary.

Refer to connection diagram below:



When installing Regeneration Resistors care must be taken as the resistor absorbs the regeneration power, and it is possible to generate the high temperatures above 100°C.

Provide the necessary cooling and use appropriate high temperature wires and ensure there has enough space between regeneration resistor and other materials.



**Assess for an external resistor and calculate for the power consumption:**

Use the table below to determine, if an external regeneration Resistor is necessary.

The table below shows the permitted number of no load operation cycles per minute for various servo motors in regeneration condition.

**Defination of “ No load operation cycles”:**

The servo motor, accerlate from 0 speed to rated speed and deceleration from the rated speed to 0 speed. (No load)

The regeneration energy capacity (in Joules) which can be absorbed by the built-in resistor during no load acceleration/deceleration period, refer to the table list below.

Drive Model	Motor Model	Permitted number of no load operation cycles/min	Main Capacitor energy absorption capacity in Joules. $E_C$ (J).
JSDA-15	JSMA-LC03	433	6
	JSMA-SC02	1775	
	JSMA-SC04	1004	
JSDA-20	JSMA-LC08	118	9
	JSMA-SC04	1004	
	JSMA-SC08	321	
	JSMA-MA05	411	
	JSMA-MH05	186	
JSDA-30	JSMA-SC08	321	13
	JSMA-MA10	213	
	JSMA-MB10	102	
	JSMA-MH10	95	
	JSMA-MA15	145	
	JSMA-MB15	73	
	JSMA-MC15	45	
JSDA-50	JSMA-MA15	484	13
	JSMA-MB15	245	
	JSMA-MC15	152	
	JSMA-MB20	178	
JSDA-75	JSMA-MB30	121	18
	JSMA-MC30	79	

**Calculation for the allowable operation cycles per minute by motor speed and inertia.**

The formula below should be used to calculate the permitted number of cycles/min in **regenerative mode** in accordance with the actual **loading** and the **running speed** of the motor.

$$\text{Allowable operation cycle/min.} = \frac{\text{No load operation cycles}}{(1 + \alpha)} \times \left( \frac{\text{Rated Speed}}{\text{MaxRunningSpeed}} \right)^2$$


$$\alpha = \text{Load Inertia} / \text{Motor Inertia}$$

If the required number of cycles /min is higher than the calculated value then an external regeneration resistor must be installed.

**Calculation of the external regeneration resistor power (Watts).**

Calculate the resistor watts according to the information and formulas below:

(Energy consumed by the motor internally is ignored).



Step	Item	Formula	Description
1	Calculate the working Energy of the servo system.	$E_M = J_T \omega_{rm}^2 / 182$	$E_M$ : Working Energy of Servo system (J) $J_T$ : Inertia applied to the motor shaft ( $kg \cdot m^2$ ) $\omega_{rm}$ : Motor running Speed(rpm)
2	Calculate the Energy consumption by the load during deceleration.	$E_L = (\pi / 60) \omega_{rm} T_L t_D$	$E_L$ : The Energy during deceleration (J) $T_L$ : Loading Torque(Nm) $t_D$ : The Time from deceleration to stopping(s)
3	Calculate the Energy absorbed by internal main capacitor.	$E_C$ Check the diagram above	$E_C$ : The Energy absorbed by the main capacitor (J)
4	Calculate the Energy which regeneration resistor consumes	$E_R = E_M - (E_L + E_C)$	$E_R$ : The Energy which Regeneration Resistor consumes (J)
5	Calculate the Power for regeneration resistor	$P_R = (E_R / T) / 0.4$	$P_R$ : Regeneration Resistor Power(W) $T$ : Operating cycle for servo system(s)

**Note 1 :** 0.4 in the formula for  $P_R$  corresponds to 40% regeneration duty cycle.

**Note 2:** If the  $E_L$  can not be calculated, then let  $E_L = 0$ , then calculate ER .

In applications with regenerative loads, which cause reverse torque, a large amount of energy will flow back to the driver.

In such applications, calculate ER and hence regeneration resistor power according to the formula below.

Item	Formula	Description for Symbols
Calculate the working Energy during the continuous regenerative period.	$E_G = (\pi / 60)\omega_{rm,G}T_G t_G$	$E_G$ : Working Energy during the regenerative period. (J) $\omega_{rm,G}$ : Motor running speed during the regenerative period . (rpm) $T_G$ : Loading Torque during the regenerative period (Nm) $t_G$ : Regenerative Time. (s)

The formula for step 4 in the previous table will be:  $E_R = E_M - (E_L + E_C) + E_G$



### 5-6-8 Fan Setting

Available models that equipped with the fan ( JSDA-50 & JSDA-75 ).


Parameter	Name	Setting	Description	Control Mode
Cn031	Cooling fan running mode	0	Auto-run by internal temperature sensor.	ALL
		1	Run when Servo ON	
		2	Always Running.	
		3	Disabled.	

### 5-6-9 Analog Monitor

There are two analog output signals which can be used to monitor running Speed, Torque, Current and Position as follows:

Parameters	Name & Function		Default	Unit	Setting Range	Control Mode
<b>Cn006.0</b> 	<b>Analog monitor output selection (MON1)</b>		2	X	0   6	ALL
	Setting	Explanation				
	0	Speed feedback				
	1	Torque control				
	2	Speed control				
	3	Pulse command input				
	4	Position deviation value				
	5	Electrical angle				
<b>Cn006.1</b> 	<b>Analog monitor output selection MON2</b>		0			
	Refer to <b>Cn006.0</b> for setting this parameter					


Circuit diagram for analog monitor shows below:




Analog monitor output zero offset can be adjusted by parameters **Cn027&Cn028** as below.

Parameter	Name	Default	Unit	Setting Range	Control Mode
Cn027	Analog Monitor 1 Offset adjustment	4	x40mV	-250~250	ALL
Cn028	Analog Monitor 2 Offset adjustment	4	x40mV	-250~250	ALL

**Before Adjustment**



**After Adjustment**



### 5-6-10 Factory setting parameter

This parameter can reset all parameter settings to default value (factory reset).

Parameter Signal	Name	Setting	Description	Control Mode
★Cn029	Reset parameters	0	Disabled	ALL
		1	All parameters are reset to default values.	

***New setting will become effective after re-cycling the power.***

## Chapter 6 Parameter

### 6-1 Explanation of Parameter groups.

There are 9 groups of parameters as listed below.

Symbol	Description
Un-xx	Status Display Parameters.
dn-xx	Diagnostics Parameters.
AL-xx	Alarm Parameters
Cn-xx	System Parameters
Tn1xx	Torque Control Parameters
Sn2xx	Speed Control Parameters
Pn3xx	Position Control Parameters
qn4xx	Quick Set-up Parameters
Hn5xx	Multi-function I/O parameters

#### Control Mode Code





Signal	Control Mode
ALL	All Control Mode
Pi	Position Control Mode(Internal Positional Command )
Pe	Position Control Mode(External Pulse Command)
S	Speed Control Mode
T	Torque Control Mode




#### Definition of Symbols.



Symbol	Explanation
★	Parameter becomes effective after recycling the power.
◆	Parameter is Effective without pressing the <b>Enter</b> key.

## 6-2 Parameter Display Table



### System Parameters

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter	
★Cn001	<b>Control Mode selection</b>		2	X	0   6	ALL	5-1
	Setting	Explanation					
	0	Torque Control					
	1	Speed Control					
	2	Position Control (external pulse Command)					
	3	Position/Speed Control Switching					
	4	Speed/Torque Control Switching					
	5	Position/Torque Control Switching					
6	Position Control (internal position Command)	5-6-2					
★Cn002.0 	<b>SON (Servo On) Input contact function</b>		0	X	0   1	ALL	
	Setting						Explanation
	0						Input Contact, Enables SON (Servo On).
1	Input Contact has no function. (SON is enabled when Power on).						
Cn002.1 	<b>CCWL &amp; CWL Input contact function.</b>		0	X	0   1	ALL	
	Setting	Explanation					
	0	CCWL and CWL input contacts are able to control the drive inhibit of CCW and CW.					
1	CCWL & CWL input contacts are not able to control CCW and CW drive inhibit. CCW and CW drive inhibit is disable.						
Cn002.2 	<b>Auto Tuning</b>		0	X	0   1	Pi Pe S	
	Setting	Explanation					
	0	Continuously Auto Tuning is Disable					
1	Continuously Auto Tuning is Enabled.						
★Cn002.3 	<b>EMC reset mode selection</b>		0	X	0   1	ALL	
	Setting	Explanation					
	0	Reset EMC signal is only available in Servo Off condition (SON contact is open) and reset AL-09 by ALRS signal. (P.S.) It is NOT allow to reset when SON is applied.					
1	When EMC status is released, AL-09 can be reset on both Servo ON and Servo OFF conditions.  Attention! Ensure that the speed command are removed before the alarm is reset to avoid motor unexpected start.						


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter		
Cn003	Output time setting for Mechanical Brake Signal	0	msec	-2000   2000	ALL	5-6-5		
	Brake Signal Timing Sequence : Cn003 (machinery brake signal output time) is positive  Cn003 (machinery brake signal output time) is negative  Implementation a pin for dynamic brake signal(BI) as a output signal before to perform this function. Refer to sequence diagram above. Note: Signal logic level status: 1 = ON. 0 = OFF. Refer to section 5-6-1 for setting contact the high & Low logic levels.							
Cn004	<b>Motor rotate direction.(Inspect from the load side)</b>  When Torque or Speed Command value is Positive, the setting of Motor rotation direction are:	0	X	0   3	S T	5-2-4 5-3-7		
	Setting						Explanation	
							Torque Control	Speed Control
	0						Counter ClockWise(CCW)	Counter ClockWise (CCW)
	1						ClockWise (CW)	Counter ClockWise (CCW)
	2						Counter ClockWise (CCW)	ClockWise(CW)
3	ClockWise (CW)	ClockWise (CW)						

Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Chapter
★Cn005	<b>Encoder pulse output scale.</b>		Encoder pulse per rotation	pulse	1   Encoder pulse per rotation	ALL	5-3-5
	For default set to the rated encoder number of pulses per revolution, such as 2500ppr. Encoder ppr can be scaled by setting a ppr in the range of 1 to the rated ppr of the encoder for scaling purpose. <b>PPR = Pulse per revolution.</b> <b>Ex:encoder rated precision is 2000 ppr, If you setting Cn005 =1000, the output is 1000ppr.</b>						
Cn006.0 	<b>Analog monitor output selection MON1</b>		2	X	0   6	ALL	5-6-9
	Setting	Explanation					
	0	Speed feedback					
	1	Torque control					
	2	Speed control					
	3	Pulse command input					
	4	Position deviation value					
	5	Electrical angle					
6	Main circuit (Vdc Bus) voltage						
Cn006.1 	<b>Analog monitor output selection MON2</b>		0				
	Refer to <b>Cn006.0</b> for setting this parameter						
Cn007	<b>Speed reached preset.</b>		Rated rpm × 1/3	rpm	0   4500	S T	5-3-12
	Speed preset level for ClockWise or Counter ClockWise rotation. When the speed is greater then preset level in Cn007 the Speed reached output signal INS will be activated..						
Cn008	<b>Brake Mode</b>		2	X	0   3	ALL	5-6-4
	Setting	Explanation					
		Dynamic brakes      Mechanical brakes					
	0	No                              No					
	1	No                              Yes					
	2	Yes                              No					
3	Yes                              Yes						
★Cn009	<b>CW/CCW drive inhibit mode</b>		0	X	0   2	ALL	5-6-6
	Setting	Explanation					
	0	When torque limit reached the setting value of (Cn010,Cn011), servo motor deceleration to stop in the zero clamp condition.					
	1	Deceleration by using dynamic brake to stop then hold in dynamic brake status. Cn009 setting has priority over Cn008 setting, it require re-cycling power to take effect after setting changed.					
2	Once max torque limit (± 300% ) is detected then deceleration to stop, zero clamp is applied when stop.						





Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter
<b>Cn010</b>	<b>CCW Torque command Limit.</b>	300	%	0   300	ALL	5-2-5 5-3-10
	Ex: For a torque limit in CCW direction which is twice the rated torque , set Cn10=200.					
<b>Cn011</b>	<b>CW Torque command Limit.</b>	-300	%	-300   0	ALL	5-2-5 5-3-10
	Ex: For a torque limit in CW direction which is twice the rated torque , set Cn11=-200.					
<b>Cn012</b>	<b>Power setting for External Regeneration Resistor</b>	60 / 150	W	0   10000	ALL	5-6-7
	Refer to section 5-6-7 to choose external Regen resistor and set its power specification in Watts of Cn012. (P.S.)This default value will change depend on servo model.					
<b>Cn013</b>	<b>Frequency of resonance Filter ( Notch Filter).</b>	0	Hz	0   1000	Pi Pe S	5-3-9
	Enter the vibration frequency in Cn013, to eliminate system mechanical vibration.					
<b>Cn014</b>	<b>Band Width of the Resonance Filter.</b>	7	X	1   100	Pi Pe S	5-3-9
	Adjusting the band width of the frequency, lower the band width value in <b>Cn014</b> , restrain frequency Band width will be wider.					
<b>Cn015.0</b> 	<b>P/I/P control switch mode.</b>		4	X	0   4	Pi Pe S
	Setting	Explanation				
	0	Switch from PI to P if the <b>torque</b> command is larger than <b>Cn016</b> .				
	1	Switch from PI to P if the <b>speed</b> command is larger than <b>Cn017</b> .				
	2	Switch from PI to P if the <b>acceleration</b> rate is larger than <b>Cn018</b> .				
	3	Switch from PI to P if the <b>position error</b> is larger than <b>Cn019</b> .				
4	Switch from PI to P be the input contact <b>PCNT</b> . Set one of the multi function terminals to option 03.					
<b>Cn015.1</b> 	<b>Automatic gain 1&amp; 2 switch</b>		4	X	0   4	Pi Pe S
	Setting	Explanation				
	0	Switch from gain 1 to 2 if <b>torque</b> command is greater than <b>Cn021</b> .				
	1	Switch from gain 1 to 2 if <b>speed</b> command is greater than <b>Cn022</b> .				
	2	Switch from gain 1 to 2 if <b>acceleration</b> command is greater than <b>Cn023</b> .				
	3	Switch from gain 1 to 2 if <b>position error</b> value is greater than <b>Cn024</b> .				
4	Switch from gain 1 to 2 by input contact <b>G-SEL</b> . Set one of the multi function terminals to option 15.					



Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter
<b>Cn016</b>	<b>PI/P control mode switch by Torque Command</b> Set the <b>Cn015.0=0</b> first. If Torque Command is less than Cn016 PI control is selected. If Torque Command is greater than Cn016 P control is selected.	200	%	0   399	Pi Pe S	5-3-11
<b>Cn017</b>	<b>PI/P control mode switch by Speed Command</b> Set the <b>Cn015.0=1</b> first. If Speed Command is less than <b>Cn017</b> PI control is selected. If Speed Command is greater than <b>Cn017</b> P control is selected.	0	rpm	0   4500	Pi Pe S	5-3-11
<b>Cn018</b>	<b>PI/P control mode switch by accelerate Command</b> Set the <b>Cn015.0=2</b> first. If Acceleration is less than <b>Cn018</b> PI control is selected. If Acceleration is greater than <b>Cn018</b> P control is selected.	0	rps/s	0   18750	Pi Pe S	5-3-11
<b>Cn019</b>	<b>PI/P control mode switch by position error number</b> Set the <b>Cn015.0=3</b> first. If Position error value is less than <b>Cn019</b> PI control is selected. If Position error value is greater than <b>Cn019</b> P control is selected.	0	pulse	0   50000	Pi Pe S	5-3-11
<b>Cn020</b>	<b>Automatic gain 1 &amp; 2 switch delay time.</b> Speed loop 2 to speed loop 1, Change over delay, when two control speed loops ( P&I gains 1 & 2) are used.	0	x02 msec	0   10000	Pi Pe S	5-3-11
<b>Cn021</b>	<b>Automatic gain 1 &amp; 2 switch condition (Torque command)</b> Set <b>Cn015.1=0</b> first. When torque command is less than <b>Cn021</b> , Gain 1 is selected. When torque command is greater than <b>Cn021</b> , Gain 2 is selected When <b>Gain 2</b> is active and torque command becomes less than <b>Cn021</b> setting value, system will automatically switch back to <b>Gain 1</b> switch time delay can be set by Cn020.	200	%	0   399	Pi Pe S	5-3-11
<b>Cn022</b>	<b>Automatic gain 1 &amp; 2 switch condition (Speed Command)</b> Set the <b>Cn015.1=1</b> first. When speed command is less than Cn022 Gain 1 is selected. When speed command is greater than Cn022 Gain 2 is selected. When <b>Gain 2</b> is active and speed command becomes less than <b>Cn022</b> setting value, system will automatically switch back to <b>Gain 1</b> the switch time delay can be set by Cn020.	0	rpm	0   4500	Pi Pe S	5-3-11


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter			
<b>Cn023</b>	<b>Automatic gain 1 &amp; 2 switch condition (Acceleration Command)</b>	0	rps/s	0   18750	Pi Pe S	5-3-11			
	Set <b>Cn015.1=2</b> first. When accel. command is less than Cn023 Gain 1 is selected. When accel. command is greater than Cn023 Gain 2 is selected. When <b>Gain 2</b> is active and acceleration command becomes less than <b>Cn023</b> system will automatically switch back to <b>Gain 1</b> the switch time delay can be set by Cn020. * accel. is acceleration								
<b>Cn024</b>	<b>Automatic gain 1 &amp; 2 switch condition (Position error value)</b>	0	pulse	0   50000	Pi Pe S	5-3-11			
	Set <b>Cn015.1=3</b> first. When position error value is less than Cn024 Gain 1 is selected. When position error value is greater than Cn024 Gain 2 is selected. When <b>Gain 2</b> is active and position error value becomes less than <b>Cn024</b> system will automatically switch back to <b>Gain 1</b> and the switch time delay can be set by Cn020.								
<b>Cn025</b>	<b>Load-Inertia ratio</b>	40	x0.1	0   1000	Pi Pe S	5-5			
	$LoadInertiaRatio = \frac{LoadInertiaToMotor(J_L)}{MotorRotorInertia(J_M)} \times 100\%$								
<b>Cn026</b> 	<b>Rigidity Setting</b>	4	X	1   A	Pi Pe S	5-5-1			
	When Auto tuning is used, set the Rigidity Level depending on the various Gain settings for applications such as those listed below:								
							Explanation		
	Setting						Position Loop Gain <b>Pn310 [1/s]</b>	Speed Loop Gain <b>Sn211 [Hz]</b>	Speed Loop Integral-Time Constant <b>Sn212 [x0.2msec]</b>
	<b>1</b>						15	15	300
	<b>2</b>						20	20	225
	<b>3</b>						30	30	150
	<b>4</b>						40	40	100
	<b>5</b>						60	60	75
	<b>6</b>						85	85	50
	<b>7</b>						120	120	40
<b>8</b>	160	160	30						
<b>9</b>	200	200	25						
<b>A</b>	250	250	20						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter	
<b>Cn027</b>	<b>Analog monitor output 1, Offset adjustment</b>	4	x40 mV	-250   250	ALL	5-6-9	
	Analog monitor output zero offset can be adjusted by parameter. <b>Cn027</b> as below. <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Before offset Adjust</p> </div> <div style="text-align: center;"> <p>After offset adjust</p> </div> </div>						
<b>Cn028</b>	<b>Analog monitor output 2, offset adjustment</b>	4	x40 mV	-250   250	ALL	5-6-9	
	Analog monitor output 2, zero offset can be adjusted by parameter. <b>Cn028</b> . See diagram for Monitor 1 above.						
★ <b>Cn029</b>	<b>Reset parameters.</b>	0	X	0   1	ALL	5-6-10	
	Setting						Explanation
	0						Disabled
★ <b>Cn030</b> 	<b>Servo motor model code</b>	Default	X	X	ALL	3-2-2	
	Servo model code can be display and checked with parameter dn-08, refer <b>3-2-2 dn-08</b> table for more information.						
	Attention : Before operate your servo motor., check this parameter setting is compatible for servo drive and motor. If there has any incompatible problem contact supplier for more information.						
<b>Cn031</b>	<b>Cooling fan running modes</b> <b>(Available for JSDA-50 &amp; JSDA-75)</b>	0	X	0   3	ALL	5-6-8	
	Setting						Explanation
	0						Auto-run by internal temperature sensor.
	1						Run when Servo ON
	2						Always Running.
3	Disabled.						
<b>Cn032</b>	<b>Speed feed back smoothing filter</b>	500	Hz	1   1000	Pe Pi S	5-3-12	
Restrain sharp vibration noise by the setting and this filter also delay the time of servo response.							
<b>Cn033</b>	<b>Speed Feed-forward smoothing filter</b>	40	Hz	1   100	Pe Pi	5-4-6	
Smooth the speed feed-forward command.							
<b>Cn034</b>	<b>Torque command smoothing filter</b>	0	Hz	0   1000	ALL	5-2-7	
	Restrain sharp vibration noise by the setting and this filter delay the time of servo response.						
<b>Cn035</b>	<b>Panel display content selection</b>	0	X	0   19	ALL	3-1 3-2-1	
	Select display content for LED panel for power on status.						
	Setting						Explanation
	0						Display data set and drive status parameter. Refer 3-1
1   19	Display Un-01 ~ Un-19 content. Refer 3-2-1 for more information. Ex : Set Cn035=1, when power on it display the actual speed of motor. (content of Un-01)						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter	
Cn036	<b>Servo ID number</b>	1	X	0   254	ALL	7	
	When using Modbus for communication, each servo unit has to setting a ID number. repeated ID number will lead to communication fail.						
Cn037.0 	<b>Modbus RS-485 braud rate setting</b>	1	bps	0   5	ALL	7	
	Setting						Explanation
	0						4800
	1						9600
	2						19200
	3						38400
	4						57600
5	115200						
Cn037.1 	<b>PC Software RS-232 braud rate setting</b>	1	bps	0   3	ALL	7	
	Setting						Explanation
	0						4800
	1						9600
	2						19200
3	38400						
Cn038	<b>Communication protocol</b>	0	X	0   8	ALL	7	
	Setting						Explanation
	0						7, N, 2 ( Modbus , ASCII )
	1						7, E, 1 ( Modbus , ASCII )
	2						7, O, 1 ( Modbus , ASCII )
	3						8, N, 2 ( Modbus , ASCII )
	4						8, E, 1 ( Modbus , ASCII )
	5						8, O, 1 ( Modbus , ASCII )
	6						8, N, 2 ( Modbus , RTU )
	7						8, E, 1 ( Modbus , RTU )
8	8, O, 1 ( Modbus , RTU )						
Cn039	<b>Communication time-out dection</b> Setting non-zero value to enable this function, communication Time should be in the setting period otherwise alarm message of communication time-out will show. Setting a zero value to disable this function.	0	sec	0   20	ALL	7	
Cn040	<b>Communication response delay time</b> Delay Servo response time to master control unit.	0	0.5 msec	0   255	ALL	7	

## Torque-Control Parameter

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter	
<b>★Tn101</b>	<b>Linear acceleration/deceleration method</b>		0	X	0   1	T	5-2-3
	Setting	Explanation					
	0	Disabled.					
1	Enabled.						
<b>★Tn102</b>	<b>Linear accel/decel time period.</b>		1	msec	1   50000	T	5-2-3
	Time taken for the torque-command to linearly accelerate to the rated torque level or Decelerate to zero torque .  						
<b>Tn103</b>	<b>Analog Torque Command Ratio</b> Slope of voltage command / Torque command can be adjusted.  		300	% 10V	0   300	T	5-2-1


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter
Tn104	<b>Torque Command, analog input voltage offset</b>	0	mV	-10000   10000	T	5-2-2
	The offset amount can be adjusted by this parameter. 					
Tn105	<b>Preset Speed Limit 1. ( Torque control mode)</b>	100	rpm	0   3000	T	5-2-6
	In Torque control, input contacts SPD1 and SPD2 can be used to select Preset speed limit 1. As follows: <table border="1" data-bbox="303 728 821 795"> <tr> <td><b>Input Contact SPD2</b></td> <td><b>Input Contact SPD1</b></td> </tr> <tr> <td>0</td> <td>1</td> </tr> </table> Note: Input contacts status “1” (ON) and “0” (OFF). Refer to 5-6-1 to set high or low input logic levels.					
<b>Input Contact SPD2</b>	<b>Input Contact SPD1</b>					
0	1					
Tn106	<b>Preset Speed Limit 2. ( Torque control mode)</b>	200	rpm	0   3000	T	5-2-6
	In Torque control, input contacts SPD1 and SPD2 can be used to select Preset speed limit 2. As follows: <table border="1" data-bbox="303 1019 821 1086"> <tr> <td><b>Input Contact SPD2</b></td> <td><b>Input Contact SPD1</b></td> </tr> <tr> <td>1</td> <td>0</td> </tr> </table> Note: Input contacts status “1” (ON) and “0” (OFF) Refer to 5-6-1 to set high or low input logic levels.					
<b>Input Contact SPD2</b>	<b>Input Contact SPD1</b>					
1	0					
Tn107	<b>Preset Speed Limit 3. ( Torque control mode)</b>	300	rpm	0   3000	T	5-2-6
	In Torque control, input contacts SPD1 and SPD2 can be used to select Preset speed limit 3. As follows:- <table border="1" data-bbox="303 1276 821 1344"> <tr> <td><b>Input Contact SPD2</b></td> <td><b>Input Contact SPD1</b></td> </tr> <tr> <td>1</td> <td>1</td> </tr> </table> Note: Input contacts status “1” (ON) and “0” (OFF) Refer to 5-6-1 to set high or low input logic levels.					
<b>Input Contact SPD2</b>	<b>Input Contact SPD1</b>					
1	1					
Tn108	<b>Torque output monitor value</b> When the torque level in CW or CCW direction become greater then this value setting, the output contact INT operate.	0	%	0   300	ALL	5-2-7

## Speed-Control Parameter

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter				
Sn201	Internal Speed Command 1	100	rpm	-3000   3000	S	5-3-1				
	In Speed control, input contacts SPD1 and SPD2 can be used to select 3 sets of internal speed command, select for speed command 1 contact status shows below:									
	<table border="1"> <thead> <tr> <th>Input Contact SPD2</th> <th>Input Contact SPD1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1</td> </tr> </tbody> </table>						Input Contact SPD2	Input Contact SPD1	0	1
	Input Contact SPD2						Input Contact SPD1			
0	1									
Note: Input contacts status "1" (ON) and "0" (OFF) Refer to 5-6-1 to set high or low input logic levels.										
Sn202	Internal Speed Command 2	200	rpm	-3000   3000	S	5-3-1				
	In Speed control, input contacts SPD1 and SPD2 can be used to select 3 sets of internal speed command, select for speed command 2 contact status shows below:									
	<table border="1"> <thead> <tr> <th>Input Contact SPD2</th> <th>Input Contact SPD1</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>0</td> </tr> </tbody> </table>						Input Contact SPD2	Input Contact SPD1	1	0
	Input Contact SPD2						Input Contact SPD1			
1	0									
Note: Input contacts status "1" (ON) and "0" (OFF) Refer to 5-6-1 to set high or low input logic levels.										
Sn203	Internal Speed Command 3	300	rpm	-3000   3000	S	5-3-1				
	In Speed control, input contacts SPD1 and SPD2 can be used to select 3 sets of internal speed command, select for speed command 3 contact status shows below:									
	<table border="1"> <thead> <tr> <th>Input Contact SPD2</th> <th>Input Contact SPD1</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>1</td> </tr> </tbody> </table>						Input Contact SPD2	Input Contact SPD1	1	1
	Input Contact SPD2						Input Contact SPD1			
1	1									
Note: Input contacts status "1" (ON) and "0" (OFF). Refer to 5-6-1 to set high or low input logic levels.										
Sn204	<b>Zero Speed selection Enable or Disable the zero speed preset parameter Sn215.</b>	0	X	0   1	S	5-3-12				
	Setting						Explanation			
	0						No Action. ( Sn215 zero preset is not effective).			
	1						Set the preset value in Sn215 as zero speed.			
Sn205	<b>Speed command accel/decel smooth method.</b>	0	X	0   3	S	5-3-6				
	Setting						Explanation			
	0						<b>By Step response</b>			
	1						Smooth Acceleration/deceleration according to the curve defined by Sn206.			
	2						Linear accel/decel time constant .Defined by Sn207			
3	S curve for Acceleration/deceleration. Defined by Sn208.									






Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter
Sn206	<b>Speed command smooth accel/decel time Constant.</b> Set <b>Sn205=1</b> to enable this function then set the time period for the speed to rise to 63.2% of the full speed.	1	msec	1   10000	S	5-3-6
Sn207	<b>Speed command linear accel/decel time constant.</b> Set <b>Sn205=2</b> to enable this function then set the time period for the speed to rise linearly to full speed.	1	msec	1   50000	S	5-3-6

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter
Sn208	<b>S curve speed command acceleration and deceleration time setting.</b> Set Sn205=3 to enable this function. In the period of Acc/Dec , drastic speed changing might cause vibration of machine. S curve speed command acc/dec time setting has the effect to smooth acc/dec curve. Speed Command (rpm)	1	msec	1   1000	S	5-3-6
	 <p style="text-align: right;">ts=Sn208 ta=Sn209 td=Sn210</p> <p>Rule for the setting : <math>\frac{t_a}{2} &gt; t_s</math> , <math>\frac{t_d}{2} &gt; t_s</math></p>					
Sn209	<b>S curve speed command acceleration time setting.</b> Refer Sn208	200	msec	0   5000	S	5-3-6
Sn210	<b>S curve speed command deceleration time setting.</b> Refer Sn208	200	msec	0   5000	S	5-3-6
Sn211	<b>Speed loop Gain 1</b> Speed loop gain has a direct effect on the frequency response bandwidth of the Speed-control loop. Without causing vibration or noise Speed-loop-gain can be increased to obtain a faster speed response.  If Cn025 (load Inertia ratio) is set correctly, the speed-loop-bandwidth will equal to speed-loop-gain.	40	Hz	10   450	Pi Pe S	5-3-8 5-5
Sn212	<b>Speed-loop Integral time 1</b> Speed loop integral element can eliminate the steady speed error and react to even slight speed variations. Decreasing Integral time can improve system rigidity. The formula below shows the relationship between Integral time and Speed loop Gain.  $SpeedLoopIntegrationTimeCons \tan t \geq 5 \times \frac{1}{2\pi \times SpeedLoopGain}$	100	x0.2 ms	1   500	Pi Pe S	5-3-8 5-5

Parameter	Name & Functions	Default	Unit	Setting Range	Control Mode	Chapter
Sn213	<b>Speed loop Gain 2</b>	40	Hz	10   450	Pi Pe S	5-3-8 5-5
	Refer to Sn211					
Sn214	<b>Speed loop Integral time 2</b>	100	x0.2 msec	1   500	Pi Pe S	5-3-8 5-5
	Refer to Sn212					
Sn215	<b>Value of zero speed</b>	50	rpm	0   4500	S	5-3-12
	Set the zero speed range in Sn215 When the actual speed is lower than Sn215 value, Output contact <b>ZS</b> is activated.					
Sn216	<b>Analog Speed Command Ratio</b>		Rate rpm	rpm /10V	S	5-3-2
	Slope of voltage command / Speed command can be adjusted.					
				100   4500		
Sn217	<b>Analog Speed Command offset adjust</b>				S	5-3-3
	The offset amount can be adjusted by this parameter.					
		0	mV	-10000   10000		
Sn218	<b>Analog speed command limited</b>	Rate rpm x 1.02	rpm	100   4500	S	5-3-4
	Setting Sn218 for limit the highest speed command of analog input.					

## Position Control Parameter

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter
★Pn301.0 	<b>Position pulse command selection</b>	0	X	0   3	Pe	5-4-1
	Setting   Explanation					
	0   (Pulse)+(Sign)					
	1   (CCW)/(CW) Pulse					
	2   AB-Phase pulse x 2					
3   AB-Phase pulse x 4						
★Pn301.1 	<b>Position- Pulse Command Logic</b>	0	X	0   1		
	Setting   Explanation					
	0   Positive Logic					
1   Negative Logic						
★Pn301.2 	<b>Selection for command receive of drive inhibit mode</b>	0	X	0   1	Pi Pe	5-4-1
	Setting   Explanation					
	0   When drive inhibit occurs, record value of position command input coherently.					
1   When drive inhibit occurs, ignore the value of position command.						
Pn302	<b>Electronic Gear Ratio Numerator 1</b>	1	X	1   50000	Pi Pe	5-4-3
	<p>Use input contacts GN1 &amp; GN2 to select one of four electronic Gear Ratio Numerators. To select Numerator 1, the statue of the input-contacts GN1 &amp; GN2 should be as follows:</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td style="padding: 2px;">Input Contact GN2</td> <td style="padding: 2px;">Input Contact GN1</td> </tr> <tr> <td style="text-align: center; padding: 2px;">0</td> <td style="text-align: center; padding: 2px;">0</td> </tr> </table> <p>Note: Input contacts status “1” (ON) and “0” (OFF). Refer to 5-6-1 to set high or low input logic levels.</p>					
Input Contact GN2	Input Contact GN1					
0	0					
Pn303	<b>Electronic Gear Ratio Numerator 2</b>	1	X	1   50000	Pi Pe	5-4-3
	<p>Use input contacts GN1 &amp; GN2 to select one of four electronic Gear Ratio Numerators. To select Numerator 2, the statue of the input-contacts GN1 &amp; GN2 should be as follows:</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td style="padding: 2px;">Input Contact GN2</td> <td style="padding: 2px;">Input Contact GN1</td> </tr> <tr> <td style="text-align: center; padding: 2px;">0</td> <td style="text-align: center; padding: 2px;">1</td> </tr> </table> <p>Note: Input contacts status “1” (ON) and “0” (OFF). Refer to 5-6-1 to set high or low input logic levels.</p>					
Input Contact GN2	Input Contact GN1					
0	1					
Pn304	<b>Electronic Gear Ratio Numerator 3</b>	1	X	1   50000	Pi Pe	5-4-3
	<p>Use input contacts GN1 &amp; GN2 to select one of four electronic Gear Ratio Numerators. To select Numerator 3, the statue of the input-contacts GN1 &amp; GN2 should be as follows:</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td style="padding: 2px;">Input Contact GN2</td> <td style="padding: 2px;">Input Contact GN1</td> </tr> <tr> <td style="text-align: center; padding: 2px;">1</td> <td style="text-align: center; padding: 2px;">0</td> </tr> </table> <p>Note: Input contacts status “1” (ON) and “0” (OFF). Refer to 5-6-1 to set high or low input logic levels.</p>					
Input Contact GN2	Input Contact GN1					
1	0					

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter
Pn305	<b>Electronic Gear Ratio Numerator 4</b>	1	X	1   50000	Pi Pe	5-4-3
	Use input contacts GN1 & GN2 to select one of four electronic Gear Ratio Numerators. To select Numerator 4, the statue of the input-contacts GN1 & GN2 should be as follows: <table border="1" style="margin-left: 20px;"> <tr> <td><b>Input Contact GN2</b></td> <td><b>Input Contact GN1</b></td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">1</td> </tr> </table> <p>Note: Input contacts status "1" (ON) and "0" (OFF). Refer to 5-6-1 to set high or low input logic levels.</p>					
<b>Input Contact GN2</b>	<b>Input Contact GN1</b>					
1	1					
★Pn306	<b>Electronic Gear Ratio Denominator</b> Set the calculated Electronic Gear Ratio Denominator in Pn 306. ( Refer to section 5-4-3). Final Electronic Gear Ratio should comply with the formula below. $\frac{1}{200} \leq \text{ElectronicGearRatio} \leq 200$	1	X	1   50000	Pi Pe	5-4-3
Pn307	<b>Position complete value</b>	10	pulse	0   50000	Pi Pe	5-4-9
	Set a value for In position output signal. When the Position pulse error value is less then <b>Pn307</b> output-contact <b>INP (In position output signal)</b> will be activated.					
Pn308	<b>"Incorrect position" Error band Upper limit.</b>	50000	pulse	0   50000	Pi Pe	5-4-9
	When the Position error value is higher then number of pulses set in <b>Pn308</b> , an Alarm message <b>AL-11</b> (Position error value alarm) will be displayed.					
Pn309	<b>"Incorrect position" Error band lower limit.</b>	50000	pulse	0   50000	Pi Pe	5-4-9
	When the Position error value is lower then number of pulses set in <b>Pn309</b> , an Alarm message <b>AL-11</b> (Position error value alarm) will be displayed.					
Pn310	<b>Position Loop Gain 1</b>	40	1/s	1   450	Pi Pe	5-4-6 5-5
	Without causing vibration or noise on the mechanical system the position loop gain value can be increased to speed up response and shorten the positioning time. Generally, the position loop bandwidth should not be higher then speed loop bandwidth. The relationship is according to the formula below: $\text{PositionLoopGain} \leq 2\pi \times \frac{\text{SpeedLoopGain}}{5}$					
Pn311	<b>Position Loop Gain 2</b>	40	1/s	1   450	Pi Pe	5-4-6 5-5
	Refer to <b>Pn310</b>					
Pn312	<b>Position Loop Feed Forward Gain</b>	0	%	0   100	Pi Pe	5-4-6 5-5
	It can be used to reduce the track error of position control and speed up the response. If the feed forward gain is too large, it might cause speed Overshoot and in position oscillations which result in the repeated ON/OFF operation of the output contact <b>INP</b> ("In Position" output signal).					


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter	
★Pn313	<b>Position command smooth Acceleration/Deceleration Time Constant</b> Set the time period for the Position command pulse frequency to rise from 0 to 63.2%. Position Pulse Command Frequency (%)	10	msec	0   10000	Pi Pe	5-4-4	
★Pn314	<b>Positioning Command Direction Definition</b> 	1	X	0   1	Pi Pe	5-4-5	
	Setting						Explanation
	0						(CW) .Clockwise
1	(CCW). Counter Clockwise						
Pn315	<b>Pulse Error Clear Modes.</b> Setting	0	X	0   2	Pe  Pi Pe  Pi	5-4-7	
	Explanation						
	0						Once <b>CLR</b> signal is activated, it eliminates, the Pulse error amount.
	1						Once CLR signal is activated, following takes place: <ul style="list-style-type: none"> <li>• The position command is cancelled.</li> <li>• Motor rotation is interrupted</li> <li>• Pulse error amount is cleared.</li> <li>• Machine home reference is reset</li> </ul>
2	Once CLR signal is activated, following takes place:- <ul style="list-style-type: none"> <li>• The position command is cancelled..</li> <li>• Motor rotation is interrupted</li> <li>• Pulse error amount is cleared.</li> </ul>						




Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter	
★Pn316	<b>Internal Position Command Mode</b>	0	X	0   1	Pi	5-4-2	
	Setting						Explanation
	0						Absolute Position
	1	Incremental Position					
★Pn316.1 	<b>Internal Position Command Hold (PHOLD) program select</b>	0	X	0   1	Pi	5-4-2	
	Setting						Explanation
	0						When PHOLD is active then received PTRG signal. servomotor will be proceed internal position command from PHOLD position.
	1	When PHOLD is active then received PTRG signal. Servomotor will operate internal position command of current selection.					
Pn317	<b>Internal Position Command 1 – Rotation Number</b> Set the Rotation number of the internal Position Command 1 Use input contacts POS1~POS4 to select Refer to 5-4-2.	0	rev	-30000   30000	Pi	5-4-2	
Pn318	<b>Internal Position Command 1 - Pulse Number</b> Set the rotation pulse number of internal position Command 1 <b>Internal Position Command 1 =Pn317(Rotation Number) x Pulse number of One Rotate x 4 + Pn318(Pulse number)</b>	0	pulse	-32767   32767	Pi	5-4-2	
Pn319	<b>Internal Position Command 1 - Move Speed</b> Setting the Move Speed of internal Position Command 1	0	rpm	0   3000	Pi	5-4-2	
Pn320	<b>Internal Position Command 2-Rotation Number</b> Please refer to Pn317	0	rev	-30000   30000	Pi	5-4-2	
Pn321	<b>Internal Position Command 2-Pulse Number</b> Please refer to Pn318	0	pulse	-32767   32767	Pi	5-4-2	
Pn322	<b>Internal Position Command 2-Move Speed</b> Please refer to Pn319	0	rpm	0   3000	Pi	5-4-2	
Pn323	<b>Internal Position Command 3-Rotation Number</b> Please refer to Pn317	0	rev	-30000   30000	Pi	5-4-2	
Pn324	<b>Internal Position Command 3-Pulse Number</b> Please refer to Pn318	0	pulse	-32767   32767	Pi	5-4-2	
Pn325	<b>Internal Position Command 3-Move Speed</b> Please refer to Pn319	0	rpm	0   3000	Pi	5-4-2	
Pn326	<b>Internal Position Command 4 -Rotation Number</b> Please refer to Pn317	0	rev	-30000   30000	Pi	5-4-2	
Pn327	<b>Internal Position Command 4-Pulse Number</b> Please refer to Pn318	0	pulse	-32767   32767	Pi	5-4-2	
Pn328	<b>Internal Position Command 4-Move Speed</b> Please refer to Pn319	0	rpm	0   3000	Pi	5-4-2	


Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter
Pn329	<b>Internal Position Command 5 -Rotation Number</b>	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					
Pn330	<b>Internal Position Command 5-Pulse Number</b>	0	pulse	-32767   32767	Pi	5-4-2
	Please refer to Pn318					
Pn331	<b>Internal Position Command 5-Move Speed</b>	0	rpm	0   3000	Pi	5-4-2
	Please refer to Pn319					
Pn332	<b>Internal Position Command 6 -Rotation Number</b>	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					
Pn333	<b>Internal Position Command 6-Pulse Number</b>	0	pulse	-32767   32767	Pi	5-4-2
	Please refer to Pn318					
Pn334	<b>Internal Position Command 6-Move Speed</b>	0	rpm	0   3000	Pi	5-4-2
	Please refer to Pn319					
Pn335	<b>Internal Position Command 7 -Rotation Number</b>	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					
Pn336	<b>Internal Position Command 7-Pulse Number</b>	0	pulse	-32767   32767	Pi	5-4-2
	Please refer to Pn318					
Pn337	<b>Internal Position Command 7-Move Speed</b>	0	rpm	0   3000	Pi	5-4-2
	Please refer to Pn319					
Pn338	<b>Internal Position Command 8 -Rotation Number</b>	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					
Pn339	<b>Internal Position Command 8-Pulse Number</b>	0	pulse	-32767   32767	Pi	5-4-2
	Please refer to Pn318					
Pn340	<b>Internal Position Command 8-Move Speed</b>	0	rpm	0   3000	Pi	5-4-2
	Please refer to Pn319					
Pn341	<b>Internal Position Command 9 -Rotation Number</b>	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					
Pn342	<b>Internal Position Command 9-Pulse Number</b>	0	pulse	-32767   32767	Pi	5-4-2
	Please refer to Pn318					
Pn343	<b>Internal Position Command 9-Move Speed</b>	0	rpm	0   3000	Pi	5-4-2
	Please refer to Pn319					
Pn344	<b>Internal Position Command 10 -Rotation Number</b>	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					
Pn345	<b>Internal Position Command 10-Pulse Number</b>	0	pulse	-32767   32767	Pi	5-4-2
	Please refer to Pn318					



Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter
Pn346	Internal Position Command 10-Move Speed	0	rpm	0   3000	Pi	5-4-2
	Please refer to Pn319					
Pn347	Internal Position Command 11 -Rotation Number	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					
Pn348	Internal Position Command 11-Pulse Number	0	pulse	-32767   32767	Pi	5-4-2
	Please refer to Pn318					
Pn349	Internal Position Command 11-Move Speed	0	rpm	0   3000	Pi	5-4-2
	Please refer to Pn319					
Pn350	Internal Position Command 12-Rotation Number	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					
Pn351	Internal Position Command 12-Pulse Number	0	pulse	-32767   32767	Pi	5-4-2
	Please refer to Pn318					
Pn352	Internal Position Command 12-Move Speed	0	rpm	0   3000	Pi	5-4-2
	Please refer to Pn319					
Pn353	Internal Position Command 13 -Rotation Number	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					
Pn354	Internal Position Command 13-Pulse Number	0	pulse	-32767   32767	Pi	5-4-2
	Please refer to Pn318					
Pn355	Internal Position Command 13-Move Speed	0	rpm	0   3000	Pi	5-4-2
	Please refer to Pn319					
Pn356	Internal Position Command 14 -Rotation Number	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					
Pn357	Internal Position Command 14-Pulse Number	0	pulse	-32767   32767	Pi	5-4-2
	Please refer to Pn318					
Pn358	Internal Position Command 14-Move Speed	0	rpm	0   3000	Pi	5-4-2
	Please refer to Pn319					
Pn359	Internal Position Command 15 -Rotation Number	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					
Pn360	Internal Position Command 15-Pulse Number	0	pulse	-32767   32767	Pi	5-4-2
	Please refer to Pn318					
Pn361	Internal Position Command 15-Move Speed	0	rpm	0   3000	Pi	5-4-2
	Please refer to Pn319					
Pn362	Internal Position Command 16 -Rotation Number	0	rev	-30000   30000	Pi	5-4-2
	Please refer to Pn317					

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter	
Pn363	<b>Internal Position Command 16-Pulse Number</b>	0	pulse	-32767   32767	Pi	5-4-2	
	Please refer to <b>Pn318</b>						
Pn364	<b>Internal Position Command 16-Move Speed</b>	0	rpm	0   3000	Pi	5-4-2	
	Please refer to <b>Pn319</b>						
<b>Pn365.0</b> 	<b>Setting for HOME routine.</b>						
	Setting	Explanation					
	0	<p>Once the home routine is activated, motor will search for Home Position switch in 1<sup>st</sup> speed in <b>CCW direction</b>.  <b>Input contacts CCWL or CWL can be used as Home Reference Switch.</b>  Once Home reference switch is detected, then Contacts <b>CCWL</b> and <b>CWL</b> will act as normal M limits again.  <b>Note:</b>  When using this function, <b>Pn365.1</b> can not be set to 1 or 2. <b>Cn002.1 ( selection for CCWL and CWL) must be set to 0.</b></p>					
	1	<p>Once the home routine is activated, motor will search for Home Position switch in 1<sup>st</sup> speed in <b>CW direction</b>.  <b>Input contacts CCWL or CWL can be used as the Home Reference Switch.</b>  Once Home position is detected, then input contacts <b>CCWL</b> and <b>CWL</b> will act as normal max. limits again.  <b>Note:</b>  When using this function, <b>Pn365.1</b> can not be set to 1 or 2. <b>Cn002.1 ( selection for CCWL and CWL) must be set to 0.</b></p>	0	X	0   5	Pi Pe	5-4-8
	2	<p>Once the home routine is activated , motor will search for Home position switch in 1<sup>st</sup> speed in <b>CCW direction</b> and sets the Home reference position as soon as the input contact <b>ORG is activated</b>.  If <b>Pn365.1=2</b>, it will directly find the closest Rising-Edge of <b>ORG</b> to be the Home position (without a need for Home Reference), then it stops in accordance with <b>Pn365.3</b> setting.</p>					
3	<p>Once the home routine is activated , motor will search for Home Position switch in 1<sup>st</sup> speed in <b>CW direction</b> and sets the reference Home position as soon as the input contact <b>ORG is activated</b>.  If <b>Pn365.1=2</b>, it will directly find the closest rising -Edge of <b>ORG</b> to be the Home position (without a need for Home reference), then it stops in accordance with <b>Pn365.3</b> setting.</p>						

Parameter	Name & Functions		Default	Unit	Setting Range	Control Mode	Chapter
<b>Pn365.0</b> 	4	Once the home routine is activated , motor will search for Home position in 1 <sup>st</sup> speed in <b>CCW direction</b> and sets the Home reference position as soon as the nearest Z (marker pulse) is detected. When using this function, set <b>Pn365.1=2</b> . After setting the <b>Z</b> Phase to be the Home, it stops in accordance with the setting of <b>Pn365.3</b> .	0	X	0   5	Pi Pe	5-4-8
	5	Once the home routine is activated , motor will search for Home position in 1 <sup>st</sup> speed in <b>CW direction</b> and sets the Home reference position as soon as the nearest Z (marker pulse) is detected. When using this function, set <b>Pn365.1=2</b> . After setting the <b>Z</b> Phase to be the Home, it stops in accordance with the setting of <b>Pn365.3</b> .					
<b>Pn365.1</b> 	<b>Once Reference Home switch or Signal, is found it sets the search method for the Home position.</b>		0	X	0   2	Pi Pe	5-4-8
	<b>Setting</b>	<b>Explanation</b>					
	0	Once the Home Reference switch or signal is detected, motor <b>reverses direction</b> in 2 <sup>nd</sup> speed to find the nearest <b>Z</b> . Phase pulse and sets this as the Home position, then stops in accordance with <b>Pn365.3</b> setting method.					
	1	Once the Home Reference switch or signal is detected, motor <b>Continues in its direction</b> in 2 <sup>nd</sup> speed to find the nearest <b>Z</b> Phase pulse and sets this as the Home position, then stops in accordance with <b>Pn365.3</b> setting method.					
2	When <b>Pn365.0=2</b> or <b>3</b> , it finds the rising edge of ORG to be the Home position, then stops in accordance with <b>Pn365.3</b> .  When <b>Pn365.0=4</b> or <b>5</b> , it finds <b>Z</b> Phase pulse to be the Home, then stops in accordance with <b>Pn365.3</b> .						
<b>Pn365.2</b> 	<b>Setting of Home Routine Start method</b>		0	X	0   2		
	<b>Setting</b>	<b>Explanation</b>					
	0	Homing routine is <b>Disabled</b> .					
	1	On power up and activation of <b>Servo on</b> the home routine is started automatically. This method is useful for applications that do not require repeated home routines. No external home reference switch is required.					
2	Use <b>SHOME</b> input contact to start a home routine. In position mode, <b>SHOME</b> can be used to start a home routine at any moment.						

Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter	
<b>Pn365.3</b> 	<b>Setting of stopping mode after finding Home signal.</b>	0	X	0   1	Pi Pe	5-4-8	
	Setting						Explanation
	0						After detecting the Home signal, it <b>sets</b> this position to be the Home reference ( <b>Un-14</b> encoder feed back rotating number and <b>Un-15</b> encoder feed back pulse number are all 0), motor decelerates and stops. Then it reverses direction in 2 <sup>nd</sup> speed to detect the Home Position again then it decelerates and stops..
1	After detecting the Home signal, it <b>sets</b> this position to be the Home reference ( <b>Un-14</b> encoder feed back rotating number and <b>Un-15</b> encoder feed back pulse number are all 0), motor decelerates and stops.						
<b>Pn366</b>	<b>Machine Home reference search speed. 1<sup>st</sup> speed ( Fast)</b> HOME Refeence search speed . Speed 1.	100	rpm	0   2000	Pi Pe	5-4-8	
<b>Pn367</b>	<b>Machine Home position search speed. 2<sup>nd</sup> Speed (Slow)</b> Home <b>position</b> search speed . Speed 2.	50	rpm	0   500	Pi Pe	5-4-8	
<b>Pn368</b>	<b>Home position offset . Number of revolutions.</b> Once the searched home position is found in accordance with Pn365 (Home routine mode), then it will search by a number of revolutions and pulses set in parameters Pn368 and Pn 369 to find the new (off set) Home position.	0	rev	-30000   30000	Pi Pe	5-4-8	
<b>Pn369</b>	<b>Home position offset . Number of Pulses.</b> Home Offset position = Pn368(Rotate Number) x Number of Encoder Pulse per Rotation x 4 + Pn369(Pulse Number)	0	pulse	-32767   32767	Pi Pe	5-4-8	

## Quick Set-up Parameters



Parameter	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter
◆qn401	<b>Speed Loop Gain 1. (Same function as Sn211)</b>	40	Hz	10   450	Pi Pe S	5-3-8 5-5
	Speed loop gain has a direct effect on the frequency response bandwidth of the Speed-control loop. Without causing vibration or noise Speed-loop-gain can be increased to obtain a faster speed response. If <b>Cn025 (load Inertia ratio)</b> is correctly set, the speed-loop-bandwidth will equal to speed-loop-gain.					
◆qn402	<b>Speed-loop Integral time 1. (Same function as Sn212)</b>	100	x0.2 ms	1   500	Pi Pe S	5-3-8 5-5
	Speed loop integral element can eliminate the steady speed error and react to even slight speed variations. Decreasing Integral time can improve system rigidity. The formula below shows the relationship between Integral time and Speed loop Gain. $SpeedLoopIntegrationTimeConstant \geq 5 \times \frac{1}{2\pi \times SpeedLoopGain}$					
◆qn403	<b>Speed Loop Gain 2. (Same function as Sn213)</b>	40	Hz	10   450	Pi Pe S	5-3-8 5-5
	Refer to qn401					
◆qn404	<b>Speed Loop Integration Time Constant 2. (Same function as Sn214)</b>	100	x0.2 ms	1   500	Pi Pe S	5-3-8 5-5
	Refer to qn402					
◆qn405	<b>Position Loop Gain 1. (Same function as Pn310)</b>	40	1/s	1   450	Pi Pe	5-4-6 5-5
	Without causing vibration or noise on the mechanical system the position loop gain value can be increased to speed up response and shorten the positioning time. Generally, the position loop bandwidth should not be higher than speed loop bandwidth. The relationship is according to the formula below: $PositionLoopGain \leq 2\pi \times \frac{SpeedLoopGain}{5}$					
◆qn406	<b>Position Loop Gain 2 (Same function as Pn311)</b>	40	1/s	1   450	Pi Pe	5-4-6 5-5
	Please refer to qn405					
◆qn407	<b>Position Loop Feed Forward Gain</b>	0	%	0   100	Pi Pe	5-4-6 5-5
	It can be used to reduce the follow up error of position control and speed up the response. If the feed forward gain is too large, it might cause speed overshoot and in position oscillations which result in the repeated ON/OFF operation of the output contact <b>INP</b> ("In Position" output signal).					

## Multi-Function Input Parameters

All digital inputs D1 to D13 are programmable and can be set to one of the functions listed below.

Hn 501 which includes Hn 501.0 ,Hn501.1, Hn501.2 is used for digital input 1 ( D1-1).

Hn502 to Hn513 are used for setting digital inputs 2 to 13.( D1-2 to D1-13).

Parameter	Name & Function		Default	Unit	Setting Range	Control Mode	Chapter
★Hn501.0 ★Hn501.1 	<b>DI-1</b>		01	X	01   26	ALL	5-6-1
	Setting	Explanation					
		Signal Functions					
	01	<b>SON</b> Servo On					
	02	<b>ALRS</b> Alarm Reset					
	03	<b>PCNT</b> PI/P Switching					
	04	<b>CCWL</b> CCW Limit					
	05	<b>CWL</b> CW Limit					
	06	<b>TLMT</b> External Torque Limit					
	07	<b>CLR</b> Clear Pulse Error Value					
	08	<b>LOK</b> Servo Lock					
	09	<b>EMC</b> Emergency Stop					
	0A	<b>SPD1</b> Speed 1					
	0B	<b>SPD2</b> Speed 2					
	0C	<b>MDC</b> Control Mode Switch					
	0D	<b>INH</b> Position Command Inhibit					
	0E	<b>SPDINV</b> Speed Inverse					
	0F	<b>G-SEL</b> Gain Select					
	10	<b>GN1</b> Electronic Gear Ratio Numerator 1					
	11	<b>GN2</b> Electronic Gear Ratio Numerator 2					
	12	<b>PTRG</b> Position Trigger					
	13	<b>PHOLD</b> Position Hold					
	14	<b>SHOME</b> Start Home					
15	<b>ORG</b> Home Position Reference (Origin)						
16	<b>POS1</b> Internal Position select 1						
17	<b>POS2</b> Internal Position select 2						
18	<b>POS3</b> Internal Position select 3						
19	<b>POS4</b> Internal Position select 4						
1A	<b>TRQINV</b> Torque Inverse						
1B	<b>RS1</b> Torque CW Selecting						
1C	<b>RS2</b> Torque CCW Selecting						
★Hn501.2 	<b>DI-1 Logic State. NO/NC Selection</b>		0	X	0   1		
	Setting	Explanatoin					
	0	Input contact state. NO (Normally Open). Connecting (IG24) to inputs, enables the selected function.					
1	Input contact state. NC (Normally Closed). Disconnecting (IG24) from inputs, enables the selected function.						



★New setting will become effective after re-cycling the power.

**Warning!** If any of programmable Inputs of DI-1 ~ DI-13 are set for the same type of function then the logic state selection ( NO or NC selection) for these inputs must be the same type. Otherwise an Alarm will be displayed. AL-07 (Abnormal DI/DO programming).

Parameter Signal	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter
★Hn502	DI-2	002	X	001   11C	ALL	5-6-1
	Please refer to Hn501					
★Hn503	DI-3	003	X	001   11C	ALL	5-6-1
	Please refer to Hn501					
★Hn504	DI-4	104	X	001   11C	ALL	5-6-1
	Please refer to Hn501					
★Hn505	DI-5	105	X	001   11C	ALL	5-6-1
	Please refer to Hn501					
★Hn506	DI-6	006	X	001   11C	ALL	5-6-1
	Please refer to Hn501					
★Hn507	DI-7	007	X	001   11C	ALL	5-6-1
	Please refer to Hn501					
★Hn508	DI-8	008	X	001   11C	ALL	5-6-1
	Please refer to Hn501					
★Hn509	DI-9	009	X	001   11C	ALL	5-6-1
	Please refer to Hn501					
★Hn510	DI-10	00A	X	001   11C	ALL	5-6-1
	Please refer to Hn501					
★Hn511	DI-11	00B	X	001   11C	ALL	5-6-1
	Please refer to Hn501					
★Hn512	DI-12	00C	X	001   11C	ALL	5-6-1
	Please refer to Hn501					
★Hn513	DI-13	00E	X	001   11C	ALL	5-6-1
	Please refer to Hn501					

★New setting will become effective after re-cycling the power.

**Warning!** If any of programmable Inputs of DI-1 ~ DI-13 are set for the same type of function then the logic state selection ( NO or NC selection) for these inputs must be the same type. Otherwise an Alarm will be displayed. AL-07 (Abnormal DI/DO programming).

Parameter	Name & Function			Default	Unit	Setting Range	Control Mode	Chapter
★Hn514.0 ★Hn514.1 	<b>DO-1</b>			01	X	01   08	ALL	5-6-1
	Setting	Explanation						
		Signal	Functions					
	01	<b>RDY</b>	Servo Ready					
	02	<b>ALM</b>	Alarm					
	03	<b>ZS</b>	Zero Speed					
	04	<b>BI</b>	Brake Signal					
	05	<b>INS</b>	In Speed					
	06	<b>INP</b>	In Position					
07	<b>HOME</b>	HOME						
08	<b>INT</b>	In Torque						
★Hn514.2 	<b>DO-1</b>			0	X	0   1		
	Setting	Explanation						
	0	Close, when the output is activated.						
1	Open, when the output is activated.							
★Hn515	<b>DO-2</b>			002	X	001   108	ALL	5-6-1
	Please refer to <b>Hn514</b>							
★Hn516	<b>DO-3</b>			003	X	001   108	ALL	5-6-1
	Please refer to <b>Hn514</b>							
★Hn517	<b>DO-4</b>			006	X	001   108	ALL	5-6-1
	Please refer to <b>Hn514</b>							

***New setting will become effective after re-cycling the power.***

**Warning!** If any of programmable Inputs of DI-1 ~ DI-13 are set for the same type of function then the logic state selection ( NO or NC selection) for these inputs must be the same type. Otherwise an Alarm will be displayed. AL-07 (Abnormal DI/DO programming).



Parameter Signal	Name & Function	Default	Unit	Setting Range	Control Mode	Chapter										
Hn518	<p><b>Digital input control method selection.</b></p> <p>Select digital input (13 pins) control method by external terminal or communication. Convert Binary code to Hex code for setting this parameter. DI and binary bits table as below.</p> <p>Ex. DI-1 is bit 0 and DI-13 is bit 12.</p> <table border="1" style="margin-left: 40px;"> <tr> <td>DI-[ ]</td> <td>DI-13</td> <td>DI-12</td> <td>.....</td> <td>DI-1</td> </tr> <tr> <td>bit</td> <td>12</td> <td>11</td> <td>.....</td> <td>0</td> </tr> </table> <p>Binary code representation :  →" 0 " Digital input control by external terminal.  →" 1 " Digital input control by communication.</p> <p>Set H0000 for Hn518 represent DI-1 ~ DI-13 are controlled by external terminal and set H1FFF represent all terminal is controlled by communication.</p> <p>Ex. Set DI (1, 3, 6, 10, 12) for communication control other pins by external terminal;  The corresponding binary code is :[0 1010 0010 0101] convert to Hex code is : [H 0A25]for entering parameter.  For the setting Bit0 (DI-1) is control by communication and Bit1 (DI-2) is control by external terminal ....etc</p>	DI-[ ]	DI-13	DI-12	.....	DI-1	bit	12	11	.....	0	H0000	X	H0000   H1FFF (HEX)	ALL	5-6-1 7
DI-[ ]	DI-13	DI-12	.....	DI-1												
bit	12	11	.....	0												
Hn519	<p><b>Setting digital input status in communication mode</b></p> <p>Change Hn519 Hex code for setting digital input status of communication control mode; Setting method refer Hn518.</p> <p>Binary code representation :  "0" : digital input contact OFF  "1" : digital input contact ON</p> <p>Set H0000 for Hn518 represent DI-1 ~ DI-13 are controlled by external terminal and set H1FFF represent all terminal is controlled by communication.</p> <p><b>P.S.)This parameter should co-operate with Hn518.</b></p>	H0000	X	H0000   H1FFF (HEX)	ALL	5-6-1 7										

## Display Parameter

Parameter Signal	Display	Unit	Explanation
Un-01	Actual Motor Speed	rpm	Motor Speed is displayed in rpm.
Un-02	Actual Motor Torque	%	It displays the torque as a percentage of the rated torque. Ex: 20 are displayed. It means that the motor torque output is 20% of rated torque.
Un-03	Regenerative load rate	%	Value for the processable regenerative power as 100% . Displays regenerative power consumption in 10-s cycle.
Un-04	Accumulated load rate	%	Value for the rated torque as 100%. Displays effective torque in 10-s cycle.
Un-05	Max load rate	%	Max value of accumulated load rate
Un-06	Speed Command	rpm	Speed command is displayed in rpm.
Un-07	Position Error Value	pulse	Error between position command value and the actual position feedback.
Un-08	Position Feed-back Value	pulse	The accumulated number of pulses from the encoder.
Un-09	ExternalVoltage Command	V	External analog voltage command value in volts.
Un-10	(Vdc Bus)Main Loop Voltage	V	DC Bus voltage in Volts.
Un-11	External Spdd Limit Command Value	rpm	External speed limit value in rpm.
Un-12	External CCW Torque Limit Command Value	%	Ex: Display 100. Means current external CCW torque limit command is set to 100 %.
Un-13	External CW Torque LimitCommand Value	%	Ex: Display 100. Means current external CW toque limit command is set to 100%.
Un-14	Motor feed back – Rotation value (absolute value)	rev	After power on, it displays motor rotation number as an absolute value.
Un-15	Motor feed back – Less than 1 rotation pulse value(absolute value)	pulse	After power on, it displays the number of pulses for an incomplete revolution of the motor as an absolute value.
Un-16	Pulse command – rotation value(absolute value)	rev	After power on, it displays pulse command input rotation number in absolute value.
Un-17	Pulse command – Less than 1 rotation pulse value(absolute value)	pulse	After power on, it displays pulse command input for an incomplete rotation. pulse value is an absolute value.
Un-18	Torque command	%	It displays the torque command as a percentage of the rated torque. Ex: Display. 50.Means current motor torque command is 50% of rated torque.
Un-19	Load inertia	x0.1	When Cn002.2=0(Auto gain adjust disabled), it displays the current preset load inertia ratio from parameter Cn025. When <b>Cn002.2=1</b> (Auto gain adjust enabled), it displays the current estimated load inertia ratio.

## Diagnosis Parameter

Parameter	Name & Function	Chapter
<b>dn-01</b>	Selected control mode	3-2-2
<b>dn-02</b>	Output terminal signal status.	
<b>dn-03</b>	Input terminal signal status.	
<b>dn-04</b>	Software version	
<b>dn-05</b>	JOG mode operation	
<b>dn-06</b>	Hold position.	
<b>dn-07</b>	Auto offset adjustment of external analog command voltage.	
<b>dn-08</b>	Servo model code.	

# Chapter 7 Communications function

## 7-1 Communications function ( RS-232 & RS-485 )

The Servo drive provides RS232 communication. The description below shows the communication wiring and communication protocol.

### 7-1-1 Communication wiring


#### RS-232

##### Driver terminal D-Type 9Pins

Pin	Description	Name
1	unassignment	
2	Transmit Data	TxD
3	Receive Data	RxD
4	unassignment	
5	Ground	GND
6	unassignment	
7	unassignment	
8	unassignment	
9	unassignment	

##### PC terminal D-Type 9Pins(female)

Pin	Description	Name
1	Protective Ground	PG
2	Receive Data	RxD
3	Transmit Data	TxD
4	Data Terminal Ready	DTR
5	Ground	GND
6	Data Set Ready	DSR
7	Request to Send	RTS
8	Clear to Send	CTS
9	Ring indicator	RI



Pin 4 and Pin 6 is a close loop  
Pin 7 and Pin 8 is a close loop


#### RS-485

##### Driver terminal D-Type 9Pins

Pin	Description	Name
1	unassignment	
2	unassignment	
3	unassignment	
4	unassignment	
5	unassignment	
6	unassignment	
7	Serial transmission	Data+
8	unassignment	
9	Serial transmission	Data-

##### PC terminal D-Type 9Pins(female)

Pin	Description	Name
1	Protective Ground	PG
2	Receive Data	RxD
3	Transmit Data	TxD
4	Data Terminal Ready	DTR
5	Ground	GND
6	Data Set Ready	DSR
7	Request to Send	RTS
8	Clear to Send	CTS
9	Ring indicator	RI



## 7-1-2 RS-232 Communication protocol and format

Baud rate	9600bps (Selection by Cn037.1 )
Parity	No
Data bit	8
Stop bit	1

※ Symbol H in following sentence is for Hex representation.

### (1) Read a word from servo drive ▶ Function code format: **R5XxSs**

Xx : A request to read register " Xx " from slave device( Unit :Byte, Hex representation)

Ss : Check Sum Ss = 'R'+ '5'+ 'X'+ 'x' ( Unit :Byte 、 Hex representation)

Ex1: Read register address 30H and

( Convert 『R530』 into ASCII codes )

Check Sum=52H+35H+33H+30H=EA H

→ R 5 3 0

Obtain Function code for read register address 30H: 『R530EA』

Servo drive response : %XxYySs

Ss is Check Sum, Ss='%'+'X'+ 'x'+ 'Y'+ 'y'

Response message of example 1:

0008H is the data store in register address 30H:

Check Sum=25H+30H+30H+30H+38H=EDH

% 0 0 0 8

Drive response message: 『%0008ED』

\* When function code incorrect , drive response : 『!』 (ASCII code: 21H )

**(2) Read consecutive 2 words from drive** ▶ Function code format: L5NnSs

Nn : A request to read register “ Nn ” from slave device ( Unit :Byte, Hex representation)

Ss : Check Sum · Ss = 'L'+ '5'+ 'N'+ 'n' ( Unit : Byte, Hex representation)

Ex2: Read data from register address 60H and

( Convert 『 L560 』 into ASCII codes )

Check Sum=4CH+35H+36H+30H=E7

L 5 6 0

Obtain Function code for read register address 60H: 『 L560E7 』

Servo drive response: %XxYyAaBbSs

Ss is Check Sum · Ss='%'+ 'X'+ 'x'+ 'Y'+ 'y' + 'A'+ 'a'+ 'B'+ 'b'

XxYy is the data store in register address Nn+1,

AaBb is the data store in register address Nn

Response message of example 2:

0001 000AH is the data store in register 60H

Check Sum=25H+30H+30H+30H+31H+30H+30H +30H+41H=1B7H

% 0 0 0 1 0 0 0 A

Drive response message: 『 %0001000AB7 』

\* When function code incorrect , drive response : 『 ! 』 (ASCII code: 21H )

**(3) Write a word to drive** ▶ Function code format: W5XxYyZzSs

Xx : Address for write data ( Unit :Byte 、 Hex representation)

YyZz : Writes the data contents ( Unit :word, Hex representation)

Ss : Check Sum , Ss ='W'+5+'X'+x+'Y'+y+'Z'+z' ( Unit :Byte, Hex representation)

Ex3 : Write data 0008H to register 30H

( Convert 『W5300008』 into ASCII codes )

Check Sum=57H+35H+33H+30H+30H+30H+30H+38H=1B7H

W 5 3 0 0 0 0 8

Obtain Function code for write data 0008H to register 30H : 『W5300008B7』

Drive response message : 『%』 (ASCII code :25H)

\* When function code incorrect , drive response : 『!』 (ASCII code: 21H)

**(4) Write consecutive 2 words to drive** ▶ Function code format: M5NnXxYyAaBbSs

Nn : Address for write data( Unit :Byte 、 Hex representation)

XxYy : Writes the data contents of address Nn+1 ( Unit :Word 、 Hex representation)

AaBb : Writes the data contents of address Nn ( Unit :Word 、 Hex representation)

Ss : Check Sum , Ss ='M'+5+'N'+n+'X'+x+'Y'+y+'A'+a+'B'+b' ( Unit :Byte 、 Hex representation)

Ex4: Write data 0002 000BH to register 60H

( Convert 『M5600002000B』 into ASCII codes )

Check Sum=4DH+35H+36H+30H+30H+30H+30H+32H+30H+30H+30H+42H =27CH

M 5 6 0 0 0 0 2 0 0 0 B

Obtain Function code for write data 0002000BH to register 60H : 『M5600002000B7C』

Drive response message: 『%』 (ASCII code :25H)

\* When function code incorrect , drive response : 『!』 (ASCII code: 21H)

### 7-1-3 Modbus communication protocol for RS-485

The MODBUS protocol allows an easy communication within types of network architectures, before start to communication with slave device, set the ID number ( **Cn036** ) for Servo drive respectively, server distinguish ID number for controlling specific client station.

Standard Modbus networks combine two transmission modes: ASCII or RTU: ASCII(American Standard Code for information interchange) Mode and RTU (Remote Terminal Unit) Mode, Use **Cn038** to select ASCII or RTU mode.

#### Coding method

##### ASCII Mode

8-bits Data consist of two ASCII code.

Ex: Data 26H 1-byte , the '26' convert to ASCII code is include character '2' → <32H> and '6' →<36H>

ASCII Chart ( 0 ~ 9 and A ~ F ):

Character	'0'	'1'	'2'	'3'	'4'	'5'	'6'	'7'
ASCII code(Hex)	30H	31H	32H	33H	34H	35H	36H	37H
Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII code(Hex)	38H	39H	41H	42H	43H	44H	45H	46H

##### RTU Mode


Each 8bits is consist of 2 Hex number (4-bits per Hex number).

Ex.: Data 26H, the data length is 1-byte.




## ASCII Mode Framing

### 10 bits Frame (7-bits Data)



### 11 bits Frame (8-bits Data)



## ASCII Mode Framing

Symbol	Name	Description
STX	Comm. start	3AH, Char ':'
ADR	Slave address	Include 2 ASCII code within 1-byte Comm. add : 1 ~ 254 convert to Hex representation ; Ex. Servo drive ADR is No.20 convert to 14H ; ADR = '1', '4' → '1' = 31H, '4' = 34H
Function Code	Function code	Include 2 ASCII code within 1-byte <b>Function codes</b> : 03H : Read the register contents, 06H : Write Single Register , 08H : Diagnostic function, 10H : Write Multipile Registers
DATA(n-1)   DATA(0)	Data	n-word = 2n-byte (ASCII numbers : 4n ), $n \leq 30$ The format of data is depend on Function code
LRC	Check code	Include 2 ASCII code within 1-byte
END 1	END 1 (CR)	0DH ; Char '\r'
END 0	END 0 (LF)	0AH ; Char '\n'

## RTU Mode

Symbol	Name	Description
STX	Comm. start	Excess comm. loss time setting 10ms
ADR	Slave address	1-byte Comm. address : 1 ~ 254 , convert to Hex representation ; Ex. Comm. address = 20 convert representation to 14 Hex, ADR = '14H'
Function Code	Function code	1-byte <b>Function codes</b> : 03H : Read the register contents, 06H : Write Single Register , 08H : Diagnostic function, 10H : Write Multipile Registers
DATA(n-1)   DATA(0)	Data	n-word = 2n-byte ; $n \leq 30$ The format of data is depend on Function code
CRC-Low	Checking code-LO	1-byte
CRC-High	Checking code-HI	1-byte
END 0	End 0	Excess comm. loss time setting 10ms

## Common function codes

03H : Read the register contents

Continuous read N words. \* Largest number of N is 29 (1DH)

Ex.: Read two words ( register 0200H and 0201H ) from Slave address 01H.

## ASCII Mode

Query PC → Servo		Response Servo → PC OK		Servo → PC (ERROR)	
STX		STX		STX	
ADR		ADR		ADR	
Function Code		Function Code		Function Code	
Register ADD.	(Hi)	Data length (byte)		Exception code	
	(Lo)	Data of 0200H		LRC	
Data length (word)		Data of 0201H		END1 (CR)	
LRC		LRC		END0 (LF)	
END1 (CR)		END1 (CR)		END0 (LF)	
END0 (LF)		END0 (LF)		END0 (LF)	

## RTU Mode

Query PC → Servo		Response Servo → PC (OK)		Servo → PC (ERROR)	
ADR		ADR		ADR	
Function Code		Function Code		Function Code	
Register ADD	(Hi)	Data (Byte)		Exception	
	(Lo)	Data of 0200H		CRC(Lo)	
Data length (word)		Data of 0201H		CRC(Hi)	
CRC(Lo)		CRC(Lo)		CRC(Hi)	
CRC(Hi)		CRC(Hi)		CRC(Hi)	

## 06H : Write Single Register

Write a word into register.

Ex : Write data (0064H) into register address 0200H and slave ADR= 01

## ASCII Mode

Query PC → Servo

STX		' :
ADR		' 0 '
		' 1 '
Function Code		' 0 '
		' 6 '
Register ADD	(Hi)	' 0 '
		' 2 '
	(Lo)	' 0 '
		' 0 '
Write data (word)		' 0 '
		' 0 '
		' 6 '
		' 4 '
LRC		' 9 '
		' 3 '
END1 (CR)		(0DH)
END0 (LF)		(0AH)

Response Servo → PC (OK)

STX		' :
ADR		' 0 '
		' 1 '
Function Code		' 0 '
		' 6 '
Register ADD.	(Hi)	' 0 '
		' 2 '
	(Lo)	' 0 '
		' 0 '
Write data (word)		' 0 '
		' 0 '
		' 6 '
		' 4 '
LRC		' 9 '
		' 3 '
END1 (CR)		(0DH)
END0 (LF)		(0AH)

Servo → PC (ERROR)

STX		' :
ADR		' 0 '
		' 1 '
Function Code		' 8 '
		' 6 '
Exception code		' 0 '
		' 3 '
LRC		' 7 '
		' 6 '
END1 (CR)		(0DH)
END0 (LF)		(0AH)

## RTU Mode

Query PC → Servo

ADR		01H
Function Code		06H
Register ADD	(Hi)	02H
	(Lo)	00H
Write data (word)		00H
		64H
CRC(Lo)		89H
CRC(Hi)		99H

Response Servo → PC (OK)

ADR		01H
Function Code		03H
Register ADD.	(Hi)	02H
	(Lo)	00H
Write data (word)		00H
		64H
CRC(Lo)		89H
CRC(Hi)		99H

Servo → PC (ERROR)

ADR		01H
Function Code		86H
Exception code		03H
CRC(Lo)		02H
CRC(Hi)		61H

08H : Diagnostic function

The sub-function code 0000H is able to check communication signal between Master and Slaver. Data content is random value.

Ex: Use the diagnostic function for ID=01H

### ASCII Mode

Query PC → Servo

STX		‘.’
ADR		‘0’
		‘1’
Function Code		‘0’
		‘8’
Sub-Function	(HI)	‘0’
		‘0’
	(Lo)	‘0’
		‘0’
Data (word)		‘A’
		‘5’
		‘3’
		‘7’
LRC		‘1’
		‘B’
END1 (CR)		(0DH)
END0 (LF)		(0AH)

Response Servo → PC (OK)

STX		‘.’
ADR		‘0’
		‘1’
Function Code		‘0’
		‘8’
Sub-Function	(HI)	‘0’
		‘0’
	(Lo)	‘0’
		‘0’
Data (word)		‘A’
		‘5’
		‘3’
		‘7’
LRC		‘1’
		‘B’
END1 (CR)		(0DH)
END0 (LF)		(0AH)

Servo → PC (ERROR)

STX		‘.’
ADR		‘0’
		‘1’
Function Code		‘8’
		‘8’
Exception code		‘0’
		‘3’
LRC		‘7’
		‘4’
END1 (CR)		(0DH)
END0 (LF)		(0AH)

### RTU Mode

Query PC → Servo

ADR		01H
Function Code		08H
Sub-Function	(HI)	00H
	(Lo)	00H
Data (word)		A5H
		37H
CRC(Lo)		DAH
CRC(Hi)		8DH

Response Servo → PC (OK)

ADR		01H
Function Code		08H
Sub-Function	(HI)	00H
	(Lo)	00H
Data (word)		A5H
		37H
CRC(Lo)		DAH
CRC(Hi)		8DH

Servo → PC (ERROR)

ADR		01H
Function Code		88H
Exception code		03H
CRC(Lo)		06H
CRC(Hi)		01H

## 10H : Write Multiple Registers

Continuously write N words to register. \* Largest number of N is 27 (1BH)

Ex.: Write data (0064H) and (012CH) into register address 100H and 101H respectively.

### ASCII Mode

Query PC → Servo

STX		‘:’
ADR		‘0’
		‘1’
Function Code		‘1’
		‘0’
Register ADD	(HI)	‘0’
		‘1’
	(Lo)	‘0’
		‘0’
Data length (word)		‘0’
		‘0’
		‘0’
		‘2’
Byte counters (byte)		‘0’
		‘4’
ADD. 0100H	(HI)	‘0’
		‘0’
	(Lo)	‘6’
		‘4’
ADD. 0101H	(HI)	‘0’
		‘1’
	(Lo)	‘C’
		‘2’
LRC		‘5’
		‘7’
END1 (CR)		(0DH)
END0 (LF)		(0AH)

Response Servo → PC (OK)

STX		‘:’
ADR		‘0’
		‘1’
Function Code		‘1’
		‘0’
Register ADD	(HI)	‘0’
		‘1’
	(Lo)	‘0’
		‘0’
Data length (word)		‘0’
		‘0’
		‘0’
		‘2’
LRC		‘E’
		‘C’
END1 (CR)		(0DH)
END0 (LF)		(0AH)

Servo → PC (ERROR)

STX		‘:’
ADR		‘0’
		‘1’
Function Code		‘9’
		‘0’
Exception code		‘0’
		‘2’
LRC		‘6’
		‘D’
END1 (CR)		(0DH)
END0 (LF)		(0AH)

## RTU Mode

ADR	01H	
Function Code	10H	
Register ADD	(Hi)	01H
	(Lo)	00H
Data length (word)	00H	
	02H	
Byte counters	04H	
Data 0100H	(Hi)	00H
	(Lo)	64H
Data 0101H	(Hi)	01H
	(Lo)	2CH
CRC(Lo)	BFH	
CRC(Hi)	ADH	

ADR	01H	
Function Code	10H	
Register ADD	(Hi)	01H
	(Lo)	00H
Data length (word)	00H	
	02H	
CRC(Lo)	40H	
CRC(Hi)	34H	

ADR	01H	
Function Code	90H	
Exception code	02H	
CRC(Lo)	CDH	
CRC(Hi)	C1H	

## LRC (ASCII Mode ) and CRC (RTU Mode) Check methods

### LRC Checking:

ASCII Mode LRC (Longitudinal Redundancy Check) checking method

The LRC is calculated by adding together successive 8-bit bytes of the message, discarding any carries.

Ex. add ADR, Function code, register address and data contents together, if it get the sum 19DH then discard carrier "1" and find two's complement for 9DH to obtain LRC code.

Ex: Execute diagnostic function for Servo drive ID =01H

STX	' :	
ADR	' 0 '	
	' 1 '	
Function code	' 0 '	
	' 8 '	
Sub-function	(Hi)	' 0 '
		' 0 '
	(Lo)	' 0 '
		' 0 '

Data (word)	' A '
	' 5 '
	' 3 '
	' 7 '
LRC	' 1 '
	' B '
END1 (CR)	(0DH)
END0 (LF)	(0AH)

$$01H+08H+00H+00H+A5H+37H = E5H$$

Two's complement for E5H is 1BH ; derive LRC code: ' 1 ', ' B '

## CRC Checking:

CRC check code is from Slave Address to end of the data. The calculation method is illustrated as follow:

- (1) Load a 16-bit register with FFFF hex (all 1's). Call this the CRC register.
- (2) Exclusive OR the first 8-bit byte of the message with the low-order byte of the 16-bit CRC register, putting the result in the CRC register.
- (3) Shift the CRC register one bit to the right (toward the LSB), Zero-filling the MSB, Extract and examines the LSB.
- (4) (If the LSB was 0): Repeat Steps (3) (another shift) (If the LSB was 1): Exclusive OR the CRC register with the polynomial value A001 hex (1010 0000 0000 0001).
- (5) Repeat Steps (3) and (4) until 8 shifts been performed. When this is done, a complete 8-bit byte will be processed.
- (6) Repeat Steps (2) through (5) for next 8-bit byte of the message, Continue doing this until all bytes have been processed. The final content of the CRC register is the CRC value.

Placing the CRC into the message:

When the 16-bit CRC (2 8-bit bytes) is transmitted in the message, the low-order byte will be transmitted first, followed by the high-order byte, For example, if the CRC value is 1241 hex, the CRC-16 (Low) put the 41h, the CRC-16 (Hi) put the 12h.

Example :

An example of a C language function performing CRC generation is shown on the following pages. All of the possible CRC values are preloaded into two arrays, which are simply indexed as the function increments through the message buffer. One array contains all of the 256 possible CRC values for the high byte of the 16-bit CRC field, and the other array contains all of the values for the low byte.

Indexing the CRC in this way provides faster execution than would be achieved by calculating a new CRC value with each new character from the message buffer.

Note

This function performs the swapping of the high/low CRC bytes internally. The bytes are already swapped in the CRC value that is returned from the function.

Therefore the CRC value returned from the function can be directly placed into the message for transmission.

The function takes two arguments:

- |                            |  |
|----------------------------|--|
| unsigned char *puchMsg ;   | A pointer to the message buffer containing binary data to be used for generating the CRC |
| unsigned short usDataLen ; | The quantity of bytes in the message buffer.   |

The function returns the CRC as a type unsigned short.



## CRC Generation Function

```
unsigned short CRC16(puchMsg, usDataLen)
unsigned char *puchMsg ;                               /* message to calculate CRC upon*/
unsigned short usDataLen ;                             /* quantity of bytes in message*/
{
unsigned char uchCRCHi = 0xFF ;                       /* high byte of CRC initialized*/
unsigned char uchCRCLo = 0xFF ;                       /* low byte of CRC initialized*/
unsigned uIndex ;                                     /* will index into CRC lookup table*/

while (usDataLen--)                                  /* pass through message buffer
{
uIndex = uchCRCHi ^ *puchMsgg++ ;                   /* calculate the CRC*/
uchCRCHi = uchCRCLo ^ auchCRCHi[uIndex] ;
uchCRCLo = auchCRCLo[uIndex] ;
}
return (uchCRCHi << 8 | uchCRCLo) ;
}
```

## High-Order Byte Table

*/\* Table of CRC values for high-order byte \*/*

```
static unsigned char auchCRCHi[] = {
0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81,
0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0,
0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x00, 0xC1, 0x81, 0x40, 0x01,
0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41,
0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x00, 0xC1, 0x81,
0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0,
0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x01,
0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40,
0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80,
0x41, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0,
0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x01,
0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41,
0x00, 0xC1, 0x81, 0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x00, 0xC1, 0x81,
0x40, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0, 0x80, 0x41, 0x01, 0xC0,
0x40
};
```

## Low-Order Byte Table

/\* Table of CRC values for low-order byte \*/

```
static char auchCRCLo[] = {
0x00, 0xC0, 0xC1, 0x01, 0xC3, 0x03, 0x02, 0xC2, 0xC6, 0x06, 0x07, 0xC7, 0x05, 0xC5, 0xC4,
0x04, 0xCC, 0x0C, 0x0D, 0xCD, 0x0F, 0xCF, 0xCE, 0x0E, 0x0A, 0xCA, 0xCB, 0x0B, 0xC9, 0x09,
0x08, 0xC8, 0xD8, 0x18, 0x19, 0xD9, 0x1B, 0xDB, 0xDA, 0x1A, 0x1E, 0xDE, 0xDF, 0x1F, 0xDD,
0x1D, 0x1C, 0xDC, 0x14, 0xD4, 0xD5, 0x15, 0xD7, 0x17, 0x16, 0xD6, 0xD2, 0x12, 0x13, 0xD3,
0x11, 0xD1, 0xD0, 0x10, 0xF0, 0x30, 0x31, 0xF1, 0x33, 0xF3, 0xF2, 0x32, 0x36, 0xF6, 0xF7,
0x37, 0xF5, 0x35, 0x34, 0xF4, 0x3C, 0xFC, 0xFD, 0x3D, 0xFF, 0x3F, 0x3E, 0xFE, 0xFA, 0x3A,
0x3B, 0xFB, 0x39, 0xF9, 0xF8, 0x38, 0x28, 0xE8, 0xE9, 0x29, 0xEB, 0x2B, 0x2A, 0xEA, 0xEE,
0x2E, 0x2F, 0xEF, 0x2D, 0xED, 0xEC, 0x2C, 0xE4, 0x24, 0x25, 0xE5, 0x27, 0xE7, 0xE6, 0x26,
0x22, 0xE2, 0xE3, 0x23, 0xE1, 0x21, 0x20, 0xE0, 0xA0, 0x60, 0x61, 0xA1, 0x63, 0xA3, 0xA2,
0x62, 0x66, 0xA6, 0xA7, 0x67, 0xA5, 0x65, 0x64, 0xA4, 0x6C, 0xAC, 0xAD, 0x6D, 0xAF, 0x6F,
0x6E, 0xAE, 0xAA, 0x6A, 0x6B, 0xAB, 0x69, 0xA9, 0xA8, 0x68, 0x78, 0xB8, 0xB9, 0x79, 0xBB,
0x7B, 0x7A, 0xBA, 0xBE, 0x7E, 0x7F, 0xBF, 0x7D, 0xBD, 0xBC, 0x7C, 0xB4, 0x74, 0x75, 0xB5,
0x77, 0xB7, 0xB6, 0x76, 0x72, 0xB2, 0xB3, 0x73, 0xB1, 0x71, 0x70, 0xB0, 0x50, 0x90, 0x91,
0x51, 0x93, 0x53, 0x52, 0x92, 0x96, 0x56, 0x57, 0x97, 0x55, 0x95, 0x94, 0x54, 0x9C, 0x5C,
0x5D, 0x9D, 0x5F, 0x9F, 0x9E, 0x5E, 0x5A, 0x9A, 0x9B, 0x5B, 0x99, 0x59, 0x58, 0x98, 0x88,
0x48, 0x49, 0x89, 0x4B, 0x8B, 0x8A, 0x4A, 0x4E, 0x8E, 0x8F, 0x4F, 0x8D, 0x4D, 0x4C, 0x8C,
0x44, 0x84, 0x85, 0x45, 0x87, 0x47, 0x46, 0x86, 0x82, 0x42, 0x43, 0x83, 0x41, 0x81, 0x80,
0x40
};
```

## Exception Codes

When communication error occur , servo drive is returned with an error code and Function code+80H return to the ModBus host controller.

Code	Name	Description
01	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the server (or slave).
02	ILLEGAL DATA ADD.	The data address received in the query is not an allowable address for the server (or slave).
03	ILLEGAL DATA VALUE	A value contained in the query data field is not an allowable value for server (or slave).
04	SLAVE DEVICE FAILURE	An unrecoverable error occurred while the server (or slave) was attempting to perform the requested action.
05	RTU CHECK FAILURE	RTU mode: CRC check error
06	ASCII CHECK FAILURE	ASCII mode: LRC check error or no end code(CRLF)

## 7-2 Communication address table

All parameters allow to write data by communication excluding display parameters.

### System parameters

Address		Parameter	Name of parameter
RS485	RS232		
0001	510H	Cn001	Control Mode
0002	51DH	Cn002	DI Contacts function and Auto tuning
0003	511H	Cn003	Output time setting for Mechanical Brake Signal
0004	512H	Cn004	Motor rotation direction
0005	513H	Cn005	Encoder pulse output scale
0006	514H	Cn006	Analog Monitor output Selection
0007	515H	Cn007	Value for Speed reached
0008	516H	Cn008	Brake Modes
0009	517H	Cn009	CW/CCW Drive inhibit
000A	518H	Cn010	CCW Torque command limit
000B	519H	Cn011	CW Torque command limit
000C	51AH	Cn012	Power setting for external Re-generation resistor
000D	5DEH	Cn013	Frequency of Notch Filter (Resonance Filter)
000E	5DFH	Cn014	Band Width of the Resonance Filter.
000F	58FH	Cn015	Gain selection.
0010	5F8H	Cn016	PI/P control switch Mode (Torque Command)
0011	5F9H	Cn017	PI/P control switch Mode (Speed Command)
0012	5FAH	Cn018	Switch-condition in PI/P mode (accelerate Command )
0013	5FBH	Cn019	PI/P control switch Mode (position error number)
0014	53CH	Cn020	Automatic Gain 1 & 2 switch delay time
0015	53DH	Cn021	Automatic Gain 1 & 2 switch condition (Torque command)
0016	53EH	Cn022	Automatic Gain 1 & 2 switch condition (Speed Command)
0017	53FH	Cn023	Automatic Gain 1 & 2 switch condition (Acceleration Command)
0018	540H	Cn024	Automatic Gain 1 & 2 switch condition (Position error value)
0019	587H	Cn025	Load-Inertia ratio
001A	5D0H	Cn026	Rigidity Setting
001B	58BH	Cn027	Analog monitor output 1 for offset adjustment
001C	58CH	Cn028	Analog monitor output 2 for offset adjustment
001D	5FDH	Cn029	Reset Parameter
001E	50BH	Cn030	Servo motor model code
001F	50EH	Cn031	Cooling fan running mode
0020	546H	Cn032	Speed feed-back smoothing filter
0021	51EH	Cn033	Speed Feed-forward smoothing filter
0022	5B8H	Cn034	Torque command smoothing filter
0023	541H	Cn035	Panel display content selection

Address		Parameter	Name of parameter
RS485	RS232		
0024	51BH	Cn036	Servo ID number
0025	544H	Cn037	Braud rate setting for (Modbus RS-485 / PC Software RS-232)
0026	545H	Cn038	Communication protocol selection
0027	567H	Cn039	Communication time-out dection time
0028	579H	Cn040	Communication response delay time

### **Torque control parameters**

Address		Parameter	Name of parameter
RS485	RS232		
0101	520H	Tn101	Linear acceleration/deceleration method selection
0102	523H	Tn102	Linear acceleration/deceleration time period
0103	521H	Tn103	Analog Torque Command Ratio
0104	522H	Tn104	Analog torque command offset
0105	526H	Tn105	Internal Speed Limit 1
0106	527H	Tn106	Internal Speed Limit 2
0107	528H	Tn107	Internal Speed Limit 3
0108	5CDH	Tn108	Torque output monitor value

### **Speed control parameters**

Address		Parameter	Name of parameter
RS485	RS232		
0201	536H	Sn201	Internal Speed Command 1
0202	537H	Sn202	Internal Speed Command 2
0203	538H	Sn203	Internal Speed Command 3
0204	529H	Sn204	Zero Speed preset selection
0205	52AH	Sn205	Speed command acceleration / deceleration methods
0206	52BH	Sn206	Speed command Smooth acceleration/deceleration-time constant
0207	52CH	Sn207	Speed command Linear acceleration/deceleration time constant
0208	52DH	Sn208	S curve speed command acceleration and deceleration time setting
0209	52EH	Sn209	S curve speed command acceleration time setting
020A	52FH	Sn210	S curve speed command deceleration time setting
020B	530H	Sn211	Speed loop Gain 1
020C	531H	Sn212	Speed-loop Integral time constant 1
020D	53AH	Sn213	Speed loop Gain 2
020E	53BH	Sn214	Speed loop Integral time constant 2
020F	532H	Sn215	Value of zero speed

Address		Parameter	Name of parameter
RS485	RS232		
0210	533H	Sn216	Analog Speed Command Ratio
0211	534H	Sn217	Analog Speed Command offset adjust
0212	599H	Sn218	Analog Speed Command Limit

### Position control parameters

Address		Parameter	Name of parameter
RS485	RS232		
0301H	550H	Pn301	Position command selection (for pulse type 、 logic and drive inhizibit )
0302H	560H	Pn302	Electronic Gear Ratio Numerator 1
0303H	561H	Pn303	Electronic Gear Ratio Numerator 2
0304H	562H	Pn304	Electronic Gear Ratio Numerator 3
0305H	563H	Pn305	Electronic Gear Ratio Numerator 4
0306H	554H	Pn306	Electronic Gear Ratio Denominator
0307H	552H,553H	Pn307	Position complete value
0308H	556H,557H	Pn308	Position error band upper limit
0309H	558H,559H	Pn309	Position error band lower limit
030AH	55AH	Pn310	Position Loop Gain 1
030BH	551H	Pn311	Position Loop Gain 2
030CH	55BH	Pn312	Position Loop Feed Forward Gain
030DH	55CH	Pn313	Position command Smooth Accel/Decel time constant
030EH	55DH	Pn314	Position Command Direction definition
030FH	51FH	Pn315	Position Pulse error clear mode
0310H	50DH	Pn316	Internal Position Command Mode
0311H	568H	Pn317	Internal Position Command 1-Rotation Number
0312H	569H	Pn318	Internal Position Command 1-Pulse Number
0313H	56AH	Pn319	Internal Position Command 1-Move Speed
0314H	56BH	Pn320	Internal Position Command 2-Rotation number
0315H	56CH	Pn321	Internal Position Command 2-Pulse Number
0316H	56DH	Pn322	Internal Position Command 2-Move Speed
0317H	56EH	Pn323	Internal Position Command 3-Rotation number
0318H	56FH	Pn324	Internal Position Command 3-Pulse Number
0319H	575H	Pn325	Internal Position Command 3-Moving Speed
031AH	576H	Pn326	Internal Position Command 4-Rotation number
031BH	577H	Pn327	Internal Position Command 4-Pulse Number
031CH	578H	Pn328	Internal Position Command 4-Move Speed
031DH	59CH	Pn329	Internal Position Command 5-Rotation Number
031EH	59DH	Pn330	Internal Position Command 5-Pulse Number

Address		Parameter	Name of parameter
RS485	RS232		
031FH	59EH	Pn331	Internal Position Command 5- Move Speed
0320	59FH	Pn332	Internal Position Command 6-Rotation Number
0321	5A0H	Pn333	Internal Position Command 6-Pulse Number
0322	5A1H	Pn334	Internal Position Command 6- Move Speed
0323	5A2H	Pn335	Internal Position Command 7-Rotation Number
0324	5A3H	Pn336	Internal Position Command 7-Pulse Number
0325	5A4H	Pn337	Internal Position Command 7- Move Speed
0326	5A5H	Pn338	Internal Position Command 8-Rotation Number
0327	5A6H	Pn339	Internal Position Command 8-Pulse Number
0328	5A7H	Pn340	Internal Position Command 8- Move Speed
0329	5A8H	Pn341	Internal Position Command 9-Rotation Number
032A	5A9H	Pn342	Internal Position Command 9-Pulse Number
032B	5AAH	Pn343	Internal Position Command 9- Move Speed
032C	5ABH	Pn344	Internal Position Command 10-Rotation Number
032D	5ACH	Pn345	Internal Position Command 10-Pulse Number
032E	5ADH	Pn346	Internal Position Command 10-Move Speed
032F	5AEH	Pn347	Internal Position Command 11-Rotation Number
0330	5AFH	Pn348	Internal Position Command 11-Pulse Number
0331	5B3H	Pn349	Internal Position Command 11-Move Speed
0332	5E0H	Pn350	Internal Position Command 12-Rotation Number
0333	5E1H	Pn351	Internal Position Command 12-Pulse Number
0334	5E3H	Pn352	Internal Position Command 12-Move Speed
0335	5E4H	Pn353	Internal Position Command 13-Rotation Number
0336	5E5H	Pn354	Internal Position Command 13- Pulse Number
0337	5E6H	Pn355	Internal Position Command 13- Move Speed
0338	5E7H	Pn356	Internal Position Command 14-Rotation Number
0339	5E8H	Pn357	Internal Position Command 14- Pulse Number
033A	5E9H	Pn358	Internal Position Command 14- Move Speed
033B	5EAH	Pn359	Internal Position Command 15-Rotation Number
033C	5EBH	Pn360	Internal Position Command 15- Pulse Number
033D	5ECH	Pn361	Internal Position Command 15- Move Speed
033E	5EDH	Pn362	Internal Position Command 16- Rotation Number
033F	5EEH	Pn363	Internal Position Command 16- Pulse Number
0340	5EFH	Pn364	Internal Position Command 16-Move Speed
0341	54AH	Pn365	Setting for HOME routine
0342	54BH	Pn366	1 st preset speed of HOME (high speed)
0343	54CH	Pn367	2 nd preset speed of HOME ( low speed )
0344	54DH	Pn368	HOME Position Offset. (No of Revolutions)
0345	54EH	Pn369	HOME – Bias Pulse value (No of pulses)

**Quick Setup parameters**

Address		Parameter	Name of parameter
RS485	RS232		
0401	530H	qn401	Speed Loop Gain 1
0402	531H	qn402	Integral Time constant for Speed Loop 1
0403	53AH	qn403	Speed Loop Gain 2
0404	53BH	qn404	Integral Time constant for Speed Loop 2
0405	55AH	qn405	Position Loop Gain 1
0406	551H	qn406	Position Loop Gain 2
0407	55BH	qn407	Position Loop Feed-Forward Gain

**Multi-function programmable contact parameter**

Address		Parameter	Name of parameter
RS485	RS232		
0501	5C0H	Hn501	DI-1 Programmable digital inupt
0502	5C1H	Hn502	DI-2 Programmable digital inupt
0503	5C2H	Hn503	DI-3 Programmable digital inupt
0504	5C3H	Hn504	DI-4 Programmable digital inupt
0505	5C4H	Hn505	DI-5 Programmable digital inupt
0506	5C5H	Hn506	DI-6 Programmable digital inupt
0507	5C6H	Hn507	DI-7 Programmable digital inupt
0508	5C7H	Hn508	DI-8 Programmable digital inupt
0509	5C8H	Hn509	DI-9 Programmable digital inupt
050A	5C9H	Hn510	DI-10 Programmable digital inupt
050B	5CAH	Hn511	DI-11 Programmable digital inupt
050C	5CBH	Hn512	DI-12 Programmable digital inupt
050D	5CCH	Hn513	DI-13 Programmable digital inupt
050E	5F4H	Hn514	DO-1 Programmable digital output
050F	5F5H	Hn515	DO-2 Programmable digital output
0510	5F6H	Hn516	DO-3 Programmable digital output
0511	5F7H	Hn517	DO-4 Programmable digital output
0512	5CEH	Hn518	Digital input control method selection
0513	5FFH	Hn519	Digital input status control in communication mode

## Display parameters

Address		Parameter	Name of parameter
RS485	RS232		
0601	6E4H	Un-01	Actual Motor Speed
0602	9B6H	Un-02	Actual Motor Torque
0603	691H	Un-03	Regenerative load rate
0604	693H	Un-04	Accumulated load rate
0605	694H	Un-05	Max load rate
0606	678H	Un-06	Speed Command
0607	65CH	Un-07	Position Error Value
0608	688H	Un-08	Position Feed-back Value
0609	632H	Un-09	ExternalVoltage Command
060A	6B7H	Un-10	(Vdc Bus) Main Loop Voltage
060B	695H	Un-11	External Spped Limit Command Value
060C	6C0H	Un-12	External CCW Torque Limit Command Value
060D	6C1H	Un-13	External CW Torque Limit Command Value
060E	8BBH	Un-14	Motor feed back – Rotation value (absolute value)
060F	8BAH	Un-15	Motor feed back – Less then one rotation pulse value(absolute value)
0610	8C5H	Un-16	Pulse command – rotation value(absolute value)
0611	8C4H	Un-17	Pulse Command-Pulse value less than one rotation(Absolute value)
0612	67EH	Un-18	Torque command
0613	844H	Un-19	Load inertia ratio




## Chapter 8 Troubleshooting

### 8-1 Alarm functions

The Alarm codes are displayed in a format such as that shown below. For any Alarm messages, refer to this section to identify the cause and dispel the error. To reset the Alarm message by following the pages description. If this is not possible for any reason then contact your local supplier for assistance.

#### Alarm Status Display :



For Alarm List refer to the section 8-2. In the example above AL-01 indicates (Under Voltage)

There is also an Alarm history which can record ten entries of alarm records.

History records are listed as the alarm history record table shows.

#### Alarm History Record

Display	Explanation
AL - □□	The Latest Alarm.
A1 - □□	Previous First Alarm.
A2 - □□	Previous Second Alarm.
A3 - □□	Previous Third Alarm.
A4 - □□	Previous Fourth Alarm.
A5 - □□	Previous Fifth Alarm.
A6 - □□	Previous Sixth Alarm.
A7 - □□	Previous Seventh Alarm.
A8 - □□	Previous Eighth Alarm.
A9 - □□	Previous Ninth Alarm.

Latest record  
↑  
↓  
Earliest record

**Note :** □□ is denotation of the Alarm Codes.

**Example:**

Following table are procedures to access the alarm history record parameter.

Steps	Key	LED Display	Procedures
1	Turn On the Power		On" power on " <b>Drive Status</b> parameter is displayed.
2			Press <b>MODE key</b> to enter the Alarm History record.
3			Press <b>Key</b> to view the Alarm 1 message that previously happened and the alarm code is "03" (Overload)
4			Press <b>Key</b> again to view Alarm 2 message and repeat this to see entire alarm history list. In this example Alarm code is 01. (Under voltage)
5			Press <b>MODE key</b> once to view System Parameters. Repeat this to select all other available parameters.



## 8-2 Troubleshooting of Alarm and Warning

Alarm Code	Alarm Name and Description	Corrective Actions	Reset Method	Fault Status Digital Output			
				CN1-25 BB/A3	CN1-24 ST/A2	CN1-23 PC/A1	CN1-22 LM/A0
00	<b>Normal</b>	—	—	If there is no Alarm, <b>CN1-22~CN1-25</b> operates in accordance with default function. Please refer to <b>2-2-1</b> .			
01	<b>Under-voltage</b>	Use multi-meter to check whether the input voltage is within the specified limit. If it can not be solved, there may be failure inside the Drive.	Turn ALRS(DI) ON	1	1	1	0
	The main circuit voltage is below its minimum specified value. (190Vac)						
02	<b>Over-voltage (Regeneration error)</b>	<ol style="list-style-type: none"> <li>Use multi-meter to check whether the input voltage is within the specified limit.</li> <li>Check the Parameter <b>Cn012</b> if it is setting correctly.</li> <li>If this alarm appears during operation. Extend ac/deceleration time or reduce load ratio in the permitted range. Otherwise, an external regeneration resistor is needed. (Please contact your supplier for assistance.)</li> </ol>	Turn ALRS(DI) ON	1	1	0	1
	<ol style="list-style-type: none"> <li>The main circuit voltage is exceeded maximum allowable value. (410V)</li> <li>Regeneration voltage is too high.</li> </ol>						
03	<b>Motor Over-load</b>	<ol style="list-style-type: none"> <li>Check connection for Motor terminal s (U,V,W) and Encoder.</li> <li>Adjust the Drive gain, If gain is not correctly adjusted, it would cause motor vibration and large current will lead to motor over load.</li> <li>Extend acc/deceleration time or reduce load ratio in the permitted range.</li> </ol>	Turn ALRS(DI) ON	1	1	0	0
	The drive has exceeded its rated load during continuous operation. When the loading is equal to 2 times of rated loading, alarm occurs within 10sec.						
04	<b>Drive Over-current</b>	<ol style="list-style-type: none"> <li>Check connection of the motor cable (U,V,W) and encoder. Check power cable connection. Refer to the diagram in Chapter 2.</li> <li>Turn off the power, and turn on again after 30 min. If the alarm still exists, there may be power module malfunction or noise consider the drive for test and repair.</li> </ol>	Reset Power Supply	1	0	1	1
	Drive main circuit Over current or Transistor error.						

Alarm Code	Alarm Name and Description	Corrective Actions	Reset Method	Alarm Status Digital Output			
				CN1-25 BB/A3	CN1-24 ST/A2	CN1-23 PC/A1	CN1-22 LM/A0
05	<b>Encoder ABZ phase signal error</b>	1. Check the motor's encoder connections. 2. Check the encoder if short circuit, poor solder joints or break. 3. Check the encoder signal terminals CN2-1 and CN2-2. ( power cable 5v)	Reset Power Supply	1	0	1	0
	Motor's encoder failure or encoder connection problem.						
06	<b>Encoder UVW phase signal error</b>		Reset Power Supply	1	0	0	1
	Motor's encoder failure or encoder connection problem.						
07	Multi-function contact setting error	1. Check parameters Hn501~Hn513, trigger level selected by 2 <sup>nd</sup> digit of Hn 501 to 513 should be the same for all inputs <b>DI-1~DI-13</b> . 2. Check parameters setting of <b>Hn514 ~ Hn517</b> should NOT be the same for outputs contact <b>DO-1~DO-4</b> .	Reset Power Supply	1	0	0	0
	Input/output contacts function setting error.						
08	<b>Memory Error</b>	Disconnect all command cable then re-cycle the power. If alarm still occurs, it means the Drive was failure.	Reset Power Supply	0	1	1	1
	Parameter write-in error						
09	<b>Emergency Stop</b>	1. Disable Emergency stop signal input. 2. Internal mal-function. Ensure that all connection are correct, refer to Chapter 2 Power and motor circuit diagrams connection. Control wiring diagrams.	Turn ALRS(DI) ON	0	1	1	0
	When the input contact point EMC is activated. Alarm 09 appears.						
10	<b>Motor over-current</b>	1. Check if the motor wiring (U,V,W) and encoder wiring correct or not. 2. Internal interference and mal-function. Ensure that all connection are correct, refer to Chapter 2 Power and motor circuit diagrams.	Turn ALRS(DI) ON	0	1	0	1
	Motor current is 4 times greater than rated current.						

Alarm Code	Alarm Name and Description	Corrective Actions	Reset Method	Alarm Status Digital Output			
				CN1-25 BB/A3	CN1-24 ST/A2	CN1-23 PC/A1	CN1-22 LM/A0
11	<b>Position error</b>	1. Increase the position loop gain ( <b>Pn310</b> and <b>Pn311</b> ) setting value. 2. Increase in position tolerance value by ( <b>Pn307</b> ) for a better motor response. 3. Extend the time of ac/deceleration or reduce load inertia in the permitted range. 4. Check if the motor wiring (U,V,W) is correct.	Turn ALRS (DI) ON	0	1	0	0
	The deviation between Pulse command and encoder feed back ( position error) is greater than the setting of <b>Pn308</b> or <b>Pn309</b> .						
12	<b>Motor over speed</b>	1. Reduce the speed command. 2. Electronic gear ratio is incorrect check and set correctly. 3. Adjust speed loop gains ( <b>Sn211</b> & <b>Sn213</b> ) for a better motor response.	Turn ALRS (DI) ON	0	0	1	1
	Motor's speed is 1.5 times more than motor's rated speed.						
13	<b>CPU Error</b>	Turn off the power. Turn on again after 30min. If error alarm still exists, this may be due to external interference. Refer to the chapter 2 Motor 、 power cable and control signals connections.	Reset Power Supply	0	0	1	0
	Control system Mal-function.						
14	<b>Drive disable</b>	1. Remove input contact signal <b>CCWL</b> or <b>CWL</b> . 2. Check all input wiring for correct connections. 3. For the selected High /Low logic potential settings refer to Section 5-6-1.	Turn ALRS (DI) ON	0	0	0	1
	When input contacts <b>CCWL</b> & <b>CWL</b> are operated at the same time this alarm occurs.						
15	<b>Drive overheat</b>	Over-load for a long duration will cause driver overheat, check and reset operation system.	Turn ALRS (DI) ON	0	0	0	0
	Power transistor temperature exceed 90°C.						

## Alarm Reset Methods

1. carry out the suggestions below to reset Alarm.
  - (a) **Reset by input signal:** Once the cause of Alarm is rectified, disable **SON** signal (Switch off Servo ON), then activate input signal **ALRS**. Alarm condition should be cleared and the drive will be ready for operation. Reference 5-6-1 for setting SON and Alarm signal.
  - (b) **Reset from Keypad :** Once the cause of Alarm is rectified, disable **SON** signal (Switch off Servo ON), then press the buttons  and  at the same time to reset Alarm and the drive will be ready for operation.
2. **Power reset:** Once the cause of Alarm is rectified, disable **SON** signal (Switch off Servo ON) and re-cycling power. Alarm condition can be reset and the drive will be ready for operation.

### Warning!

- 1) **Before applying power rest , ensure that SON is off ( SON signal is removed first) to prevent danger.**
- 2) **Ensure that the speed commands are removed before the alarm is reset, otherwise the motor may run abruptly once the alarm signal is reset.**

## Chapter 9 Specifications

### 9-1 Specifications and Dimension for Servo Drives





Servo motor for JSDA-□□□□		15A	20A	30A	50A3	75A3
Available Servo Motor (Applicable Motor Models) JSMA-□□□□		SC02(3000 rpm)	SC04(3000 rpm)	SC08(3000 rpm)	MA15(1000 rpm)	MB30(2000 rpm)
		SC04(3000 rpm)	SC08(3000 rpm)	MA10(1000 rpm)	MB15(2000 rpm)	MC30(3000 rpm)
		LC03(3000 rpm)	LC08(3000 rpm)	MB10(2000 rpm)	MC15(3000 rpm)	—
		—	MA05(1000 rpm)	MC10(3000 rpm)	MB20(2000 rpm)	—
		—	MH05(1500 rpm)	MH10(1500 rpm)	MC20(3000 rpm)	—
Servo motor capacity [KW] Max.		0.4	0.8	1.0	2.0	3.0
Continuous output current [A rms]		3.5	4.4	5.16	9.18	14.00
Max. output current [A rms]		10.5	13.8	15.50	27.50	42.00
Input Power Supply	Main Circuit R/S/T	Single/Three Phase 170 ~ 253Vac 50/60Hz ±5%			Three Phase 170 ~ 253Vac 50/60Hz ±5%	
	Control Circuit R/S	Single Phase 200 ~ 230Vac 50/60Hz ±5%				
Cooling System		Natural Air Cooling			Fan Cooling	
Control of Main Circuit		Three-phase full-wave rectification IGBT- SVPWM Control				
Control Mode		Position(Pulse input), Position (Internal control), Speed, Torque, Position/Speed, Speed/Torque, Position/Torque,				
Resolution of Encoder Feedback		Incremental type: 2000ppr / 2500ppr / 8192ppr				
Regeneration /Dynamic Brake		Built-in (brake Transistor and brake resistor)				
Panel and operation key		5 digital seven-segment display ; four function key.				
Communication interface		RS-232 / RS- 485 (Modbus protocol)				

<b>Position Control Mode</b>	Command Source		External Pulse Control / 16-Stage internal register control
	Input Pulse	Type	Positive/Negative Edge Trigger Type : CW/CCW, CLK+DIR, A Phase + B Phase
		Waveform	Line Driver(+5V), Open Collector
		Max. Frequency	500 KHz(Line Driver) / 200 KHz(Open Collector)
	Electronice Gear		$1/200 \leq A/B \leq 200$ ( A=1~50000, B=1~50000 )
	Position Smoothing Constant (Input Ripple Filtering)		Ripple Time Constant 0~10sec (Time Constant 0~10 sec)
	Final Position Tolerance (In Position)		0~50000 Pulse
	Torque Limit Operation		Set by Parameters
Feed Forward Compensation		Set by Parameters	
<b>Speed Control Mode</b>	Command Source		External Analog Command / 3-Stage internal Parameters
	Analog voltage input range		$\pm 10V_{dc}$
	Input Impedance		Approx.10k ohm
	Speed Control Range		1 : 5000(Internal speed control) / 1 : 2000(External analog voltage control)
	Speed fluctuation Rate		-0.03% or less at Load fluctuation 0 to 100% (at Rated Speed) 0.2% or less at power fluctuation $\pm 10\%$ (at Rated Speed) 0.5% or less at ambient temperature fluctuation 0 °C to 50 °C (at Rated Speed)
	Zero Speed Command		0~3000rpm
	Limit of Speed up or down		Line and speed up or down, time constant 0~50sec, smoothing time constant 0~10sec
	P/PI switch		Switch by control Terminal Input
	Speed Reached		0~3000rpm
	Servo Lock		Set by Parameters (Switch to lock on Position Command)
	Torque Limit		Set by Parameters
	Frequency Response Characteristic		Max. 400Hz







<b>Torque Control Mode</b>	<b>Voltage Command</b>	0~±10Vdc / 0~±3000rpm		
	<b>Input Impedance</b>	About 10k ohm		
	<b>Torque Time Constant</b>	Time Constant 0~50sec		
<b>Digital</b>	<b>Position Output</b>	<b>Output Type</b>	A, B, Z Line Drive Output	
		<b>Encoder Ratio</b>	1 ~ 8192 Encoder Ratio (any Arbitrary Value)	
	<b>DI[NPN/ PNP] Input</b>	<b>Optional Input To 13 ports</b>	Servo ON, P/PI switching, inhibit forward/reverse drive, error pulse clear, servo lock, Emergency stop, internal speed choice, run mode switching, inhibit position command, gain switching, electronic gear ratio setting, internal position command choice, internal position command trigger, internal position command pause, original point positioning, return to original point, external torque limit, control model switching, forward/reverse switching, internal speedsetting, inhibit pulse command	
	<b>DO Output</b>	<b>Fix Output To 4 Ports</b>	Reached Torques Limits, In Position, Forward/Reverse Drive Inhibit, Base Block, Alarm Bit Output	
<b>Optional Input to 4 ports</b>		Servo Motor Warning, Servo Ready, Zero Speed, Positioning Completed, Speed Reach, Brake interlock, Home Completed		
<b>Analog Monitoring Output</b>		Monitor Signal can be set by Parameters.		
<b>Protection Function</b>		Overcurrent, Over Voltage, Undervoltage, Overheat, Overload, Overspeed, Excessive deviation, decoder abnormal, rise again abnormal, Memory abnormal		
<b>Environment</b>	<b>Altitude</b>	Sea level 1000m below		
	<b>Install Location</b>	Indoor (avoiding direct sunshine) no erosion air (avoiding oil gases, inflammable gas and dust)		
	<b>Temperature</b>	Operating Temperature 0~ 55 °C , storage Temperature: -20 ~ +85 °C		
	<b>Humidity</b>	Operating, storage below 90% RH		
	<b>Vibration</b>	Below 0.5G		





※ Dimension for JSDA-15 and JSDA-20



※ Dimension for JSDA-30




※ Dimension for JSDA-50 and JSDA-75



## 9-2 Specifications and Dimension for Servomotors

### Description for Servo Motor Type Number



## ※ Standard Specifications for Low Inertia and Super Low Inertia

Motor Mode	Symbol	Unit	JSMA-□□□□			
			SC01	SC02	SC04	SC08
Drive Mode			15A	15A	15A/20A	20A/30A
Rate Output	$P_R$	W	100	200	400	750
Rated Line Voltage(rms)	$V_T$	V	71.41	88.34	82.2	117.74
Rated Torque	$T_R$	N · m	0.32	0.637	1.274	2.386
Rated Current	$I_R$	A	0.94	1.8	3.5	4.4
Rated Speed	$N_R$	rpm	3000	3000	3000	3000
Max. Torque	$T_{max}$	N · m	0.95	1.911	3.822	7.159
Max. Armature Current	$I_{max}$	A	2.82	6.3	10.5	13.2
Torque Constant	$K_T$	N · m/A	0.391±10%	0.40±10%	0.386±10%	0.604±10%
Induced Voltage Constant	$K_E$	V/k rpm	39.45	42.4	40.4	63.3
Rotor Moment of Inertia	$J_M$	Kg · cm <sup>2</sup>	0.036±10%	0.164±10%	0.277±10%	0.907±10%
Back EMF(@1800rpm)	$V_{EMF}$	Volts	41±10%	44.06±10%	42±10%	65.8±10%
Armature Resistance	$R_a$	$\Omega$	3.1±10%	4.74±10%	1.96±10%	1.4±10%
Armature Inductance	$L_a$	mH	4.2±10%	9.6±10%	3.8±10%	2.2±10%
Mechanical Time Constant	$T_m$	ms	0.5±10%	0.712±10%	0.48±10%	0.428±10%
Electrical Time Constant	$T_e$	ms	0.9±10%	2.025±10%	1.94±10%	1.57±10%
Weight (standard)	W	kgw	0.7	0.9	1.44	2.5
Insulation Grade	—	—	Class B (130°C)	Class F (155°C)		
Mechanical Brake	Rated Voltage	V	VDC 24V±10%			
	Static Friction Torque	N · m	—	1.3	1.3	3.25
	Rotor Moment of Inertia	kg · cm <sup>2</sup>	—	0.0254	0.0254	0.22
	Current Dissipation	A	—	0.25	0.25	0.5
	Weight	W	kgw	—	0.55	0.55
Operating Ambient Temp.	T	°C	0 ~ 40			
Operating Ambient Humidity	RH	%	<80	<90		
Storage Temp.	T	°C	-20 ~ 60			
Storage Humidity	RH	%	<80	<90		



※ Standard Specifications for Low Inertia and Super Low Inertia

Motor Mode	Symbol	Unit	JSMA-□□□□	
			LC03	LC08
Drive Mode			15A	20A
Rate Output	$P_R$	W	300	750
Rated Line Voltage(rms)	$V_T$	V	109.2	150.52
Rated Torque	$T_R$	N · m	0.95	2.391
Rated Current	$I_R$	A	2.0	3.4
Rated Speed	$N_R$	rpm	3000	3000
Max. Torque	$T_{max}$	N · m	2.861	7.164
Max. Armature Current	$I_{max}$	A	6.0	10.2
Torque Constant	$K_T$	N · m/A	0.523±10%	0.774±10%
Induced Voltage Constant	$K_E$	V/k rpm	54.9	81.4
Rotor Moment of Inertia	$J_M$	Kg · cm <sup>2</sup>	0.6773±10%	2.459±10%
Back EMF(@1800rpm)	$V_{EMF}$	Volts	57±10%	84.6±10%
Armature Resistance	$R_a$	$\Omega$	5.58±10%	2.18±10%
Armature Inductance	$L_a$	mH	11.6±10%	6.8±10%
Mechanical Time Constant	$T_m$	ms	1.978±10%	1.036±10%
Electrical Time Constant	$T_e$	ms	2.05±10%	3.12±10%
Weight (standard)	$W$	kgw	1.588	3.05
Insulation Grade	—	—	Class F (155°C)	
Mechanical Brake	Rated Voltage	V	VDC 24V±10%	
	Static Friction Torque	N · m	1.176	2.352
	Rotor Moment of Inertia	kg · cm <sup>2</sup>	0.098	0.225
	Current Dissipation	A	0.45	0.44
	Weight	$W$	kgw	0.68
Operating Ambient Temp.	$T$	°C	0 ~ 40	
Operating Ambient Humidity	RH	%	<90	
Storage Temp.	$T$	°C	-20 ~ 60	
Storage Humidity	RH	%	<90	

## ※ Standard Specifications for Middle Inertia

Motor Mode	Symbol	Unit	JSMA-□□□□					
			MA05	MH05	MA10	MB10	MC10	MH10
Drive Mode			20A	20A	30A	30A	30A	30A
Rate Output	P <sub>R</sub>	W	550	550	1000	1000	1000	1000
Rated Line Voltage(rms)	V <sub>T</sub>	V	116.1	161.86	134.8	134.2	133.23	134.67
Rated Torque	T <sub>R</sub>	N · m	5.252	3.502	9.545	4.782	3.2	6.403
Rated Current	I <sub>R</sub>	A	3.43	2.98	5.16	5.16	4.96	5
Rated Speed	N <sub>R</sub>	rpm	1000	1500	1000	2000	3000	1500
Max. Torque	T <sub>max</sub>	N · m	15.758	10.507	28.645	14.327	9.6	19.209
Max. Armature Current	I <sub>max</sub>	A	10.3	8.94	15.5	15.5	14.88	15
Torque Constant	K <sub>T</sub>	N · m/A	1.679±10%	1.294±10%	2.039±10%	1.019±10%	0.715±10%	1.41±10%
Induced Voltage Constant	K <sub>E</sub>	V/k rpm	175.9	135.55	213.6	106.8	74.58	147.57
Rotor Moment of Inertia	J <sub>M</sub>	Kg · cm <sup>2</sup>	6.26±10%	6.26±10%	12.14±10%	6.26±10%	4.6±10%	12.14±10%
Back EMF(@1800rpm)	V <sub>EMF</sub>	Volts	182.8±10%	140.87±10%	222±10%	111±10%	80.91±10%	153.36±10%
Armature Resistance	R <sub>a</sub>	Ω	3.58±10%	2.31±10%	1.853±10%	1.22±10%	1.02±10%	0.946±10%
Armature Inductance	L <sub>a</sub>	mH	18.33±10%	10.8±10%	12.14±10%	6.7±10%	5.06±10%	8.781±10%
Mechanical Time Constant	T <sub>m</sub>	ms	1.19±10%	1.19±10%	0.81±10%	1.09±10%		0.82±10%
Electrical Time Constant	T <sub>e</sub>	ms	5.12±10%	5.12±10%	6.55±10%	5.52±10%	4.96±10%	9.282±10%
Weight (standard)	W	kgw	6.47	6.47	10.18	6.47	5.29	10.18
Insulation Grade	—	—	Class B (130°C)					
Mechanical Brake	Rated Voltage	V	VDC 24V±10%					
	Static Friction Torque	N · m	15	15	15	15	15	15
	Rotor Moment of Inertia	kg · cm <sup>2</sup>	0.675	0.675	0.675	0.675	0.675	0.675
	Current Dissipation	A	0.58	0.58	0.58	0.58	0.58	0.58
	Weight	W	kgw	1.2	1.2	1.2	1.2	1.2
Operating Ambient Temp.	T	°C	0 ~ 40					
Operating Ambient Humidity	RH	%	<90					
Storage Temp.	T	°C	-20 ~ 60					
Storage Humidity	RH	%	<90					




※Standard Specifications for Middle Inertia motor

Motor Mode	Symbol	Unit	JSMA-□□□□						
			MA15	MB15	MC15	MB20	MC20	MB30	MC30
Drive Mode			30A/50A3	30A/50A3	30A/50A3	50A3	50A3	75A3	75A3
Rate Output	P <sub>R</sub>	W	1500	1500	1500	2000	2000	3000	3000
Rated Line Voltage(rms)	V <sub>T</sub>	V	138.24	141.56	142.43	143.71	140.81	141.7	139.68
Rated Torque	T <sub>R</sub>	N · m	14.327	7.164	4.782	9.545	6.37	14.327	9.545
Rated Current	I <sub>R</sub>	A	7.45	7.57	7.06	9.18	9.5	14	14
Rated Speed	N <sub>R</sub>	rpm	1000	2000	3000	2000	3000	2000	3000
Max. Torque	T <sub>max</sub>	N · m	42.963	21.492	14.327	28.645	19.11	42.963	28.645
Max. Armature Current	I <sub>max</sub>	A	22.35	22.71	21.2	27.5	28.5	42	42
Torque Constant	K <sub>T</sub>	N · mA	2.108±10%	1.06±10%	0.74±10%	1.14±10%	0.74±10%	1.13±10%	0.75±10%
Induced Voltage Constant	K <sub>E</sub>	V/k rpm	220.8	108.99	77.5	119.4	77.4	118.3	78.5
Rotor Moment of Inertia	J <sub>M</sub>	Kg · cm <sup>2</sup>	17.92±10%	8.882±5%	6.26±10%	12.14±10%	8.882±5%	17.92±10%	12.14±10%
Back EMF(@1800rpm)	V <sub>BMF</sub>	Volts	229.5±10%	113.2±10%	80.54±10%	124±10%	80.44±10%	122.94±10%	81.58±10%
Armature Resistance	R <sub>a</sub>	Ω	1.19±10%	0.79±10%	0.653±10%	0.58±10%	0.4±10%	0.333±10%	0.247±10%
Armature Inductance	L <sub>a</sub>	mH	8.44±10%	4.74±10%	3.58±10%	3.78±10%	2.4±10%	2.124±10%	1.62±10%
Mechanical Time Constant	T <sub>m</sub>	ms		1.14±10%	1.12±10%	0.80±10%		0.71±10%	0.81±10%
Electrical Time Constant	T <sub>e</sub>	ms	7.09±10%	6±10%	5.48±10%	6.59±10%	6±10%	7.08±10%	6.57±10%
Weight (standard)	W	kgw	13.87	8.08	6.47	10.18	8.08	13.87	10.18
Insulation Grade	—	—	Class B (130°C)						
Mechanical Brake	Rated Voltage	V	VDC 24V±10%						
	Static Friction Torque	N · m	15	15	15	15	15	15	15
	Rotor Moment of Inertia	kg · cm <sup>2</sup>	0.725	0.725	0.725	0.725	0.725	0.725	0.725
	Current Dissipation	A	0.59	0.59	0.59	0.59	0.59	0.59	0.59
	Weight	W	kgw	1.7	1.7	1.7	1.7	1.7	1.7
Operating Ambient Temp.	T	°C	0 ~ 40						
Operating Ambient Humidity	RH	%	<90						
Storage Temp.	T	°C	-20 ~ 60						
Storage Humidity	RH	%	<90						


## JSMA-L dimension diagram

	Type	A	B	C	D	E	F	G	H	J	K	L	M
With Brake	LC03	$\phi 5.5$	$\phi 100$	$\phi 90$	76	2	5	$\phi 14$	$\phi 70$	20	3	30	147.8
	LC08	$\phi 6.5$	$\phi 112$	$\phi 100$	86	2	5	$\phi 16$	$\phi 80$	25	3	35	183.2
Without Brake	LC03	$\phi 5.5$	$\phi 100$	$\phi 90$	76	2	5	$\phi 14$	$\phi 70$	20	3	30	113.4
	LC08	$\phi 6.5$	$\phi 112$	$\phi 100$	86	2	5	$\phi 16$	$\phi 80$	25	3	35	148




### JSMA-S dimension diagram(1)

	Type	A	B	C	D	E	F	G	H	J	K	L
With Brake	SC02	$\phi 4.5$	60	$\phi 70$	2	5	$\phi 14$	$\phi 50$	20	3	27	154.5
	SC04AF	$\phi 5.5$	60	$\phi 70$	2	5	$\phi 14$	$\phi 50$	20	3	27	130.5
	SC08	$\phi 5.5$	80	$\phi 90$	2.5	6	$\phi 19$	$\phi 70$	30	3	37	137
Without Brake	SC02	$\phi 4.5$	60	$\phi 70$	2	5	$\phi 14$	$\phi 50$	20	3	27	80.5
	SC04AF	$\phi 5.5$	60	$\phi 70$	2	5	$\phi 14$	$\phi 50$	20	3	27	95.5
	SC08	$\phi 5.5$	80	$\phi 90$	2.5	6	$\phi 19$	$\phi 70$	30	3	37	102





## JSMA-S dimension diagram(2)

	Type	A	B	C	D	E	F	G	H	J	K	L
With Brake	SC04AB/H	$\phi 5.5$	60	$\phi 70$	2	5	$\phi 14$	$\phi 50$	20	3	27	157.1
Without Brake	SC04AB/H	$\phi 5.5$	60	$\phi 70$	2	5	$\phi 14$	$\phi 50$	20	3	27	121.7




JSMA- SC01 dimension










## JSMA –M middle inertia motor dimension





Type	With Brake L (mm)	Without Brake L (mm)	Type	With Brake L (mm)	Without Brake L (mm)
MA05	219.8	164.8	MA15	319.8	264.8
MH05	219.8	164.8	MB15	239.8	184.8
MA10	269.8	214.8	MC15	219.8	164.8
MB10	219.8	164.8	MB20	269.8	214.8
MC10	204.8	149.8	MC20	239.8	184.8
MH10	269.8	214.8	MB30	319.8	264.8
			MC30	269.8	214.8





## Appendix A: Peripheral for Servo motors

Part No.	Description	Model
JSSCN20P	Encoder Connector (3M 20pin)	
JSSCN50P	I/O Connector (3M 50pin)	
JSSCNM04	JSMA-S/L Power Connector (AMP 4pin)	
JSSCNP09	JSMA-S/L Encoder Connector (AMP 9pin)	
JSSCNML04	JSMA-M L-type Power Connector (MS 4pin)	
JSSCNPL09	JSMA-M L-type Power Connector (with brake) / Encoder Connector (MS 9pin)	
JSSCNMS04	JSMA-M S-type Power Connector (MS 4pin)	
JSSCNPS09	JSMA-M S-type Power Connector (with brake) / Encoder Connector (MS 9 pin)	
JSSLM001	JSMA-S/L 1M Power Cable (AMP)	
JSSLM003	JSMA-S/L 3M Power Cable (AMP)	
JSSLM005	JSMA-S/L 5M Power Cable (AMP)	
JSSLM010	JSMA-S/L 10M Power Cable (AMP)	
JSSLP001	JSMA-S/L 1M Encoder Cable (AMP+3M)	
JSSLP003	JSMA-S/L 3M Encoder Cable (AMP+3M)	
JSSLP005	JSMA-S/L 5M Encoder Cable (AMP+3M)	
JSSLP010	JSMA-S/L 10M Encoder Cable (AMP+3M)	

Part No.	Description	Model.
JSSMLM001	JSMA-M 1M L-type Power Cable (MSL)	
JSSMLM003	JSMA-M 3M L-type Power Cable (MSL)	
JSSMLM005	JSMA-M 5M L-type Power Cable (MSL)	
JSSMLM010	JSMA-M 10M L-type Power Cable (MSL)	
JSSMLP001	JSMA-M 1M L-type Encoder Cable (MSL+3M)	
JSSMLP003	JSMA-M 3M L-type Encoder Cable (MSL+3M)	
JSSMLP005	JSMA-M 5M L-type Encoder Cable (MSL+3M)	
JSSMLP010	JSMA-M 10M L-type Encoder Cable (MSL+3M)	
JSSMSM001	JSMA-M 1M S-type Power Cable (MSS)	
JSSMSM003	JSMA-M 3M S-type Power Cable (MSS)	
JSSMSM005	JSMA-M 5M S-type Power Cable (MSS)	
JSSMSM010	JSMA-M 10M S-type Power Cable (MSS)	
JSSMSP001	JSMA-M 1M S-type Encoder Cable (MSS+3M)	
JSSMSP003	JSMA-M 3M S-type Encoder Cable (MSS+3M)	
JSSMSP005	JSMA-M 5M S-type Encoder Cable (MSS+3M)	
JSSMSP010	JSMA-M 10M S-type Encoder Cable (MSS+3M)	





**TECO Electric & Machinery Co., Ltd.**

10F., No.3-1, Yuancyu St., Nangang District,  
Taipei City 115, Taiwan  
Tel :+886-2-6615-9111  
Fax : +886-2-6615-0933

<http://www.teco.com.tw>

Distributor
-------------

Ver.02 2008.06

---

This manual may be modified when necessary because of improvement of the product, modification, or changes in specifications, This manual is subject to change without notice.